




# WORKSHOP SERVICE MANUAL

Part 1

## CONTENTS

	Section
INTRODUCTION _____	1
CAB AND EQUIPMENT _____	2
SPLITTING THE TRACTOR _____	3
ENGINE _____	4
GEARBOX _____	5
REAR AXLE _____	6





630212

Centra



## Introduction

### 1 A01 Introduction

#### CONTENTS

A .	Using the manual	2
B.	Specifications	3
C.	Chassis dimensions and mounting points	16
D.	Safety precautions	19
E.	Practical advice	21
F.	Installation instructions	24
G.	Conversion table	25
H.	Sealants	33
I.	Tightening torques	33



1A01.2



## Introduction

### A . Using the manual

#### General

The purpose of this manual is to assist Distributors and Dealers in the efficient installation, maintenance and repair of MASSEY FERGUSON machinery. Carrying out the procedures as detailed, together with the use of special tools where appropriate, will enable the operations to be completed within the time stated in the repair time schedule.

#### Page numbering

Example : 7C01-3

This manual is divided into parts and sections. Each page contains the following information :

7 = Section

C = Part

01 = Sequence number within the Part

3 = Page number within the Part

The issue number and the date are indicated at the bottom of the page.

#### Using the manual

To assist with locating information, each section of the manual is preceded by an index listing the Parts contained in that section.

The preliminary operations to be carried out in order to reach the item involved are listed at the beginning of each Part.

Items are indicated by means of identification marks (circles, squares, triangles).

#### Meaning of identification marks

circle ○ (..) identifies part only

square □ [..] identifies part and indicates an adjustment

triangle Δ /.. identifies part and indicates an important point to be noted during removal or refitment

#### Amendments

Amended pages will be issued carrying the same page number as previous pages : only the issue number and the date will change.

Old pages should be destroyed.

#### Special tools

Where the use of a special tool is necessary in an operation, the tool number is shown following the instruction requiring its use.

#### Repairs and replacements

When parts have to be replaced, it is essential that only genuine MASSEY FERGUSON parts are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

Safety features embodied in the tractor may be impaired if other than genuine parts are fitted.

In certain territories, legislation prohibits the fitting of parts not to the tractor manufacturer's specification.


Torque wrench setting figures given in the Workshop Manual must be strictly adhered to. Locking devices must be fitted where specified. If the efficiency of a locking device is impaired during removal it must be renewed.

The tractor warranty may be invalidated by the fitting of other than genuine MASSEY FERGUSON parts. All MASSEY FERGUSON replacement parts have the full backing of the manufacturer's warranty. MASSEY FERGUSON Distributors and Dealers are obliged to supply only genuine service parts.

#### Repair time schedule

The sections in the repair time schedule are identical to those in the workshop manual. The Repair Time Schedule is available, under publication number 1646918M1.





### Introduction

#### B . Specifications

##### Engine

	3050	3060	3065	3070	3080	3095	3115/20	3125/40	
PERKINS Model	A 4.236	A 4.248 S	C 4.236	A T4.236	A 6.354.4	1006-6 HR	1006-6LR	1006-6T7	
Number of cylinders	4	4	4	4	6	6	6	6	
Turbocharger	-	-	yes	yes	-	-	-	yes	
Bore (mm)	98.47	100.96	98.47	98.47	98.47	100	100	100	
Stroke (mm)	127	127	127	127	127	127	127	127	
Cubic capacity (cm <sup>3</sup> )	3860	4060	3860	3860	5800	6000	6000	6000	
Maximum engine power DIN (kW)	52	59	62.5	68.5	73.5	78.5	84.5	92.5	
Maximum torque (Nm)	269	280	319	343	374	415	436	474	
Engine speed at maximum torque	1400	1400	1400	1400	1200	1200	1100	1200	
Idling speed (rev/min)	850	850	850	850	850	850	850	850	
Maximum rated speed (rev/min)	2200	2200	2200	2200	2200	2200	2200	2200	
Torque at rated speed (Nm)	230	260	276	303	325	348	367	401	
Maximum no load speed rev/min	2310	2310	2310	2310	2310	2310	2310	2310	
PTO power DIN (kW)	47	53	57	62	68	72	78	86	
At engine speed of rev/min	2200	2200	2200	2200	2200	2200	2200	2200	
Permissible front PTO power DIN (kW)	52	59	62.5	68.5	69	75	75	75	
Front PTO maximum permissible torque (all speeds) Nm	Same as engine power				300	328	328	328	
Lubrication	Gear type pump : - strainer on suction side and external canister type filter (s)								
Valves	Overhead, push-rod operated								
Valves clearances	(Cold)								
- Inlet	mm (in)	0.30 (0.012)	0.30 (0.012)	0.30 (0.012)	0.30 (0.012)	0.20 (0.008)	0.20 (0.008)	0.20 (0.008)	0.20 (0.008)
- Exhaust	mm (in)	0.30 (0.012)	0.30 (0.012)	0.30 (0.012)	0.30 (0.012)	0.45 (0.018)	0.45 (0.018)	0.45 (0.018)	0.45 (0.018)
Engine oil cooler	no	no	yes	yes	yes	no	no	yes	

##### Fuel system and air cleaner

	3050	3060	3065	3070	3080	3095	3115/20	3125/40
Lift pump	AC DELCO						AC DELCO Type LU	
Pre-filter							C A V	
Fuel filter with sediment bowl	C A V							
Number of elements	1	1	1	1	2	2	2	2
Fuel injection pump	C A V rotary with mechanical governor							
Injection timing	23°	24°	28°	16°	23°	18°	22°	18°
Injectors and nozzle holders	C A V							
Cold weather starting	Thermostart or ether, according to market							
Air cleaner	Two-stage, dry element, with centrifugal prefilter and blockage indicator							



1A01.4

## 3000 / 3100 SERIES TRACTORS



### Introduction

#### Electrical system

**Voltage :**

12 volt, negative earth

**Batteries :** - 3050-3060-3065

1 12 volt maintenance free battery or

2 12 volt *maintenance free batteries (cold climates)*

- 3070-3080-3095-3115/20-3125/40

2 12 volt maintenance free batteries.

**Safety start :**

operated by the clutch pedal.

**Bulbs :**

headlights :

European code 40/45W

sidelights :

5 W

rear/brake lights :

21/5 W

direction indicators :

21 W

number plate light :

10 W

work lamps :

55 W - H3

instrument panel lighting and warning lights :

3 W - 2 W - 1.2 W

roof lights :

2 x 10 W

#### Cooling system

**Operation :**

Pressurized system with centrifugal pump.

Thermostat opening temperature : 83°C (182°F)

Centrifugal water pump :

- belt driven (3050-3060-3065-3070-3080)

- gear driven (3095-3115-3120-3125-3140)

**Fan :**

belt driven

**Belt deflection :**

(on the longest span)

10 mm (3/8") (6 cyl. engine)

19 mm (3/4") (4cyl. engine)

#### Transmission

**Clutch :**

single disc, dry, 330 mm (13 in).

diaphragm type

automatic adjustment.

push-type (3000)

pull-type (3100)

**Gearbox :**

- 8 - 16 or 32 front speed

- with creeper gearbox (ratio 4 to 1) :

24 speed (16 speed gearbox)

48 speed (32 speed gearbox)

- reverse shuttle

#### Final reduction units

**Reduction unit :**

epicyclic, in the rear axle housings.

**Reduction ratios :**

MF 3050-3060-3065

4,714 to 1

MF 3070-3080-3095-3120

5,077 to 1






MF 3115-3125-3140

5,571 to 1



**Introduction**

**ROAD SPEEDS AT 2200 rev/min  
MF 3050/3060/3065 TRACTORS - 16.9 - 34 TYRES  
GEARBOX 4 x 4 (16 speed)**

Speed	A/B Range	RANGE	Speed-shift	30 KPH GEARBOX								40 KPH GEARBOX				
				6 SPEED				32 SPEED				32 SPEED				
				FORWARD		REVERSE		FORWARD		REVERSE		FORWARD		REVERSE		
				KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH			
1 2 3 4	A	L O W	T O R T O I S E 	Slow	-	-	-	-	1.76	1.09	1.87	1.16	2.22	1.38	2.35	1.47
				Fast	2.22	1.38	2.35	1.46	2.22	1.38	2.35	1.46	2.79	1.74	2.97	1.86
				Slow	-	-	-	-	2.07	1.29	2.20	1.37	2.68	1.67	2.86	1.79
				Fast	2.68	1.67	2.86	1.78	2.68	1.67	2.86	1.78	3.39	2.12	3.61	2.26
				Slow	-	-	-	-	2.49	1.55	2.64	1.64	3.15	1.97	3.34	2.09
				Fast	3.15	1.96	3.34	2.08	3.15	1.96	3.34	2.08	4.00	2.50	4.22	2.64
				Slow	-	-	-	-	2.93	1.82	3.12	1.94	3.69	2.30	3.94	2.46
				Fast	3.70	2.30	3.94	2.45	3.70	2.30	3.94	2.45	4.66	2.91	4.97	3.11
1 2 3 4	B	H I G H 	S E E	Slow	-	-	-	-	3.56	2.21	3.32	2.06	4.49	2.81	4.18	2.61
				Fast	4.49	2.79	4.18	2.60	4.49	2.79	4.18	2.60	5.66	3.54	5.28	3.30
				Slow	-	-	-	-	4.25	2.64	3.96	2.46	5.37	3.36	5.02	3.14
				Fast	5.37	3.34	5.02	3.12	5.37	3.34	5.02	3.12	6.78	4.23	6.34	3.96
				Slow	-	-	-	-	4.97	3.09	4.64	2.88	6.29	3.93	5.87	3.67
				Fast	6.69	3.91	5.87	3.65	6.29	3.91	5.87	3.65	7.94	4.96	7.41	4.63
				Slow	-	-	-	-	5.85	3.64	5.46	3.39	7.41	2.94	6.93	4.33
				Fast	7.41	4.60	6.93	4.31	7.41	4.60	6.93	4.31	9.35	5.84	8.76	5.48
1 2 3 4	A	H I G H	H I G H 	Slow	-	-	-	-	7.11	4.42	7.57	4.70	9.00	5.62	9.59	5.99
				Fast	9.00	5.59	9.59	5.96	9.00	5.59	9.59	5.96	11.35	7.09	12.12	7.58
				Slow	-	-	-	-	8.49	5.28	9.06	5.63	10.71	6.69	11.44	7.15
				Fast	10.73	6.67	11.48	7.14	10.73	6.67	11.48	7.14	13.53	8.46	14.45	9.03
				Slow	-	-	-	-	9.57	5.95	10.63	6.61	12.61	7.88	13.42	8.39
				Fast	12.61	7.84	13.42	8.34	12.61	7.84	13.42	8.34	15.93	9.96	16.96	10.60
				Slow	-	-	-	-	11.75	7.30	12.54	7.79	14.85	9.28	15.84	9.90
				Fast	14.85	9.23	15.89	9.88	14.85	9.23	15.89	9.88	18.77	11.73	20.02	12.51
1 2 3 4	B	H I G H 	H I G H 	Slow	-	-	-	-	14.28	8.87	13.33	8.28	18.04	11.23	16.85	10.53
				Fast	18.04	11.21	16.85	10.47	18.04	11.21	16.85	10.47	23.23	14.52	21.30	13.31
				Slow	-	-	-	-	17.03	10.58	15.91	9.89	21.49	13.43	20.06	12.54
				Fast	21.49	13.35	20.06	12.47	21.49	13.53	20.10	12.49	27.15	16.97	25.37	15.86
				Slow	-	-	-	-	19.98	12.42	18.66	11.60	26.25	16.41	25.08	15.68
				Fast	26.21	16.29	24.49	15.22	26.21	16.29	24.49	15.22	33.18	20.74	31.70	19.81
				Slow	-	-	-	-	23.66	14.70	22.11	13.74	29.77	18.61	27.81	17.38
				Fast	29.77	18.50	27.81	17.28	29.77	18.50	27.81	17.28	37.62	23.51	35.16	21.98



1A01.6


3000 / 3100 SERIES TRACTORS



Introduction

ROAD SPEEDS AT 2200 rev/min  
MF 3070/3080/3095/3120 TRACTORS - 16.9 - 38 TYRES  
GEARBOX 4 x 4 (16 speed)

Speed	A/B Range	RANGE	Speed-shift	30 KPH GEARBOX				40 KPH GEARBOX								
				16 SPEED		32 SPEED		32 SPEED								
				FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE					
				KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH	KPH - MPH					
1 2 3 4	A	L O W	T O R T S	Slow	-	-	-	-	1.76	1.10	1.88	1.17	2.22	1.40	2.38	1.50
				Fast	2.22	1.39	2.37	1.48	2.22	1.39	2.37	1.48	2.79	1.76	2.99	1.88
				Slow	-	-	-	-	2.09	1.30	2.24	1.40	2.64	1.66	2.82	1.78
				Fast	2.66	1.66	2.85	1.78	2.66	1.66	2.85	1.78	3.34	2.10	3.56	2.24
				Slow	-	-	-	-	2.46	1.54	2.63	1.64	6.82	4.30	3.30	2.08
				Fast	3.11	1.64	3.33	2.08	3.11	1.64	3.33	2.08	3.92	2.47	4.18	2.63
				Slow	-	-	-	-	2.90	1.81	3.10	1.94	3.67	2.31	3.92	2.47
				Fast	3.67	2.29	3.93	2.45	3.67	2.29	3.93	2.45	4.64	2.92	4.95	3.12
1 2 3 4	B	M E D I U M	S E R I E S	Slow	-	-	-	-	3.48	2.16	3.23	2.01	4.44	2.80	4.14	2.61
				Fast	4.44	2.76	4.14	2.57	4.44	2.76	4.14	2.57	5.61	3.53	5.21	3.28
				Slow	-	-	-	-	4.20	2.61	3.92	2.44	5.30	3.34	4.95	3.12
				Fast	5.30	3.29	4.95	3.08	5.30	3.29	4.95	3.08	6.71	4.23	6.25	3.94
				Slow	-	-	-	-	4.93	3.06	4.60	2.86	6.23	3.92	5.81	3.66
				Fast	6.23	3.87	5.81	3.61	6.23	3.87	5.81	3.61	7.88	4.96	7.35	4.63
				Slow	-	-	-	-	5.81	3.61	5.43	3.37	7.35	4.63	6.86	4.32
				Fast	7.35	4.57	6.86	4.26	7.35	4.57	6.84	4.25	9.28	5.85	8.67	5.46
1 2 3 4	A	H I G H	H I G H	Slow	-	-	-	-	7.04	4.37	7.50	4.66	8.91	5.61	9.50	5.99
				Fast	8.91	5.54	9.50	5.90	8.91	5.54	9.50	5.90	11.26	7.09	12.01	7.57
				Slow	-	-	-	-	8.40	5.22	8.95	5.56	10.63	6.70	11.33	7.14
				Fast	10.63	6.61	11.33	7.04	10.63	6.61	11.33	7.04	13.42	8.45	14.32	9.02
				Slow	-	-	-	-	9.88	6.14	10.54	6.55	12.50	7.88	13.31	8.39
				Fast	12.50	7.77	13.31	8.27	12.50	7.77	13.31	8.27	15.80	9.95	16.83	10.60
				Slow	-	-	-	-	11.64	7.23	12.41	7.71	14.72	9.27	15.69	9.88
				Fast	14.79	9.15	15.69	9.75	14.72	9.15	15.69	9.75	18.61	11.72	19.82	12.49
1 2 3 4	B	H I G H	G R E E N	Slow	-	-	-	-	14.12	8.77	13.20	8.20	17.86	11.25	16.68	10.51
				Fast	17.86	11.10	16.68	10.36	17.86	11.10	16.68	10.36	22.57	14.22	21.08	13.28
				Slow	-	-	-	-	16.85	10.47	15.73	9.77	21.32	13.43	19.91	12.54
				Fast	21.32	13.25	19.91	12.37	21.32	13.25	19.91	12.37	26.95	16.98	25.17	15.86
				Slow	-	-	-	-	19.95	12.40	18.63	11.58	25.01	15.76	23.34	14.70
				Fast	25.01	15.54	23.34	14.50	25.01	15.54	23.34	14.50	31.61	19.91	29.50	18.59
				Slow	-	-	-	-	23.34	14.50	22.78	13.50	29.48	18.57	27.54	17.35
				Fast	29.48	18.32	27.54	17.11	29.48	18.32	27.54	17.11	37.27	23.48	34.83	21.94



# Introduction

## ROAD SPEEDS AT 2200 rev/min - MF 3115 - 3125 - 3140 20.8 - 38 TYRES

Speed	Range	Speed-shift	8 SPEED 30 KPH				16 SPEED 30 KPH				16 SPEED 40 KPH				
			FORWARD		REVERSE		FORWARD		REVERSE		FORWARD		REVERSE		
			KPH	MPH	KPH	MPH	KPH	MPH	KPH	MPH	KPH	MPH	KPH	MPH	
1 2 3 4	LOW 	T	Slow	-	-	-	-	2.54	1.57	2.53	1.57	2.54	1.57	2.53	1.57
		O	Fast	3.22	2.00	3.20	1.99	3.22	2.00	3.20	1.99	3.22	2.00	3.20	1.99
		R	Slow	-	-	-	-	3.84	2.38	3.82	2.37	3.84	2.38	3.82	2.37
		T	Fast	4.86	3.02	4.83	3.00	4.86	3.02	4.83	3.00	4.86	3.02	4.83	3.00
		O	Slow	-	-	-	-	5.32	3.30	5.29	3.28	5.32	3.30	5.29	3.28
		I	Fast	6.73	4.18	6.69	4.15	6.73	4.18	6.69	4.15	6.73	4.18	6.69	4.15
		S	Slow	-	-	-	-	7.12	4.42	7.66	4.76	7.12	4.42	7.66	4.76
		E	Fast	9.74	6.05	9.69	6.02	9.74	6.05	9.69	6.02	9.74	6.05	9.69	6.02
5 6 7 8	HIGH 	H	Slow	-	-	-	-	10.22	6.35	10.16	6.31	10.22	6.35	10.16	6.31
		A	Fast	12.91	8.02	12.84	7.98	12.91	8.02	12.84	7.98	12.91	8.02	12.84	7.98
		R	Slow	-	-	-	-	15.43	9.59	15.34	9.53	15.43	9.59	15.34	9.53
		E	Fast	19.51	12.12	19.39	12.05	19.51	12.12	19.39	12.05	19.51	12.12	19.39	12.05
		S	Slow	-	-	-	-	21.36	13.27	21.23	13.19	21.36	13.27	21.23	13.19
		H	Fast	27.00	16.78	26.84	16.68	27.00	16.78	26.84	16.68	27.00	16.78	26.84	16.68
		A	Slow	-	-	-	-	30.92	19.21	30.74	19.10	30.92	19.21	30.74	19.10
		R	Fast	-	-	-	-	-	-	-	-	39.09	24.29	38.86	24.15

### Power take off

#### Independent power take off (IPTO)

Proportional to the engine speed.  
Hydraulic clutch.

PTO ratio

540 rev/min at 1980 engine rev/min - 3.667 : 1.  
1000 rev/min at 2000 engine rev/min - 2 : 1.

Speed changing  
(according to model)

Either by changing shafts, or by lever selection.  
- 540 rev/min shaft, 35 mm (1.3/8 in) diameter, 6 splines.  
- 1000 rev/min shaft, 35 mm (1.3/8 in) diameter, 21 splines

"Economy" Independent power take off  
(optional extra)

The normal 540 and 1000 rev/min PTO speeds can be obtained at the above stated engine speeds or at 1550 engine rev/min by selecting the "Economy" ratio.

Control

Lever in the cab.



1A01.8

## 3000 / 3100 SERIES TRACTORS



### Introduction

#### Ground speed PTO

(optional extra)

An addition to the independent PTO

Control

From the normal IPTO operating lever.

Speed MF 3050-3060-3065

540 rev/min - 7.87 revolutions of the PTO shaft for one revolution of the rear wheel.

1000 rev/min - 14.83 revolutions of the PTO shaft for one revolution of the rear wheel.

MF 3070-3080-3095

540 rev/min - 8.48 revolutions of the PTO shaft for one revolution of the rear wheel.

1000 rev/min - 15.54 revolutions of the PTO shaft for one revolution of the rear wheel.

MF 3115-3120-3125-3140

540 rev/min - 8.23 revolutions of the PTO shaft for one revolution of the rear wheel.

1000 rev/min - 15.08 revolutions of the PTO shaft for one revolution of the rear wheel.

#### Front power take off (optional extra)

Control

Hydraulic clutch mechanism controlled by a button in the cab.

Ratio

1000 rev/min at 2040 engine rev/min. - 2.04. : 1

#### Four wheel drive front axle

Clutch mechanism

Hydraulic, electrically actuated by push button in the cab

Differential Lock

Front and rear differential lock-hydraulic with electrical control.

#### Hydraulics

Two stage gear pump, driven directly by the engine, supplies :

1 st Stage

This circuit supplies 29 l/min (6.4 Imp. gal/min) (7.6 US gal/min) at maximum engine speed.

Maximum pressure : 17 bar

1. Hydrostatic steering

A/B range gear

Hare/Tortoise range gear

Differential lock

IPTO clutch

PTO brake

Front PTO (if fitted)

Four-wheel drive (if fitted)

Hydraulic brakes

Clutch

Lubrication of gearbox, PTO and Rear Axle



## Introduction

### 2nd Stage

This circuit supplies 50 l/min (11 imp. gal/min)  
(13.2 US gal/min)

Maximum pressure : 185 bar

Filtration (2 filters)

### 2. Trailer brake supply

Auxiliary hydraulic system  
Hydraulic lift.

-One external 150 micron throwaway, canister type filter on the suction circuit.

-One external 15 micron high pressure filter on the low flow circuit.

## Brakes

### Main brake

Type

Oil-immersed single disc per wheel, 355 mm (13.9 in) outside diameter.

Inside diameter of lining :

3050-3060-3065 : 310 mm (12.20 in)

3070-3080-3095-3115/20-3125/40 : 290 mm (11.41 in)

Operation

Hydraulic, from two master cylinders, automatic adjustment.

### Handbrake

Operates on the rear axle bevel drive pinion.

### Trailer brake

According to model by hydraulic valve.

## Differential lock - Rear axle

Type

Positive clutch

Control

Hydraulic, with electrical control.



1A01.10

## Introduction

### Hydraulic lift

Type : 3-point, Category 2, with fixed, telescopic or quick attach hook ball ends (according to model).

Rams : Twin externally mounted

Lifting force (see charts)

#### MF 3050 - 60 - 65 - Ram diameter 50 mm (1.96 in) or 57 mm (2.24 in)

Position of lift rod on lower links mm	Length of lift rods mm	Ram diameter 50 mm				Ram diameter 57 mm			
		Lower links horizontal		Lower links full raised		Lower links horizontal		Lower links full raised	
		Kg	Lb	Kg	Lb	Kg	Lb	Kg	Lb
508	565	2207	4870	2926	6457	2885	6367	3825	8441
	765	2302	5080	2421	5343	3010	6643	3165	6985
608	565	-	-	3205	7073	-	-	4190	9247
	765	2623	5788	2666	5883	3430	7570	3485	7694

#### MF 3070 - 80 - Ram diameter 57 mm (2.24 in)

Position of lift rod on lower links mm	Length of lift rods mm	Lower links horizontal		Lower links full raised	
		Kg	Lb	Kg	Lb
550	595	3192	7044	3812	8413
	827	3138	6925	3162	6978
650	595	-	-	4175	9214
	827	3514	7755	3452	7618

#### MF 3070 - 80 - 95 - Ram diameter 66 mm (2.60 in)

Position of lift rod on lower links mm	Length of lift rods mm	Lower links horizontal		Lower links full raised	
		Kg	Lb	Kg	Lb
550	595	4350	9600	5194	11463
	827	4276	9437	4308	9507
650	595	5740	12668	5689	12555
	827	4788	10567	4703	10379

#### MF 3115/20 - 3125/40 - Ram diameter 73 mm (2.87 in)

Position of lift rod on lower links mm	Length of lift rods mm	Lower links horizontal		Lower links full raised	
		Kg	Lb	Kg	Lb
550	595	5425	11975	6510	14370
	827	5000	11037	5087	11230
650	595	8130	17950	7117	15710
	827	5727	12640	5595	12350





## Introduction

### Steering

Type

Hydrostatic

Fixed or tiltable telescopic steering column.

One double action central ram

### Front axle (2 WD)

TRACTOR MODEL	3050-3060-3065-3070		3070-3080-3095-3115/20-3125/40		
CHARACTERISTICS	NORMAL DUTY		HEAVY DUTY		
<b>Steering ram</b>					
- Ram diam. (mm)	57			68	
- Rod diam. (mm)	40			45	
- Total stroke (mm)	236			236	
- Volumetric displacement (cc)	306			482	
<b>Steering pressure (bar)</b>					
- at steering valve	160			166	
- at return port	16			16	
- effective	150			150	
<b>Steering valve</b>					
- Make	Danfoss			Danfoss	
- Volumetric displacement (cc)	80			125	
- Check/safety valve	with			with	
<b>Steering wheel</b>					
- Diameter (mm)	400			400	
- Nb of turn (lock to lock)	3.80			3.86	
<b>Steering angle</b>					
- Inner wheel	56°			56°	
- Outer wheel	43°			43°	
<b>Turning circle</b>	3050/60/65	3070	3070	3080/95/3115/20	3125/40
- Without braking (mm)	3700	3750	3850	4320	4320
- With braking (mm)	3250	3300	3400	3750	4000
<b>Angle</b>					
- Axle swinging (max)	11°			11°	
- Wheel castor	0			0	
- Wheel camber	3°30			5°10	
<b>Maximum permissible load capacity (Kg) at track setting</b>	3900 1383 mm			7900 1484 mm	



1A01.12

## 3000 / 3100 SERIES TRACTORS

**Introduction****Front axle (4WD)**

TRACTOR MODEL	3050	3060-3065	3080-3070 3095-3115/20		3125 3140
<b>4 WD axle</b>	1	2	2.5		3
<b>Steering ram</b> - Ram diam. (mm) - Rod diam.-(mm) - Ram stroke (mm) - Volumetric displacement (cc)	57 32 2 x 117 408	57 32 2 x 117 408	63 32 2 x 119 550		68 45 2 x 139 567
<b>Steering pressure (bar)</b> - At steering valve - At return port - effective	166 16 150	166 16 150	166 16 150		166 16 150
<b>Steering valve</b> - Make - Volumetric displacement (cc) - Check valve	Danfoss 100 with	Danfoss 100 with	Danfoss 125 with		Danfoss 125 with
<b>Steering wheel</b> - Diameter (mm) - Nb of turn (lock to lock)	400 4.08	400 4.08	400 4.4		400 4.5
<b>Steering angle</b> - Inner wheel - Outer wheel	50° 38.5°	50° 38.5°	50° 38.5°		50° 38.5°
<b>Turning circle</b> - Without braking (mm) - With braking (mm)	4200 3800	4200 3800	3070 4300 3900	3080/95 4700 4300	4800 4400
<b>Angle</b> - Axle swinging (max) - Wheel castor - Wheel camber	11° 2°30 1	11° 2°30 1	11° 2°30 1		11° 2°30 1
<b>Maximum permissible load capacity (Kg) at track setting</b>	4500 1416 mm	4500 1416 mm	5570 1566 mm		6640 1686 mm



# Introduction

## Wheels

FRONT

2-wheel drive

pressed steel

4-wheel drive

pressed steel or

cast with power adjust

variable track (PAVT) or

fixed cast type

REAR

pressed steel with manual adjustment or

cast with power adjust variable track (PAVT), or

manual adjustment.

## Tyres

Compatibility of front/rear tyres of 4-wheel drive tractors.

MF 3050 up to 3095			
Front	Rear	Front	Rear
11.2 - 24	16.9 - 30	11.2 - 28	13.6 - 38
12.4 - 24	16.9 - 30		16.9 - 34
	18.4 - 30		15.5 - 38
13.6 - 24	18.4 - 34	12.4 - 28	15.5 - 38
	13.6 - 38	13.6 - 28	16.9 - 38
	16.9 - 34	14.9 - 28	18.4 - 38
14.9 - 24	18.4 - 34		
	15.5 - 38		
	16.9 - 34		

MF 3115 - 3120 - 3125 - 3140			
Front	Rear	Front	Rear
11.2 - 28	13.6 - 38	13.6 - 28	16.9 - 38
	16.9 - 38		18.4 - 34
	18.4 - 34		18.4 - 38
12.4 - 28	16.9 - 38	14.9 - 24	16.9 - 38
	18.4 - 34		18.4 - 34
	18.4 - 38		18.4 - 38
	13.6 - 38	14.9 - 28	16.9 - 38
13.6 - 24	13.6 - 38		18.4 - 38
	16.9 - 34		20.8 - 38
	16.9 - 38		18.4 - 34
	18.4 - 34	16.9 - 22	20.8 - 38

## Water Ballasting (75% fill)

	Tyre Size	litre	imp. gal	US gal	kg	lb
Front Tyres	11.2-24	82.5	18.2	21.8	82.5	182
	12.4-24	109	23.9	28.8	109	239
	13.6-24	150	33.0	39.6	150	330
	14.9-24	180	39.6	47.6	180	396
	11.2-28	97.5	21.5	25.8	97.5	215
	12.4-28	124	27.2	32.8	124	272
	13.6-28	157.5	34.6	41.6	157.5	346
	14.9-28	191.3	42.1	50.5	193.3	421
	16.9-28	250	55.0	66.0	250.0	552
Rear Tyres	14.9-38	235	51.7	62.0	235.0	519
	16.9-30	277.5	61	73.2	277.5	610
	18.4-30	322.5	71	85.2	322.5	710
	16.9-34	307.5	67.7	81.2	307.5	676.5
	18.4-34	337.5	74.25	89.2	337.5	742.5
	13.6-36	195	42.9	51.5	195	429
	13.6-38	202.5	44.6	53.5	202.5	445.5
	15.5-38	232.5	51.1	61.4	232.5	511
	16.9-38	315	69.3	83.2	315	693
	18.4-38	367.5	80.9	97.1	367.5	809
	20.8-38	525	115.5	138.5	525	1159



1A01.14

# 3000 / 3100 SERIES TRACTORS




## Introduction


### Dimensions and weights

	MF 3050		MF 3060 MF 3065		MF 3070		MF 3080		MF 3095	
	2WD	4WD	2WD	4WD	2WD	4WD	2WD	4WD	2WD	4WD
<b>A</b> Wheelbase-mm(in)	2371 (93.34)	2375 (93.5)	2371 (93.34)	2375 (93.35)	2460 (96.85)	2464 (97.0)	2696 (106.1)	2699 (106.25)	2696 (106.1)	2699 (106.25)
<b>B</b> Overall length with drawbar mm (in)	3995 (117.9)	4069 (160.2)	3995 (117.9)	4069 (160.2)	4084 (160.8)	4208 (165.7)	4320 (170)	4472 (176)	4320 (170)	4472 (176)
<b>C</b> Height to roof - mm (in) (cab tractor)	2627 (103.4)	2627 (103.4)	2627 (103.4)	2627 (103.4)	2724 (107.2)	2724 (107.2)	2724 (107.2)	2724 (107.2)	2755 (108.5)	2755 (108.5)
<b>D</b> Overall width	2570 (101.2)	2570 (101.2)	2570 (101.2)	2570 (101.2)	2570 (101.2)	2570 (101.2)	2570 (101.2)	2570 (101.2)	2570 (101.2)	2570 (101.2)
<b>E</b> Ground clearance (under drawbar Frame)	1971 (77.6)	1971 (77.6)	1971 (77.6)	1971 (77.6)	2023 (79.6)	2023 (79.6)	2068 (81.4)	2068 (81.4)	2068 (81.4)	2068 (81.4)
<b>F</b> Height to steering wheel - mm (in) (platform models)	385 (15.2)	385 (15.2)	385 (15.2)	385 (15.2)	385 (15.2)	385 (15.2)	385 (15.2)	385 (15.2)	445 (17.5)	445 (17.5)
Total weight (with full tank, without extra weight steel wheels) - kg (lb)	3565 (7859)	3840 (8465)	3565 (7859)	3840 (8465)	3855 (8499)	4100 (9039)	4185 (9226)	4420 (9744)	4440 (9800)	4675 (10320)
Rear tyre dimensions	16.9-34		16.9-34		16.9-34		16.9-34		18.4-38	

	MF 3115/3120		MF 3125/3140	
	2WD	4WD	2WD	4WD
<b>A</b> Wheelbase-mm(in)	2696 (106.1)	2699 (106.2)	2696 (106.1)	2699 (106.2)
<b>B</b> Overall length with drawbar mm (in)	4402 (173.3)	4402 (173.3)	4527 (178.2)	4527 (178.2)
<b>C</b> Height to roof - mm (in) (cab tractor)	2768 (109)	2768 (109)	2908 (114.5)	2908 (114.5)
<b>D</b> Overall width (")	2733 (107.6)	2733 (107.6)	2832 (111.5)	2832 (111.5)
<b>E</b> Ground clearance (under drawbar Frame)	442 (17.4)	442 (17.4)	502 (19.8)	502 (19.8)
<b>F</b> Height to steering wheel - mm (in) (platform models)	2110 (83)	2110 (83)	2250 (88.6)	2250 (88.6)
Total weight (with full tank, without extra weight steel wheels) - kg (lb)	4190 (9249)	4590 (10132)	4805 (10607)	5040 (11126)
Rear tyre dimensions	16.9-38		20.8-38	

These dimensions are for a tractor set at maximum track.





# Introduction

1A01.15

## Capacities

Description	Litre	Imp. Gal	US Gal
Fuel tank MF 3050/3060/3065	148	32.56	39.10
MF 3070/3080/3095/3115/3120	173	38.10	45.60
MF 3125/3140	220	48.5	58
Cooling system MF 3050/3060/3065	16	3.5	4.2
MF 3070	20	4.4	5.3
MF 3080/3095/3115/3120/3125/3140	25	5.5	6.6
Engine sump MF 3050/3060/3065/3070	7.5	1.65	2
MF 3080/3090/3115/3120/3125/3140	16.5	3.6	4.3
Transmission / MF 3050 to 3095	60	13.2	15.9
Rear axle * MF 3115/3120/3125/3140	64	14.1	16.9
Front axle assembly MF 3050/3060/3065	5.8	1.3	1.5
MF 3070/3080/3095/3115/3120	6.5	1.4	1.7
MF 3125/3140	11	2.4	2.9
Front final reduction MF 3050/3060/3065	1.4	0.3	0.4
units (each) MF 3070/3080/3095/3115/20/25/40	1.8	0.4	0.5

\* When working on steep slopes 10 l (2.2 Imp Gal) (2.7 Us Gal) of oil must be added.



1A01.16

## 3000 / 3100 SERIES TRACTORS



## Introduction

## C . Chassis dimensions and mounting points

	3050/3060 3065	3070	3080/3095 3120	3115 3125/40		3050/3060 3065	3070	3080/3095 3120	3115 3125/40
1	301.50	301.50	301.50	301.50	37	155	155	155	155
2	20.00	20.00	20.00	20.00	38	125	125	125	125
3	101.60	101.60	61.60	61.60	39	125	125	125	125
4	44.45	44.45	-	-	40	52	52	52	52
5	60.30	60.30	-	-					
6	101.60	101.60	-	-	41	52	52	52	52
7	481.00	570.00	621.40	621.40	42	79.5±2	79.5±2	79.5±2	96.5±2
8	112.40	201.40	49.60	49.60	43	46	46	46	46
9	25.25	25.25	6.30	6.30	44	190	190	190	190
10	70.00	70.00	101.60	101.60	45	100	100	100	100
					46	226	226	226	226
11	-	-	44.45	44.45	47	92	92	92	123
12	-	-	60.30	60.30	48	Ø149.35	Ø149.35	Ø149.35	Ø149.35
13	-	-	101.60	101.60	49	371	371	371	371
14	698.00	787.00	736.80	736.80					
15	340.00	429.05	370.60	370.60	50	320	320	320	320
16	571.75	571.75	771.50	771.50	51	110	110	110	110
17	896	896	896	896	52	130	130	130	130
18	890	890	890	890	53	65	65	65	65
19	567	567	567	567	54	142.75	142.75	142.75	142.75
20	-	-	94	94	55	20	20	20	20
					56	817	817	817	817
21	267	267	267	267	57	310	310	310	310
22	127	127	127	127	58	142.75	142.75	142.75	142.75
23	53	53	53	53	59	223	223	223	223
24	101.60	101.60	101.60	101.60	60	315	315	315	324
25	31.40	31.40	31.40	31.40					
26	101.60	101.60	101.60	101.60	61	100	100	100	
27	100	100	100	161	62	65	65	65	
28	260	260	260	280	63	65	65	65	
29	43	43	43	43	64	40 or 66	40 or 66	40 or 66	40 or 66
30	106	106	106	106	65	-	-	-	323.90
					66	-	-	-	76.20
31	224	224	224	224	67	-	-	-	120.60
32	128	128	128	128	68	-	-	-	241.30
33	1774	1774	1774	1835	69	3056	3142	3388	3388
34	-	-	-	2228					
35	-	-	-	2870	70	Ø203.2±0.3	Ø203.2±0.3	Ø203.2±0.3	Ø203.2±0.3
36	155	155	155	155					

A : 6 holes M20 through  
 B : 8 holes M20 x 38 deep  
 C : 12 holes M20 x 38 deep  
 D : 2 holes M20 through  
 E : 8 holes M16 x 25 deep  
 F : 2 holes diam. 37 - 37.16  
 G : 8 holes M18 x 31 deep

H : 8 studs M18 - 1.5  
 I : 4 holes M16 x 25 deep  
 J : 5 holes M20 x 35 deep  
 K : 4 holes M16 x 30 deep  
 L : 4 holes diam. 20.70 ± 0.12  
 through



v : 4 WD centerline  
 w : Crankshaft centerline  
 x : Differential centerline  
 y : Trumpet centerline  
 z : PTO centerline



3000 / 3100 SERIES TRACTORS








Introduction 6 CYL.

1A01.17



4 CYL.

AA






Center drive axles new generation

TECHNICAL DATA

Prepared by: P  
 Date: 9 dec 87

PAGE  
 EMISSION



PINCEMENT :  $X2 - X1 = 0 \pm 3 \text{ mm}$

Rep	Col. 1	Col. 2	Col. 2.5	Col. 3
A	1330	1330	1450	1570
B	1609	1609	1800	1920
C	1792	1810	1971	2111
D	180	180	180	205
E	135	135	135	155
F	328	328	328	365
G	255	255	255	287
H	180	180	180	185
J	125	125	125	125
K	125	125	125	145
L	95 f8	95 f8	95 f8	110 f7
M	70 f7	70 f7	70 f7	80 f7
P	1-1/8"	1-1/8"	1-3/8"	1-3/8"






# Introduction

## D . Safety precautions

Do not remove or obscure Caution, Warning or Instruction Decals (Yellow). Replace any Caution, Warning or

Instruction Decals that are not readable or are missing. See here under the actual location of these decals.

**G.B. CAUTION**



Before operating, read operator's instruction book thoroughly.  
Do not start engine until everyone is a safe distance from tractor and equipment.  
Keep all shields, covers and guards in place while engine is running.  
Keep hands, feet and clothing away from power driven or moving parts.

Always drive with due care and attention.  
If differential lock does not disengage automatically, depress clutch pedal.  
Brake pedals must always be coupled together when independent brakes are not being used.  
Before leaving tractor, apply parking brake, lower equipment, stop engine and remove key from starter switch.

When attaching equipment check operator's instruction book for front and rear axle load limits.  
Put the range lever in the neutral position in order to use the external lift controls.  
Ensure that all wheel and rim nuts are tightened as specified in operator's instruction book.  
On public roads, use SMV emblem and flashing warning lights where required by law.  
DO NOT REMOVE OR OBSCURE DECAL 3580321M02A

**WARNING**



Range lever must be in neutral position:  
-In order to use the external lift controls  
-When the driver is not in his seat

DO NOT REMOVE OR OBSCURE DECAL 3583300M1


**G.B. WARNING**



High pressure steam and hot water. Remove filler cap with extreme care


DO NOT REMOVE OR OBSCURE DECAL 3595 685 M1

**G.B. WARNING**



Before working on the tractor, disconnect negative leads to all batteries.


**WARNING**



Before removing any battery, disconnect all negative leads before positive leads.

DO NOT REMOVE OR OBSCURE DECAL 3595 679 M1

**G.B.**

DO NOT REMOVE OR OBSCURE DECAL

**G.B. CAUTION**



Keep all shields, covers and guards fastened in place while engine is running.


**WARNING**



Beware hot parts.


DO NOT REMOVE OR OBSCURE DECAL 3595 678 M1

**G.B. WARNING**



Always disengage PTO and stop engine before attaching or detaching PTO shafts or working on PTO driven equipment.  
Always fit PTO cover when PTO is not in use.


**CAUTION**



Do not stand between tractor and equipment when operating controls.  
Tow only with MF approved tractor drawbar or hitch.

DO NOT REMOVE OR OBSCURE DECAL 3581 563 M1


**CAUTION**



Belt for use only on tractors with safety structures

DO NOT REMOVE OR OBSCURE DECAL 323 784 M1

**G.B. WARNING**



Before working on the tractor or removing this cover, disconnect negative leads to all batteries


**CAUTION**



Use seat belt at all times  
Keep belt adjusted snugly

DO NOT REMOVE OR OBSCURE DECAL 3680 316 M1


**WARNING**



YOUR RANGE OF UTILISATION SEE OPERATOR INSTRUCTION BOOK  
RECEIVE L'EMETTEUR DE LIQUIDE HYDRAULIQUE EN TIRANT LE MANIVEL. CIL. OPE BACK

# 361757M1


**CAUTION**



Do not short across starter terminals to start engine.  
Never start engine while standing on the ground.  
Start engine only with start key from operator's seat, ensuring that gearbox and PTO are in neutral, with parking brake applied.

DO NOT REMOVE OR OBSCURE DECAL 3596 432 M1

**G.B. WARNING**




If tractor is overturning  
Hold onto steering wheel  
Do not leave seat



DO NOT REMOVE OR OBSCURE DECAL 3680 317 M1

**G.B. CAUTION**



TO AVOID POSSIBLE TRACTOR OVERTURN, PULL ONLY FROM DRAWBAR OR LOWER LINKS OF THREE POINT HITCH.

2752 579 M1




1A01.20

3000 / 3100 SERIES TRACTORS



# Introduction





## Introduction

### E . Practical advice

#### Safety

Your safety and that of others must always be the first consideration when working around machines of any type.

Safety is a matter of thoroughly understanding the job to be done, the correct use of tools and equipment, and the application of good common sense.

#### Trouble-shooting

The following procedure, combined with the information contained in the workshop manual will be helpful in tracing faults accurately.



It consists of following a number of logical steps to locate and correct the problem.

1. Determine the problem.
2. List possible causes.
3. Differentiate the causes.
4. Conduct checks in logical order to determine the exact cause.
5. Consider approximate remaining service life against cost of parts and labour.
6. Make any necessary repair.
7. Recheck the parts and functions for correct operation.

#### Handling of heavy components

Unless otherwise specified, all removals should be accomplished using adjustable lifting equipment. All supporting slings must be parallel to each other and as near vertical as possible in relation to the object being lifted. However, where slings are of a far greater capacity than the weight of the load to be lifted, a triangular lifting arrangement may be used (2, 3 or 4 strands from a single ring beneath the hoist hook). When removing a component at an angle, remember that the capacity of an eyebolt is reduced when the angle between the supporting members and the object becomes less than 90° (correct and incorrect method of lifting).

Eyebolts and brackets must never be bent and must only work under tension. A length of pipe and a washer may be used to reduce tension on eyebolts.



#### Forged eyebolt support

A Load - B Lifting shackle - C Shackle retaining plate (3 mm thick) - D Sleeve (may or may not be welded to plate)

In some cases, special lifting fixtures are available to obtain correct balance and provide for safe handling. Consult the relevant section of the Workshop Manual.

#### Warning

If a part resists removal, check that all nuts and bolts have been removed and that there is no interference from adjacent parts.



1A01.22



# Introduction

## Cleanliness

To ensure long life of a machine, it is important to keep dirt and foreign material out of its vital working components. Precautions must be taken to safeguard against this. Enclosed compartments, seals and filters have been provided to keep the supply of air, fuel and lubricant clean. These protective devices must not be removed.

Whenever hydraulic fluid, fuel, lubricating oil or air lines are disconnected, clean the point of disconnection and the surrounding area. As soon as a line has been disconnected, cap, plug or tape the line or opening to prevent the ingress of foreign material.

The same cleaning and covering precautions should be taken when access covers or inspection plates are removed.

Clean and inspect all parts. Make sure that all passages and holes are clear. Cover all parts to keep them clean. Make sure parts are clean when they are reassembled. Leave new parts in their wrapping until they are actually needed for reassembly.

## Assembly

When reassembling a machine, complete each step in sequence. Never partially assemble one part then start to assemble another. Make all recommended adjustments. Always check the job on completion to ensure that nothing has been overlooked.

Recheck the various adjustments before putting the machine back into service.


**Note : Before fitting new parts, remove rust preventative compound from all machined surfaces (usually «peel-off» substances).**

## Lubrication

Where applicable, fill the compartments of repaired or renewed components with the quantity, type and grade of clean lubricant recommended in the routine maintenance section of the Operation Instruction Book.

## Shims

When shims are removed, tie them together and identify their location. Keep shims clean and take care not to bend them before refitting them.



## Gaskets

Make sure that the holes in gaskets line up with lubricating oil passages in the mating parts. If gaskets have to be made, use material of the correct type and thickness. Make sure that holes are punched in the right places.

Incorrectly punched gaskets can cause serious damage.

## Lip type rubber seals.

Lubricate the lips of lip-type seals with oil before fitment. Do not use grease on seals, except for grease seals. The main parts of a lip-type seal are the case (1), the sealing element (2) and the ring spring (3). The figure shows the construction of a simple lip-type seal. The cross section shows the «heel» (4) and the «toe» (5), used to identify the sides of a single element seal. With a few exceptions, the toe of a single-lip seal is located on the lubricant side. Some seals have a second auxiliary lip which has no spring.



## Introduction

### Cables and wires

When removing or disconnecting a group of cables or wires, label each one to ensure correct refitment.

### Locking devices

Slackening of nuts and bolts is prevented by mechanical means such as lockwashers, tab washers and cotter pins, or by Loctite-type locking agents.

Flat retainers must be installed properly to be effective. Bend one end of the retainer against the edge of the part.

Bend the other end against one of the flats on the nut or bolt head.

Always fit new retainers in compartments which house moving parts.

When fitting lockwashers on aluminium housings, place a flat washer between the lockwasher and the housing.

#### Note:

1) **Never fit a lockwasher (Grower, fan, spring, etc..) under a nut or bolt to which a specified torque has to be applied (however, see Recommended Standard Torque charts).**

2) **Always thoroughly degrease components before applying Loctite type locking agents.**

### Bushes and press fits

Do not fit bushes with a hammer alone. Use a suitable fitting tool and a hammer or, better still, a press if possible.


When using a press, ensure that pressure is applied directly in line with the bore. If the ring has an oil hole, take care to align it with the oil hole in the mating part.

When press fitting a part into another part, lubricate the mating surfaces. Tapered parts should be assembled dry.


Before assembly, check that the tapers are dry and free from burrs.

### Fitting bolts in blind holes

Use bolts of the correct length. A bolt which is too long may «bottom» before the head comes into contact with the part it is to hold; this will cause damage to the threads. If a bolt is too short, there may not be enough threads engaged to hold the part securely.



Correct and incorrect use of retainers



Correct and incorrect method of fitting and bending locking tabs.



1A01.24

## 3000 / 3100 SERIES TRACTORS



# Introduction

## F . Installation instructions

### Pre-delivery checks

The following items must be checked by the Distributor before delivery to a Dealer and by the Dealer before delivery to an Owner or Operator.

#### 1 . General Installation

- . Clean the battery top and smear the terminals with petroleum jelly.
- . Charge the batteries if necessary.
- . Check all electrical connections, cable and ducting clips and light fittings.
- . Check and top up the engine and transmission housing oil levels.
- . Lubricate all grease points.
- . Check and adjust belt tensions as necessary (alternator, fan, auxiliary pump and air-conditioning compressor).
- . Except when it contains antifreeze, flush the cooling system and refill with soft water.
- . If the clutch pedal has been held down to prevent the disc sticking, remove the keeper.
- . Check that the fuel tank contains a sufficient amount of fuel of the correct type.
- . Remove air from the fuel system and tighten all fuel pipe connections.
- . Check that the engine air filter hoses are secure.
- . Check that engine control linkages are correctly adjusted and are operating freely.
- . Start the engine.
- . Check the instruments and warning lights for correct operation.
- . Check engine speed at the tachometer with both hand and foot throttles.
- . Attach a mounted implement and check the tractor hydraulics for correct operation.
- . Check and adjust tyre pressures (road or field work).
- . Check all nuts bolts, studs, pipe unions and clips for tightness.
- . Check all pipes and hoses for leaks.
- . Check and adjust headlamp alignment.
- . Road test the tractor, checking the brakes and all instruments and services for correct operation.

#### 2. Electronic systems

- . Check the electronic linkage for correct operation.
- . Carry out the quick check procedure in section 11B01.
- . Check all the Autotronic functions, using the test procedure in 12B01.
- . Check the on-board computer installation (Datatronic) using procedure 13A01.

#### 3. Tightening Torques

- . Check the torque of all chassis fixing nuts and bolt:
  - Front axle/Engine
  - Engine/Gearbox
  - Gearbox/Rear axle
  - Axle housings/Rear axle
- . Check the torque of all wheel and rim nuts and bolts.

### Instructions to the driver

Instructions must be given to the driver on the items listed below :

1. Safety precautions when starting the engine.
2. Location and significance of tractor and engine serial numbers.
3. Instruments and controls.
4. Running-in.
5. Starting and stopping the engine.
6. Selection of correct operating gear ratio and use of gearshift levers and reverse shuttle lever.
7. Danger of towing downhill without engine braking and correct use of gearbox.
8. Use and adjustment of brakes and brake pedal latch.
9. Use of clutch.
10. Use of hydraulic differential lock.
11. Use of hydraulically operated PTO - Clutch and brake.
12. Operation of hydraulic lift system.
13. Attaching and detaching towed implements.
14. Grease points.
15. Changing grades of oil.
16. Replacement of engine and transmission oil filter elements.
17. Operation of fuel system. Removal of air from the system. Air filter - clogging indicator.
18. Cooling system. Frost precautions. Tension of twin fan belts.
19. Maintenance of electrical equipment (batteries). Negative earth system.
20. Adjustment of front and rear track widths.
21. Tyre pressures.
22. Tightness of all nuts and bolts.
23. Fuel handling and storage.
24. Use of auxiliary hydraulic equipment.
25. Fill in tractor and engine serial number details in the Operator Instruction Book.
26. Read the Operator Instruction Book.



## Introduction

### G . Conversion table

#### Pressure units

1 PSI = 1 lbf/in<sup>2</sup> = 0,0689 bar

1 bar = 14,512 lbf/in<sup>2</sup> = 14,512 PSI

Bar	lbf / in <sup>2</sup>	Bar	lbf / in <sup>2</sup>	Bar	lbf / in <sup>2</sup>
0,5	7,256	9,5	137,9	35	508
1	14,51	10	145	40	588
1,5	21,77	11	159,6	45	653
2	29	12	174	50	726
2,5	36,28	13	189	60	871
3	43,54	14	203	70	1029
3,5	50,8	15	218	80	1161
4	58	16	232	90	1306
4,5	65,3	17	247	100	1451
5	72,6	18	261	200	2903
5,5	79,8	19	276	300	4354
6	87,1	20	290	400	5805
6,5	94,3	21	309	500	7257
7	101,6	22	319	600	8708
7,5	108,8	23	334	700	10160
8	116,1	24	348	800	11611
8,5	123,4	25	368	900	13235
9	130,6	30	435	1000	14514



1A01.26

# 3000 / 3100 SERIES TRACTORS



## Introduction


### Torque units

1 Nm = 0,7376 lbf/ft

1 lbf/ft = 1,3558 Nm

Nm		lbf/ft	Nm		lbf/ft	Nm		lbf/ft
1,3558	1	0,7376	46,0972	34	25,0784	90,8396	67	49,4912
2,7116	2	1,4752	47,4530	35	25,8160	92,1944	68	50,1568
4,0674	3	2,2128	48,8088	36	26,5536	93,5502	69	50,8944
5,4232	4	2,9504	50,1646	37	27,2912	94,9060	70	51,6320
6,7790	5	3,6880	51,5204	38	28,0288	96,2618	71	52,3696
8,1348	6	4,4256	52,8762	39	28,7664	97,6176	72	53,1072
9,4906	7	5,1632	54,2320	40	29,5040	98,9734	73	53,8448
10,8464	8	5,9008	55,5878	41	30,2416	100,329	74	54,5824
12,2022	9	6,6384	56,9436	42	30,9792	101,685	75	55,3200
13,5580	10	7,3760	58,2994	43	31,7168	103,041	76	56,0576
14,9138	11	8,1136	59,6552	44	32,4544	104,397	77	56,7952
16,2696	12	8,8512	61,0110	45	33,1920	105,752	78	57,5328
17,6254	13	9,5888	62,3668	46	33,9296	107,108	79	58,2704
18,9812	14	10,3264	63,7226	47	34,6672	108,464	80	59,0080
20,3370	15	11,0640	65,0784	48	35,4048	109,820	81	59,7456
21,6928	16	11,8016	66,4342	49	36,1424	111,176	82	60,4832
23,0486	17	12,5392	67,7900	50	36,8800	112,531	83	61,2208
24,4044	18	13,2768	69,1458	51	37,6176	113,887	84	61,9584
25,7602	19	14,0144	70,5016	52	38,3552	115,243	85	62,6960
27,1160	20	14,7520	71,8574	53	39,0928	116,600	86	63,4336
28,4718	21	15,4896	73,2132	54	39,8304	117,955	87	64,1712
29,8276	22	16,2272	74,5690	55	40,5680	119,310	88	64,9088
31,1834	23	16,9648	75,9248	56	41,3056	120,666	89	65,6464
32,5392	24	17,7024	77,2806	57	42,0432	122,022	90	66,3840
33,8950	25	18,4400	78,6364	58	42,7808	123,378	91	67,1216
35,2508	26	19,1776	79,9922	59	43,5184	124,734	92	67,8592
36,6066	27	19,9152	81,3480	60	44,2560	126,089	93	68,5968
37,9624	28	20,6528	82,7038	61	44,9936	127,445	94	69,3344
39,3182	29	21,3904	84,0596	62	45,7312	128,801	95	70,0720
40,6740	30	22,1280	85,4154	63	46,4688	130,157	96	70,8096
42,0298	31	22,8656	86,7712	64	47,2064	131,513	97	71,5472
43,3856	32	23,6032	88,1270	65	47,9440	132,868	98	72,2848
44,7414	33	24,3408	89,4828	66	48,6816	134,224	99	73,0224



**Introduction****Capacity units**

1 litre = 0,2199 gallon imp.

1 gallon imp. = 4,5459 litres

**Note :**

1 US gallon = 3.79 litres

Imp. gal.		Litres	Imp. gal.		Litres	Imp. gal.		Litres
0,2199	1	4,5459	7,4766	34	154,561	14,733	67	304,575
0,4398	2	9,0918	7,6965	35	159,107	14,9532	68	309,121
0,6597	3	13,6377	7,9164	36	163,652	15,1731	69	313,667
0,8796	4	18,1836	8,1363	37	168,198	15,3930	70	318,213
1,0995	5	22,7295	8,3562	38	172,744	15,6129	71	322,759
1,3194	6	27,2754	8,5761	39	177,290	15,8328	72	327,305
1,5393	7	31,8213	8,7960	40	181,836	16,0527	73	331,851
1,7592	8	36,3672	9,0159	41	186,382	16,2726	74	336,397
1,9791	9	40,9131	9,2358	42	190,929	16,4925	75	340,943
2,1990	10	45,4590	9,4557	43	195,474	16,7124	76	345,488
2,4189	11	50,0049	9,6756	44	200,019	16,9323	77	350,034
2,6388	12	54,5508	9,8955	45	204,566	17,1522	78	354,580
2,8587	13	59,0967	10,1154	46	209,111	17,3721	79	359,126
3,0786	14	63,6426	10,3353	47	213,657	17,5920	80	363,672
3,2985	15	68,1885	10,5552	48	218,203	17,8119	81	368,218
3,5184	16	72,7344	10,7751	49	222,749	18,0318	82	372,764
3,7383	17	77,2803	10,9950	50	227,295	18,2517	83	377,310
3,9582	18	81,8262	11,2149	51	231,841	18,4716	84	381,856
4,1781	19	86,3721	11,4348	52	236,387	18,6915	85	386,402
4,3980	20	90,9180	11,6547	53	240,933	18,9114	86	390,947
4,6179	21	95,4639	11,8746	54	245,479	19,1313	87	395,493
4,8378	22	100,009	12,0945	55	250,025	19,3512	88	400,039
5,0577	23	104,556	12,3144	56	254,570	19,5711	89	404,585
5,2776	24	109,102	12,5343	57	259,116	19,7910	90	409,131
5,4975	25	113,648	12,7542	58	263,662	20,0109	91	413,677
5,7174	26	118,193	12,9741	59	268,209	20,2308	92	418,223
5,9373	27	122,739	13,1940	60	272,754	20,4507	93	422,769
6,1572	28	127,285	13,4139	61	277,299	20,6706	94	427,315
6,3771	29	131,831	13,6338	62	281,846	20,8905	95	431,861
6,5970	30	136,377	13,8537	63	286,392	21,1104	96	436,406
6,8169	31	140,923	14,0736	64	290,938	21,3303	97	440,952
7,0368	32	145,469	14,2935	65	295,483	21,5502	98	445,498
7,2567	33	150,015	14,5134	66	300,029	21,7701	99	450,044



1A01.28

## 3000 / 3100 SERIES TRACTORS

**Introduction****Capacity units**

1 litre = 1,7599 pinte imp.

1 pinte imp. = 0,5682 litre

**Note :**

1 Litre = 2.113 US pints

Imp. pt.		Litres	Imp. pt.		Litres	Imp. pt.		Litres
1.7599	1	0,5682	59,8366	34	19,3188	117,913	67	38,0694
3.5198	2	1,1364	61,5965	35	19,8870	119,673	68	38,6376
5.2797	3	1,7046	63,3564	36	20,4552	121,433	69	39,2058
7.0396	4	2,2728	65,1163	37	21,0234	123,193	70	39,7740
8.7995	5	2,8400	66,8762	38	21,5916	124,953	71	40,3422
10.5594	6	3,4902	68,6361	39	22,1598	126,713	72	40,9104
12.3193	7	3,9774	70,3960	40	22,7280	128,473	73	41,4786
14.0792	8	4,5456	72,1559	41	23,2962	130,233	74	42,0468
15.8391	9	5,1138	73,9158	42	23,8644	131,993	75	42,6150
17.5990	10	5,6820	75,6757	43	24,4326	133,752	76	43,1832
19.3589	11	6,2502	77,4356	44	25,0008	135,512	77	43,7514
21.1188	12	6,8184	79,1955	45	25,5690	137,272	78	44,3196
22.8787	13	7,3866	80,9554	46	26,1372	139,032	79	44,8878
24.6386	14	7,9548	82,7153	47	26,7054	140,792	80	45,4560
26.3985	15	8,5230	84,4752	48	27,2736	142,552	81	46,0242
28.1854	16	9,0912	86,2351	49	27,8418	144,312	82	46,5924
29.9183	17	9,6594	87,9950	50	28,4100	146,072	83	47,1606
31.6782	18	10,2276	89,7549	51	28,9782	147,832	84	47,7288
33.4381	19	10,7958	91,5148	52	29,5464	149,592	85	48,2970
35.1980	20	11,3640	93,2747	53	30,1146	151,351	86	48,8652
36.9579	21	11,9322	95,0346	54	30,6828	153,111	87	49,4334
38.7178	22	12,5004	96,7945	55	31,2510	154,871	88	50,0016
40.4770	23	13,0686	98,5544	56	31,8192	156,631	89	50,5698
42.2376	24	13,6368	100,314	57	32,3874	158,391	90	51,1380
43.9975	25	14,2050	102,074	58	32,9556	160,151	91	51,7062
45.7574	26	14,7732	103,834	59	33,5238	161,912	92	52,2744
57.5173	27	15,3414	105,594	60	34,0920	163,671	93	52,8426
49.2772	28	15,9096	107,354	61	34,6602	165,431	94	53,4108
51.0371	29	16,4778	109,114	62	35,2284	167,191	95	53,9790
52.7970	30	17,0460	110,874	63	35,7966	168,950	96	54,5472
54.5569	31	17,6142	112,634	64	36,3648	170,710	97	55,1154
56.3168	32	18,1824	114,394	65	36,9330	172,470	98	55,6836
58.0767	33	18,7506	116,153	66	37,5012	174,230	99	56,2518

**Introduction****Length units**

1m = 3,2808 ft

1 ft = 0,3048 m

m		ft	m		ft	m		ft
0,3048	1	3,2808	10,3632	34	111,549	20,4216	67	219,816
0,6096	2	6,5617	10,6680	35	114,829	20,7264	68	223,097
0,9144	3	9,8425	10,9728	36	118,110	21,0312	69	226,378
1,2192	4	13,1234	11,2776	37	121,391	21,3360	70	229,659
1,5240	5	16,4042	11,5824	38	124,672	21,6408	71	232,940
1,8288	6	19,6850	11,8872	39	127,953	21,9456	72	236,220
2,1336	7	22,9659	12,1920	40	131,234	22,2504	73	239,501
2,4384	8	26,2467	12,4968	41	134,514	22,5552	74	242,782
2,7432	9	29,5276	12,8016	42	137,795	22,8600	75	246,063
3,0480	10	32,8084	13,1064	43	141,076	23,1648	76	249,344
3,3528	11	36,0892	13,4112	44	144,357	23,4696	77	252,625
3,6576	12	39,3701	13,7160	45	147,638	23,7744	78	255,906
3,9624	13	42,6509	14,0208	46	150,919	24,0792	79	259,186
4,2672	14	45,9318	14,3256	47	154,199	24,3840	80	262,467
4,5720	15	49,2126	14,6304	48	157,480	24,6888	81	265,748
4,8768	16	52,4934	14,9352	49	160,761	24,9936	82	269,029
5,1816	17	55,7743	15,2400	50	164,042	25,2984	83	272,310
5,4864	18	59,0551	15,5448	51	167,323	25,6032	84	275,591
5,7912	19	62,3360	15,8496	52	170,604	25,9080	85	278,871
6,0960	20	65,6168	16,1544	53	173,885	26,2128	86	282,152
6,4008	21	68,8976	16,4592	54	177,165	26,5176	87	285,433
6,7056	22	72,1785	16,7640	55	180,446	26,8224	88	288,714
7,0104	23	75,4593	17,0688	56	183,727	27,1272	89	291,995
7,3152	24	78,7402	17,3736	57	187,008	27,4320	90	295,276
7,6200	25	82,0210	17,6784	58	190,289	27,7368	91	298,556
7,9248	26	85,3018	17,9832	59	193,570	28,0416	92	301,837
8,2296	27	88,5827	18,2880	60	196,850	28,3464	93	305,118
8,5344	28	91,8635	18,5928	61	200,131	28,6512	94	308,399
8,8392	29	95,1444	18,8976	61	203,412	28,9560	95	311,680
9,1440	30	98,4252	19,2024	63	206,693	29,2608	96	314,961
9,4488	31	101,7060	19,5072	64	209,974	29,5656	97	318,241
9,7536	32	104,9870	19,8120	65	213,255	29,8704	98	321,522
10,0584	33	108,2680	20,1168	66	216,535	30,1752	99	324,803



1A01.30

# 3000 / 3100 SERIES TRACTORS



## Introduction

### Weight units

1kg = 2.2046 lb

1 lb = 0.4536 kg

kg		lb	kg		lb	kg		lb
0.4536	1	2,2046	15,4224	34	74,9564	30,3912	67	147,708
0.9072	2	4,4092	15,8760	35	77,1610	30,8448	68	149,913
1.3608	3	6,6138	16,3296	36	79,3656	31,2984	69	152,117
1.8144	4	8,8184	16,7832	37	81,5702	31,7520	70	154,322
2.2680	5	11,0230	17,2368	38	83,7748	32,2056	71	156,527
2.7216	6	13,2276	17,6904	39	85,9794	32,6592	72	158,731
3.1752	7	15,4322	18,1440	40	88,1840	33,1128	73	160,936
3.6288	8	17,6368	18,5976	41	90,3886	33,5664	74	163,140
4.0824	9	19,8414	19,0512	42	92,5932	34,0200	75	165,345
4.5360	10	22,0460	19,5048	43	94,7978	34,4736	76	167,549
4.9896	11	24,2506	19,9584	44	97,0024	34,9272	77	169,754
5.4432	12	26,4552	20,4120	45	99,207	35,3808	78	171,958
5.8968	13	28,6598	20,8656	46	101,412	35,8344	79	174,163
6.3504	14	30,8644	21,3192	47	103,616	36,2880	80	176,368
6.8040	15	33,0690	21,7728	48	105,821	36,7416	81	178,573
7.2576	16	35,2736	22,2264	49	108,025	37,1952	82	180,777
7.7112	17	37,4782	22,6800	50	110,230	37,6488	83	182,982
8.1648	18	39,6828	23,1336	51	112,435	38,1024	84	185,186
8.6184	19	41,8874	23,5872	52	114,639	38,5560	85	187,391
9.0720	20	44,0920	24,0408	53	116,844	39,0096	86	189,596
9.5256	21	46,2966	24,4944	54	119,048	39,4632	87	191,800
9.9792	22	48,5012	24,9489	55	121,253	39,9168	88	194,005
10.4328	23	50,7058	25,4016	56	123,458	40,3704	89	196,209
10.8864	24	52,9104	25,8552	57	125,662	40,8240	90	198,414
11.3400	25	55,1150	26,3088	58	127,867	41,2776	91	200,619
11.7936	26	57,3196	26,7624	59	130,071	41,7312	92	202,823
12.2472	27	59,5242	27,2160	60	132,276	42,1848	93	205,028
12.7008	28	61,7288	27,6696	61	134,481	42,6384	94	207,232
13.1544	29	63,9334	28,1232	62	136,685	43,0920	95	209,437
13.6080	30	66,1380	28,5768	63	138,889	43,5456	96	211,642
14.0616	31	68,3426	29,0304	64	141,094	43,9992	97	213,846
14.5152	32	70,5472	29,4840	65	143,299	44,4528	98	216,051
16.9688	33	72,7518	29,9376	66	145,504	44,9064	99	218,255

**Introduction**

Inches	LENGTH 1 inch = 25,4 mm						TEMPERATURE			
	Decimals	mm	Inches to mm		mm to inches		Fahrenheit to Celsius			
			Inches	mm	mm	Inches	° F	° C	° C	° F
1/64	.015625	0,3969					- 20	- 28,9	- 30	- 22
1/32	.031250	0,7937					- 15	- 26,1	- 28	- 18,4
3/64	.0468750	1,1906					- 10	- 23,3	- 26	- 14,8
1/16	.062500	1,5875	0,0001	0,00254	0,004	0,00015	- 5	- 20,6	- 24	- 11,2
5/64	.078125	1,9844	.0002	.00508	0,005	.00019	0	- 17,8	- 22	- 7,6
3/32	.093750	2,3812	.0003	.00762	0,006	.00023	1	- 17,2	- 20	- 4
7/64	.109375	2,7781	.0004	.01016	0,007	.00027	2	- 16,7	- 18	- 0,4
1/8	.125000	3,1750	.0005	.01270	0,008	.00031	3	- 16,1	- 16	3,2
9/64	.140625	3,5719	.0006	.01524	0,009	.00035	4	- 15,6	- 14	6,8
5/32	.156250	3,9687	.0007	.01778	0,01	.00039	5	- 15,0	- 12	10,4
11/64	.171875	4,3656	.0008	.02032	0,02	.00079	10	- 12,2	- 10	14
3/16	.187500	4,7625	.0009	.02286	0,03	.00118	15	- 9,4	- 8	17,6
13/64	.203125	5,1594	.001	.0254	0,04	.00157	20	- 6,7	- 6	21,2
7/32	.218750	5,5562	.002	.0508	0,05	.00197	25	- 3,9	- 4	24,8
15/64	.234375	5,9531	.003	.0762	0,06	.00236	30	- 1,1	- 2	28,4
1/4	.250000	6,3500	.004	.1016	0,07	.00276	35	1,7	0	32
17/64	.265625	6,7469	.005	.1270	0,08	.00315	40	4,4	2	35,6
9/32	.281250	7,1437	.006	.1524	0,09	.00354	45	7,2	4	39,2
19/64	.296875	7,5406	.007	.1778	0,10	.00394	50	10,0	6	42,8
5/16	.312500	7,9375	.008	.2032	0,20	.0078	55	12,8	8	46,4
21/64	.328125	8,3344	.009	.2286	0,30	.01181	60	15,6	10	50
11/32	.343750	8,7312	.01	.254	0,40	.01575	65	18,3	12	53,6
23/64	.359375	9,1281	.02	.508	0,50	.01969	70	21,1	14	57,2
3/8	.375000	9,5250	.03	.762	0,60	.02362	75	23,9	16	60,8
25/64	.390625	9,9219	.04	1,016	0,70	.02756	80	26,7	18	64,4
13/32	.406250	10,3187	.05	1,270	0,80	.03149	85	29,4	20	68
27/64	.421875	10,7156	.06	1,524	0,90	.03543	90	32,2	22	71,6
7/16	.437500	11,1125	.07	1,778	1	.03937	95	35,0	24	75,2
29/64	.453125	11,5094	.08	2,032	2	.07874	100	37,8	26	78,8
15/32	.468750	11,9062	.09	2,286	3	.11811	105	40,6	28	82,4
31/64	.484375	12,3031	.10	2,540	4	.15748	110	43,3	30	86
1/2	.500000	12,7000	.20	5,080	5	.19685	115	46,1	32	89,6
33/64	.515625	13,0969	.30	7,620	6	.23622	120	48,9	34	93,2
17/32	.53125	13,4937	.40	10,160	7	.27559	125	51,7	36	96,8



1A01.32

3000 / 3100 SERIES TRACTORS



Introduction

LENGTH 1 inch = 25,4 mm							TEMPERATURE			
Inches	Decimals	mm	Inches to mm		mm to inches		Fahrenheit to Celsius			
			Inches	mm	mm	Inches	° F	° C	° C	° F
35/64	,546875	13.8906	0,5	12,70	8	0,31496	130	54.4	38	100,4
9/16	,562500	14.2875	,6	15,24	9	,35433	135	57.2	40	104
37/64	,578125	14.6844	,7	17,78	10	,39370	140	60.0	42	107.6
19/32	,593750	15.0812	,8	20,32	11	,43307	145	62.8	44	112.2
39/64	,609375	15.4781	,9	22,86	12	,47244	150	65.6	46	114.8
5/8	,6250	15.8750	1	25,4	13	,51181	155	68.3	48	118.4
41/64	,640625	16.2719	2	50,8	14	,55118	160	71.1	50	122
21/32	,656250	16.6687	3	76,2	15	,59055	165	73.9	52	125.6
43/64	,671875	17.0656	4	101,6	16	,62992	170	76.7	54	129.2
11/16	,687500	17.4625	5	127	17	,66929	175	79.4	56	132.8
45/64	,703125	17.8594	6	152,4	18	,70866	180	82.2	58	136.4
23/32	,718750	18.2562	7	177,8	19	,74803	185	85.0	60	140
47/64	,734375	18.6531	8	203,2	20	,78740	190	87.8	62	143.6
3/4	,7500	19.05	9	228,6	21	,82677	195	90.6	64	147.2
49/64	,765625	19.4469	10	254	22	,86614	200	93.3	66	150.8
25/32	,781250	19.8437	11	279,4	23	,90551	205	96.1	68	154.4
51/64	,796875	20.2406	12	304,8	24	,94480	210	98.9	70	158
13/16	,812500	20.6375	13	330,2	25	,98425	212	100.0	75	167
53/64	,828125	21.0344	14	355,6	26	1,02362	215	101.7	80	176
27/32	,843750	21.4312	15	381	27	1,06299	220	104.4	85	185
55/64	,859375	21.8281	16	406,4	28	1,10236	225	107.2	90	194
7/8	,875000	22.2250	17	431,8	29	1,14173	230	110.0	95	203
57/64	,890625	22.6219	18	457,2	30	1,18110	235	112.8	100	212
29/32	,906250	23.0187	19	482,6	31	1,22047	240	115.6	105	221
59/64	,921875	23.4156	20	508	32	1,25984	245	118.3	110	230
15/16	,937500	23.8125	21	533,4	33	1,29921	250	121.1	115	239
61/64	,953125	24.2094	22	558,8	34	1,33858				
31/32	,968750	24.6062	23	584,2	34	1,37795				
63/64	,984375	25.0031	24	609,6	36	1,41732				
1	1,00	25.40	25	635	37	1,45669				
			26	660,4	38	1,49606				
					39	1,53543				
					40	1,57480				



## Introduction

### H. Sealants

The Loctite sealants quoted in this Workshop Service Manual are under their industrial names.

For repair use the commercial name according to the chart below or where applicable use the power part equivalent.

Loctite Industrial Name	Commercial Name	Part N°
221 - 241 242 - 542	Lock and Seal	3405350M1
270	Stud lock	3405352 M3
510 - 518	Instant Gasket	3405355 M2
638 - 648	Retainer	3405387 M1
Silicomet	Superflex sealant R.T.V. silicone sealant (clear)	

**Note :** *Silicomet can be replaced by Hylosil (Powerpart). Use the product "Form A gasket 2" when sealing between plastic material and iron (or steel).*

**Example :** *PTO sensor, vehicle speed sensor,...*

Loctite products may be ordered from Massey Ferguson Central Parts Operation.

#### Application method for Loctite sealants

1. Remove all traces of previous sealants or corrosion
  - by mechanical process : wire brush or emery cloth
  - by chemical application : use "Decaploc 88"

Leave the product to take effect then scrap off and wipe clean.

2. Degrease the components with a solvent. Preferably use the "Loctite 706 Dry Super Solvent" or power part safety solvent.

3. Allow the solvent to vaporize

4. Apply the recommended type of sealant

- for blind holes, coat only latest threads to the bottom of the hole.

- for components which need to be pressed together, apply sealant on mating surfaces only using a clean brush. Wipe off excess sealants.

- for gasket faces, apply a bead on one face only. Pass around the holes, then tighten as rapidly as possible.

#### IMPORTANT :

If the ambient temperature is below 10° C, in order to accelerate the action of the sealant (except for

Silicomet) after operation 2, use Loctite activator T747 on at least one surface. Excess sealant, outside the joint will not harden (anaerobic curing of product) i.e. curing occurs only because of the absence of oxygen. Therefore wipe the excess off.

#### Note :

**a) Do not attempt to retighten after 5 minutes of curing as this may break the bead of product.**

**b) Do not use too much product to avoid blocking of mating parts.**

#### Grease

When grease is used in components which are in contact with transmission oil, use a grease which is miscible with oil to avoid blocking the hydraulic filters. Use "Amber Technical" grease supplied by WITCO company, 76320 Saint-Pierre des Elfes, France, or equivalent.

### I. Tightening torques

When reassembling components, use the "standard Torque" charts as a general guide when tightening fasteners that DO NOT HAVE SPECIFIC TIGHTENING recommendations :

- **1 and 2** : for metric fasteners

- **3 and 4** : for inch fasteners

When a specific torque is necessary, it is mentioned in the text.

Charts **1** and **3** show normal torque loadings applied to galvanized threaded fasteners with normal nuts with a coarse or fine thread, with or without flat or lockwashers, and weld nuts deeper than 0,8 d.

Charts **2** and **4** show reduced torque loadings applied to threaded fasteners in assemblies with self-locking galvanized nuts, phosphated nuts or bolts, shallow nuts and weld nuts shallower than 0,8 d.


Torques recommended in these charts are for dry parts. If the threads are oiled, reduce the torque.

#### NOTE:

a) Read the strength classification on the bolt head and determine the torque loading required.

b) The size is the diameter of the shank - not the head width.

EG :





1A01.34

## 3000 / 3100 SERIES TRACTORS

**Introduction****CHART 1**

Standard torque values : zinc plated metric threads

Nominal Size	STRENGTH CLASSIFICATION		STRENGTH CLASSIFICATION	
	ISO 8.8 (SAE 5 BS S)		ISO 10.9 (SAE 8 BS V)	
	Torque N.m		Torque N.m	
	Max	Min	Max	Min
M3	1.7	1.3	2.4	1.8
M4	4.1	3.1	5.7	4.3
M5	8	6	11.5	8.5
M6	14	10	20	14
M8	35	25	46	36
M10	70	50	96	72
M12	120	90	160	120
M16	260	200	400	300
M20	560	420	800	600
M24	960	720	1300	1000
M30	1800	1400	2800	2100
M36	3300	2500	4800	3600

**CHART 2**

Standard reduced torque values : metric threads

Nominal Size	STRENGTH CLASSIFICATION		STRENGTH CLASSIFICATION	
	ISO 8.8 (SAE 5 BS S)		ISO 10.9 (SAE 8 BS V)	
	Torque N.m		Torque N.m	
	Max	Min	Max	Min
M3	1.4	1	1.9	1.5
M4	3.3	2.5	4.6	3.4
M5	6.4	4.8	9.2	6.8
M6	11	8	16	12
M8	28	20	37	29
M10	56	40	77	57
M12	96	72	130	100
M16	210	160	320	240
M20	450	340	640	480
M24	770	570	1040	800
M30	1400	1100	2200	1700
M36	2600	2000	3800	2900



**Introduction****CHART 3**

Standard torque values : zinc plated inch threads

Nominal Size	STRENGTH CLASSIFICATION		STRENGTH CLASSIFICATION	
	SAE 5 (ISO 8,8 BS S)		SAE 8 (ISO 10,9 BS V)	
	Torque N.m		Torque N.m	
	Max	Min	Max	Min
#6	2.4	1.8	3.3	2.5
#8	4.4	3.4	6.3	4.7
#10	6.3	4.7	8.9	6.7
1/4	15	11	22	16
5/16	30	22	43	31
3/8	53	39	75	55
7/16	86	64	120	90
1/2	130	100	180	140
5/8	260	200	370	280
3/4	460	350	660	490
7/8	760	560	1060	800
1	1120	840	1600	1200
1 1/8	1390	1050	2200	1700
1 1/4	2000	1500	3200	2400
1 1/2	3400	2600	5400	4100

**CHART 4**

Standard reduced torque values : inch threads

Nominal Size	STRENGTH CLASSIFICATION		STRENGTH CLASSIFICATION	
	SAE 5 (ISO 8,8 BS S)		SAE 8 (ISO 10,9 BS V)	
	Torque N.m		Torque N.m	
	Max	Min	Max	Min
#6	1.9	1.5	2.6	2
#8	3.5	2.7	5	3.8
#10	5	3.8	7.1	5.3
1/4	12	8.8	18	13
5/16	24	18	34	25
3/8	42	31	60	44
7/16	69	51	96	72
1/2	104	80	140	110
5/8	210	160	300	220
3/4	370	280	530	390
7/8	610	450	850	640
1	900	670	1280	960
1 1/8	1100	840	1760	1360
1 1/4	1600	1200	2560	1920
1 1/2	2700	2100	4320	3280





***Cab and equipment***

***2 A01 Air conditioning***

CONTENTS

A. General	2
B. Safety and precautions	4
C. Maintenance	4



## Cab and equipment

### A . General

Suitable control of the internal environment of an agricultural implement cab requires that the temperature and humidity in the cab are within the range for human comfort, that an adequate volume of fresh filtered air is fed in to keep the cab under pressure and to prevent the ingress of impurities, and that the required steps are also taken to demist the windows to permit viewing in all directions.

Moreover, the distribution of air should be such that one is unable to perceive any appreciable difference in temperature within the cab, in particular over the body surface of the driver.

In addition, the unit must also be designed to stand up to the mechanical stresses brought about by the large number of impacts and vibration stresses associated with agricultural work.

Finally, sound operation in the muddy and dusty conditions associated with such agricultural work is necessary, and the equipment must be also capable of operating in positions which can reach angles of 16° tilt from the horizontal.

### Principle of cooling

There is no known process for producing coldness ; there is only one for absorption of heat. Air conditioning is a process by which the heat is taken out of the air. Temperature is measured by the quantity of heat in a material. Like water, which always runs from a high point towards a low point, heat always «runs» from a hot body to a cold body.

Hence, in order to condition the air or absorb the heat from the air in a cab, it is necessary to place hot air in contact with a cold surface.

There is also a physical property of substances which states that at a given pressure, there is a specific corresponding temperature to cause it to boil or evaporate.

In the vaporizing process which takes place at a constant temperature, the substance is able to absorb considerable heat. One example shows that at normal atmospheric pressure, water boils or vaporizes at 100°C (212°F).

A considerable quantity of heat can be absorbed by water, but the temperature will not rise. The same principles apply if heat is removed ; steam returns to the liquid state or liquids become solid.

Thus by controlling pressure in a closed circuit it is possible to have a liquid at low pressure and a low boiling temperature.

During vaporization the liquid is able to absorb heat from its environment.

### The cooling cycle

Air conditioning in the cab is obtained by means of a ventilation system which provides, after filtering, air reheated by pipes or hot water from the engine for cold days. If the ambient temperature, being too high, makes driving the tractor uncomfortable (in summer), a compressor cooling system allows to lower the temperature of several degrees in the cab. In an air conditioning unit, a refrigerant circulates in a closed circuit under pressure : this being freon R12. At properly specified points, this gas is subjected to modification of pressure and temperature.

A compressor, driven by the engine by means of a belt, sucks the vapour keeping low pressure on the upstream side, into the evaporator and compresses the gaseous freon obtained by this way, directing it to a cooling unit known as the condenser. The passage of air across the condenser located in front of the engine water radiator cools the gaseous freon and condenses it. The refrigerant which has become liquid is filtered. Humidity and impurities are picked up by a filter, which also has the function of acting as temporary reservoir ; this filter is known as the dehydrator reservoir.


The liquid freon R12 under high pressure is taken to the expansion valve, which governs the flow of fluid, and pressure is released ; this brings about a considerable fall in temperature and pressure. The liquid under low pressure starts boiling and evaporating in an exchanger or evaporator.

The warm humid air from the cab is passed across the evaporator by the turbines, fans, cools on contact and is forced back into the cab. The humidity in the air condenses in the evaporator and is discharged outside the cab through pipes. The cycle is completed when the gas is taken back to the compressor.

Depending upon the temperature desired in the cab, a thermostatic box or thermostat including a «OFF» setting initiates automatic switch off and switch on of the compressor by means of an electromagnetic clutch, thus regulating the temperature of the discharge air.



### Cab and equipment



**Key**

- |  |  |
|--|--|
| (1) Compressor with electromagnetic clutch | (8) Thermostat   |
| (2) Compressor outlet                      | (9) Fan  |
| (3) Condenser                              | (10) Evaporator  |
| (4) Dehydrator                             | (11) Low pressure piping (compressor induction)                        |
| (5) Condenser outlet                       | (12) Low pressure piping (evaporator outlet)                           |
| (6) Expansion valve                        | (13) High pressure piping (quick attach connection to expansion valve) |
| (7) Resistance for fan (2 speed)           | (14) Cab filter  |



2A01.4

## Cab and equipment

---

### B . Safety and precautions

---

It is very important to work in a clean environment, in order to prevent ingress of dirt and moisture into the system.

Carefully clean connections, then oil them lightly with compressor oil before making the connections.

Avoid blowing compressed air through the pipes, to remove particles which might be there ; use only refrigerant in such circumstances.

Do not remove protective coverings, plugs, etc... until actually ready to install components.

Cut flexible piping using a knife, never a saw.

Plug pipes and openings carefully when components are removed or disconnected.

The oil contained in the air conditioning circuit is special refrigeration oil. This oil readily mixes with the freon.

Use only approved refrigeration oil.

#### Precautions to be taken

An air conditioning unit can be a dangerous piece of equipment. It could be compared to a high pressure steam boiler. The pressure of the refrigerant is always greater than its normal boiling point. If piping is split, the refrigerant will evaporate or boil very rapidly.

The forces resulting from expansion can be very dangerous. A refrigeration engineer must always work with precaution, in order to prevent uncontrolled escape of refrigerant. The refrigerant R12 is non-flammable, non-toxic (except when in contact with a flame) and non-corrosive (except on contact with water).

You should be very careful when handling R12. It can freeze the skin or the eyes on direct contact. In contact with a flame or a high temperature, its decomposition gives phosgene gas.

Never handle freon without wearing safety goggles, as well as gloves.

Never attempt to empty a system by loosening off a connection. Slow emptying without danger can only be carried out using a manifold gauge set.

Do not empty the system in a room where there is a flame. Decomposition of R12 gives **phosgene gas which is deadly**. The same precautions must be taken if you are looking for leaks.

If it is necessary to retighten a connection, use two spanners for tightening, so as to prevent distortion which may give rise to leakage.

Never weld or clean with steam near a filled system; as excess pressure may be created with possible leakage.

Do not store R12 refrigerant in the sun or close to a source of heat. Always store the bottle safely items back when not in use.

Avoid subjecting the bottle to impact. Do not carry the bottle in the passenger compartment of a vehicle.

In the event of accident, proceed as follows :

If you get R12 in your eyes, wash them very carefully with a solution of mineral oil, and continue to wash them very carefully, with a solution of boric acid and water (1 teaspoonful of acid, diluted in a quarter of a cup of water).

Contact a doctor immediately.

**Note :Freezing caused by liquid refrigerant can be treated by progressively thawing the injured area with cold water and then applying a dry skin cream. Contact a doctor immediately.**

---

### C . Maintenance

---

#### Very important

Before switching on the air conditioning system, **ensure that windows and doors are properly closed**.

The interior of the cab must be kept as clean as possible. If for any reason whatsoever the cab cannot be completely closed, the air recycling system must be switched off. If these few recommendations are not observed, there is a risk of clogging at the evaporator which will result in stoppage of the air conditioning system and risk of damage to the compressor.

In order to ensure operation of the system, it is necessary to check periodically the filter located at the back of the cab, the condenser as well as the fans and the evaporator. Any plugging results in increased high side and low side pressure and reduces the efficiency of cooling. The tension of the driving belt and its alignment must be checked.

Check the condition of the drain for removal of condensation from the evaporator tray. Any accumulation of water in the tray might result in icing of the evaporator and stop circulation of freon.

In order to keep the system in good condition, we recommend to operate the system for several minutes each month in order to lubricate all the components, since the oil contained in the compressor can be mixed with the freon.



## Cab and equipment

### Electrical system

In regards to electrical checks, ensure that the fuses and pressure switch located at the rear of the compressor are in good condition. Low system charge or a damaged fuse will not allow current supply to the compressor clutch.

In order to check the action of the electromagnetic clutch, set the fan switch to «ON» position then move the air conditioning switch towards the maximum cold position: a click should be heard.

After several minutes operation, you should notice the successive switching on and switching off of the electromagnetic clutch as the cab cools.

The connecting wires must be in good condition.

#### Caution :

When restarting the compressor, specially if it has not operated for some time, proceed in the following manner to ensure lubrication right from the first rotations of the compressor :

- Switch on the electro-magnetic clutch by switching the fan to «ON» and moving the thermostat to cold.
- Crank over the tractor engine for a few seconds with the fuel stop button out or with the electrical stop control of the fuel injection pump disconnected (3095).
- Then push in the fuel stop button or reconnect the electrical stop control of the fuel injection pump (3095), start the engine and allow to idle slowly for several minutes.

Check visually the quantity of refrigerant (absence of bubbles) and its colour through the observation window of the dehydrator tank while operating the engine at a maximum revs. (with the fan and thermostat set at maximum cold).

**Note : upon compressor cycling, some bubbles are usually present. If a brown or bluish colouring appears in the sight glass, the system should be emptied, the lubricating oil in the compressor changed and the dehydrator filter and if necessary the expansion valve changed in that order.**

### Pre-season check and preventive maintenance

- Carry out checks and maintenance as described in the preceding paragraphs.
- Check visually the evaporator, piping, condenser, the dehydrator, compressor connections, the belt and evaporator drain tray and hose.
- Start the engine and set speed at 1500 rev/min. Switch fan to high speed and select thermostat to maxi cold.

- Check temperature of components.

The outlet of the expansion valve (evaporator side) the evaporator, the low pressure piping and «delivery valve» on the compressor must be cold when touching. The condenser, the dehydrator tank/filter, the expansion valve inlet, the compressor, the «output valve», the high pressure piping must be warm when touching.

- The dehydrator filter and oil should be changed at least each year, or after every one thousand hours and on any occasion when there is a major leakage and particularly if a brown or bluish colour is observed in the viewing window of the dehydrator filter.
- Connect gauge set to provide internal system checks. Always connect the low pressure gauge (blue) to induction side of the compressor and high pressure gauge (red) to the discharge side. Always make connections with engine stopped.
- If the circuit is overfilled more than 2kg(4.5 lbs) of R12 freon there is a risk of blockage at the dehydrator filter and the expansion valve. High and low pressure readings will be excessively high.
- When the air conditioning unit is operating, if the high and low pressure are equal, this is an indication of a defective compressor.
- If there is water in the circuit, the expansion valve (needle valve) will be blocked by a droplet of water which will change into ice. This will be indicated by a reduction of low pressure and high pressure.

11) Allow to dry for 48 hours (the higher the humidity level, the shorter the drying time).

12) Remove the strips of adhesive tape applied in point 4 and trim off any excess sealant projecting beyond the glass at both ends.

#### Health and safety

When exposed to moisture, SILICONE SEALANT may release small quantities of acetic acid. Avoid prolonged contact with the skin. If splashed in the eyes, wash out with water and seek medical attention. It is advisable to wear protective goggles.



***Cab and equipment***

***2 B01 Recharging the system with refrigerant***

CONTENTS

A .	Discharging the system and checking for leaks _____	2
B.	Evacuating and flushing the system _____	3
C.	Recharging the system with liquid _____	4
D.	Checking the pressures _____	5





2B01.2

## Cab and equipment

### A. Discharging the system and checking for leaks

#### Discharging the system

Ensure that room in which this operation is carried out is adequately ventilated. Avoid any naked flames and do not smoke.

Prepare the system for discharging by running the engine for a few minutes at 1000 rev/min with the air conditioning set to maximum cooling.

Stop the engine and switch off the air conditioning.

Remove the pressure switch from the high pressure hose and shunt both wires (violet and black).

Connect the manifold kit to the compressor (Fig. 1).


- red hose (small diameter) in place of the pressure switch.

- blue hose to low pressure (large diameter hose)

**Slowly** open the Manifold **low pressure** valve.

**Warning : If the system is discharged too quickly, compressor oil will be carried out with the refrigerant.**

After a few minutes, when the pressure has dropped by 1.5 to 2 bar, **slowly** open the manifold high pressure valve to allow all the refrigerant to escape.



- 1 Low pressure gauge
- 2 High pressure gauge
- 3 Measuring cylinder
- 4 Vacuum pump

#### Checking for leaks

When the system is empty replace any faulty parts then flush the system with Freon R12 by filling to a pressure of 2.5 to 3 bar (36 to 50 P.S.I.). To do this, connect the centre hose between the pressure gauges to the Freon cylinder (Fig. 4). Slightly slacken the centre by-pass hose connector to purge all air from the hose, then retighten it.

Open the taps on the high and low pressure gauges and allow the R12 gas to build up to a pressure of 2.5 to 3 bar (36 to 50 P.S.I.) in the system. Close the taps and leave the system charged at this pressure for 15 to 20 minutes before checking for leaks.


**Note : To avoid accidents, make sure that all taps are closed before handling the hoses. Do not start the engine.**

Using an electronic leak detector, run the end of its hose over (Fig. 2) :

- a) the compressor valve connectors
- b) all the compressor seals : shaft seal - oil reservoir plug seal

#### Discharging the system

Allow the gas to escape through the high and low pressure taps leaving a residual pressure of 0.2 to 0.3 bar (3 to 5 P.S.I.) in the system).





## Cab and equipment

### B . Evacuating and flushing the system

#### Evacuating the system (Fig. 3)

When the system is no longer under pressure, connect the centre hose to the vacuum pump. Open the high pressure tap (low pressure tap already open). Open the tap on the vacuum pump and turn the pump on.

**Note :** At ambient temperatures above 20° (68°F) it will generally take 30 minutes, in 15 minutes periods, to create the necessary vacuum. If the temperature is below 20° (68°F) it will take at least 60 minutes, especially if humidity is high. At the end of the evacuating period, the low pressure gauge should indicate a partial vacuum of 635 to 711 mm 25 to 28 in of mercury.

Close the high and low pressure taps and the vacuum pump tap and switch off the pump.

#### Flushing the system (Fig. 4)

Disconnect the centre by-pass hose from the vacuum pump and connect it to the top of the measuring cylinder. Open the top tap on the measuring cylinder, slightly slacken the centre by-pass hose connector in order to purge any air from the hose and retighten the connector when R12 starts to escape from the hose.

Open the high and low pressure by-pass taps to obtain an R12 gas pressure of 2.5 to 3 bar (36 to 50 P.S.I.). Close the taps and leave the charged system for 20 minutes.

Using the leak detector, recheck the system for leaks (Fig. 2).

#### Discharging and evacuating the system (Fig. 3)

Purge the system by slightly opening the low pressure by-pass tap and allowing R12 to escape.

Close the tap when a residual pressure of 0.2 to 0.3 bar (3 to 5 PSI) is obtained on both high and low pressure sides.

Connect the centre hose to the vacuum pump.

Open the high and low pressure taps and let the vacuum pump running for 20 minutes.

Close the high and low pressure taps, having checked that the low pressure gauge indicates a partial vacuum of 635-711 mm (25 to 28 in) of mercury.

Having completed all these operations, the system is ready for recharging with Freon R12.

**Note :** Air must be purged from the hoses each time they are connected to the pressure gauges and charging cylinder.




Fig. 3




Fig. 4



2B01.4

## Cab and equipment

### C. Recharging the system with liquid (engine stopped)

The quantity of Freon required to charge the system correctly is 1.7 to 1.9 kg (3.7 to 4.2 lbs).

#### 1. Instructions for filling the charging cylinder from the freon gas bottle (Fig. 5)

Connect the freon bottle to the bottom of the charging cylinder and tip the bottle upside down. Open the taps. When pressures in the bottle and charging cylinder are equal, bleed gas from the charging cylinder through the top valve until the quantity of freon required for the system is obtained. Close all taps.

#### 2. Connection for charging the system (Fig. 6)



Connect the bottom of the charging cylinder to the centre connector between the pressure gauges.

- purge air from the hoses.
- mark the level on the charging cylinder.
- slowly open the low and high pressure taps on the pressure gauges in order to charge the system.

**Note :** To allow complete charging with liquid, the pressure in the charging cylinder must be between 6 and 7 bar (87 and 100 P.S.I.).

When a system is correctly charged and the pressures are equal, pressure on both low and high pressure sides should be 4 to 5 bar (58 to 73 P.S.I.).

If the charging cylinder has no heater element, the system will have to be partially charged with liquid then topped up with gas.





## Cab and equipment

### Partial liquid recharge with gas top-up (engine stopped, then running)

When pressures in the charging cylinder and system are equal, close the high and low pressure taps and the bottom tap on the charging cylinder.

To top up with gas, connect the centre hose between the pressure gauges to the top of the charging cylinder, then purge air from the hose (do this by slightly unscrewing the hose and allowing gas to escape for a few seconds) (Fig. 7).

For this operation, open the low pressure **tap only** and run the engine at 1000 - 1200 rev/min with the air conditioning set at maximum cooling and the fan on fast speed.

The system is correctly charged when the required level is obtained into the charging cylinder.

Close the taps on the charging cylinder and on the low pressure gauge.




Fig. 7

### D . Checking the pressures

Once charging has been completed, check the air conditioning system for correct operation.

With the pressure gauges already connected to the compressor (Fig. 8), start the engine and set the thermostat control to maxi cold and the fan to fast speed. After a few times, **the high pressure hose should feel hot and the low pressure hose cold.**

No bubbles should be visible in the dehydrator sight glass.

Check the compressor cycles. The compressor should cycle «on» and «off» for approximately the same length of time once the cab temperature has stabilized, according to the thermostat setting.

When the air conditioning is off, pressures on the low and high pressure sides should be equal and between 4 and 5 bar (58 and 73 PSI) in a correctly charged system. **These figures will however vary according to the outside temperature.**

When the air conditioning is running low pressure should be between 0.2 and 1 bar (3 and 15 PSI) and high pressure between 8 and 15 bar (116 and 218 PSI). All these figures depend on the outside temperature. The system should cycle on and off in all cases.

#### Note :

- fan on fast speed and thermostat on coldest setting

- engine running at 1800 - 2000 rev/min.




Fig. 8



***Cab and equipment***

***2 C01 Air conditioning system faults - Compressor***

CONTENTS

A .	Diagnosis and fault analysis	2
B.	Failure of air conditioning system itself	2
C.	Compressor	4



## Cab and equipment

### A . Diagnosis and fault analysis

#### Diagnosis

In general pressure readings are directly related to atmospheric conditions (pressure and temperature). At temperatures between 21° and 30° C (68° and 85° F) low pressure readings will vary between 0.2 and 1 bar (3 and 15 PSI) and high pressure readings between 8 and 15 bar (116 and 218 PSI). To detect faults, the pressure gauge kit must be connected to the compressor.

#### Fault analysis

Leaks in the system will lead to inadequate cooling and low and high gauge readings will be too low.

If the system is under-charged, bubbles will be permanently visible in the dehydrator sight glass and both gauges readings will be low.

If the evaporator is dirty or an expansion valve is blocked or frozen up, there will be a partial vacuum on the low pressure side and insufficient pressure on the high pressure side.

An over- charged system, an expansion valve stuck open or a clogged condenser will cause excessive pressure on the low pressure side.

A clogged condenser, an over-charged system will cause excessive pressure on the high pressure side.

#### Overcharge

In a correctly charged system, R12 discharged from the compressor in the form of gas loses its excess heat, resulting from compression in the first coil of the condenser and condenses to a liquid in the subsequent coils. Before flowing to the reservoir, this liquid is held in the last condenser coil. If the system is over-charged, the liquid level builds up in the condenser, leaving fewer coils available to condense the gas. Both temperature and pressure then build up, causing hoses to burst in some cases.

#### Failure while engine is running

Overcharge

Worn hoses

Chaffed hoses

Hoses cut by sharp edges

Bends too tight

Hoses too close to battery (acid)

Plugged condenser fins

#### Failure when engine is stopped

Same reasons as when running plus stoppage of engine compartment cooling and engine «temperature surge» in the few moments after it stops.

The sudden temperature increase when the engine is stopped causes both the temperature and pressure in the air conditioning system hoses to rise. If a hose is only just holding, this heat will reduce its resistance to bursting.

This is particularly apparent in overcharged systems and where hoses are worn or badly positioned (hot spots).

### B . Failure of air conditioning system itself

(The manifold kit must be connected to the compressor valves).

#### High pressure reading too high

- 1 - Refrigerant overcharge.
  - Purge the system.
  - Avoid leaving the system undercharged.
- 2 - Air in system, in spite of correct low pressure reading.
  - Purge and recharge the system.
- 3 - Space between condenser fins clogged with insects.
  - Clean the condenser.
- 4 - Refrigerant remains liquid in suction pipe, at the evaporator outlet.

This causes moisture or frost formation on the hose or on the compressor inlet valve.

  - Check that the expansion valve sensing bulb is securely in contact with the suction pipe.
- 5 - Plug left in a pipe on assembly, revealed by a difference of temperature above and below the point where the plug is located.
- 6 - If high pressure reading is higher than the one obtained during normal operation with correct low pressure reading and charge but presence of bubbles in the dehydrator, the dehydrator hose connections have been reversed and fluid is flowing in the wrong direction.
- 7 - If high pressure reading is very high, low pressure reading normal, with bubbles in the dehydrator and frosting of dehydrator reservoir, there is a restriction at the dehydrator inlet, causing the dehydrator to act as an expansion valve.



## Cab and equipment

### High pressure reading too low

- 1 - Incorrect charge. A lack of refrigerant causes bubbles which appear in the sight glass.
- 2 - Compressor gasket cracked or compressor valves leaking

### Low pressure reading too low, together with insufficient cooling

- 1 - Restriction in a hose or in dehydrator. Revealed by a difference of temperature above and below the restriction, or by cooling of the dehydrator reservoir whilst the system is running.
- 2 - Insufficient charge in expansion valve sensing bulb.
  - Heat the end of the thermostatic bulb by holding it. Intake pressure should rise quickly to at least 1.45 bar (21 PSI) with the engine at idling speed. If not, the expansion valve must be replaced.
- 3 - Expansion valve capillary tube broken or leaking. The expansion valve stays closed, causing the system to operate at very low pressure.
- 4 - Formation of frost in expansion valve or jet
  - The expansion valve or jet may be frozen up even though the pipes are barely frosted.
- 5 - Expansion valve stuck. Bits of rust in system.
  - Heating the end of the sensing bulb has no effect on the low pressure reading.
  - The expansion valve may open after a short rest, then stick again after some time in operation.
- 6 - Check that the evaporator air inlet is not clogged.

### Low pressure reading too high

- 1 - Compressor belt too slack.
- 2 - Expansion valve sensing bulb incorrectly fixed.
- 3 - Expansion valve needle stuck open. Refrigerant flows too freely through the coils and cools or freezes the inlet pipe.
- 4 - Compressor inlet valve filter blocked.
- 5 - Low refrigerant charge.
  - Check whether bubbles are visible in the sight glass when the system is operating with the fans switched on.

- 6 - Compressor inlet and outlet valves leaking.

- 7 - If high pressure reading is low, low pressure reading is high and the charge is correct, there are leaks at the compressor gasket or faulty valves.

### Noisy expansion valve (persistent whistling)

- 1 - Low refrigerant charge, revealed by presence of bubbles in the sight glass.

### Insufficient cooling

- 1 - Compressor not functioning properly.
- 2 - Expansion valve not functioning properly.
- 3 - High and low pressure readings low, tending towards partial vacuum, with correct charge. Temperature too low at evaporator outlet, causing the expansion valve to close and poor synchronization between thermostat cycling and expansion valve opening.

### Formation of frost on evaporation fins

- 1 - Check thermostat electrical contacts.
- 2 - Check that the sensing bulb is in contact with the evaporator fins.

### Intermittent operation of the compressor (irregular cycling)

- Check belt tension
- Check clutch drive plate clearance
- Check clutch coil voltage and current
- Check the compressor itself.

### Unusual compressor noise

#### In engaged position :

- check :compressor mounting clutch and that there is no slipping clutch and compressor bearings the refrigerant charge (175 cm<sup>3</sup> + 15 cm<sup>3</sup>) the compressor inlet and outlet valves.

#### In disengaged position :

- check clutch drive plate clearance.



2C01.4

### Cab and equipment

#### C . Compressor

##### Setting the drive plate clearance

Check the drive plate clearance with a feeler gauge. The clearance should be 0.4 - 0.8 mm (0.016 - 0.032 in)(Fig. 1).

If the clearance is not the same all the way round, lift slightly and tap gently where the clearance is greatest.

**Note :** Drive plate clearance is obtained by means of shims. When reassembling or fitting a new clutch, try fitting the original shims first.

When fitting a new clutch on a compressor which previously had no shims, use the following sizes :  
1.02 mm - 0.05 mm - 0.12 mm  
(.040 in) - (.00197 in) - (.00472 in)  
Torque the nut to 40 Nm (30 lbf/ft)




Fig. 1

##### Precaution to be taken when removing and refitting the compressor :

- Note :**
- 1) Run the air conditioning system for 5 to 10 minutes before removing the compressor in order to return all the refrigerant to the compressor.
  - 2) The head connectors must face upwards or be in line with the oil filler hole (Fig. 2).




Fig. 2

Locate the valve cover plate dowels in the correct holes in the block, then align the plate. Torque to 30 - 34 Nm (22 - 25 lbf/ft) according to tightening sequence (Fig. 3).




Fig. 3





## Cab and equipment

### Filling with oil

- 1 - Discharge the R12 refrigerant.
- 2 - Always check the oil level whenever a system component is replaced or if there has been a leak.
- 3 - Determine the mounting angle.  
Place the angle gauge on the flats of the two front fixing lugs. Centre the bubble. Make an accurate note of the mounting angle.
- 4 - Remove the plug. Look through the oil filler hole then rotate clutch plate to correctly position the internal parts of the compressor, aligning them as soon as they start to move towards the front of the compressor (Fig. 4).

**Note : This operation is essential in order to release the dipstick from the internal parts so that it can be inserted to its full depth.**

- 5 - Insert the dipstick up to the stop (Fig. 5). The stop is formed by the bend at the top of the dipstick :
  - the top of the bend must be on the left if the compressor is RH mounted.
  - the top of the bend (stop) must be on the right if the compressor is LH mounted.
  - in both cases, the bottom end of the dipstick bend **MUST BE IN CONTACT WITH THE EDGES OF THE FILLER HOLE.**
- 6 - Remove the dipstick and count the number of graduations covered by oil.




Fig. 4

- a : filler hole
- b : ball
- c : ball joint
- d : piston rod
- e : dipstick
- f : stop




Fig. 5



2C01.6

**Cab and equipment**

7 -Using the chart below, check the oil level according to the compressor mounting angle :

Mounting Angle	Acceptable oil levels (measured by notches on the dipstick)
0°	2 - 4
10°	4 - 5
20°	5 - 6
30°	6 - 7
40°	7 - 9
50°	9 - 10
60°	10 - 12
90°	12 - 13

8 -If the graduations noted on the dipstick do not agree with the chart, top up to the required level.

**Note : Use only refrigeration oil. Close the container after use.**

9 -Refit the filler plug.

- Check the condition of the «O» ring
- Check that the «O» ring and its seat are clean.

10 -Tighten the plug to a torque of 8 - 12 Nm (6 - 9 Lbf/ft). If there is a leak, do not tighten the plug any further : remove it and fit a new «O» ring.

**Note : Regular checking of the oil level is unnecessary, unless there is good reason to suspect that the level is low or needs checking.**

**Recommended lubricants for SD.5 compressor filling, capacity : 175 cm<sup>3</sup>**

Make	Name	Grade
Sun Oil Co	Suniso	4 GS 5 GS
	Sunbis	31/41/51
Caltex	Capella	WF100 WF68
BP	Enagole	LPT 100/150/185
Shell	Talpa Oil	20/30
	Bitoria Oil	33/41
Mobil	Gargoyle Artil	300
Castrol	Ice Matic	299/99



***Cab and equipment***

*2 D01 Replacement of glasses*

CONTENTS

- A . Replacement of seal (hinge) on cab door window \_\_\_\_\_ 2



2D01.2

## Cab and equipment

### A . Replacement of seal (hinge) on cab door window

#### Product family

Silicone elastomer, vulcanizing at ambient temperature without having to add a catalyst.

#### Products used

RHODORSIL SILICONE SEALANT «.B. or Rubson HP Translucid, or equivalent.

RHODORSIL is manufactured by RHONE-POULENC, Silicones Dept.

#### Composition

- Reactive siloxanic polymethyl polymer : min. 85 %
  - Reinforcing silica between 10 and 11 %
  - Cross-linking agent between 3 and 4 %
  - Pigment max 1%
- Colour : translucid

#### Instructions

- 1) Carefully remove all traces of previous silicone sealant
- 2) Clean the sides of the windows with a dry cloth.
- 3) Thoroughly degrease the edges of the 2 windows with a dielectric solvent (trichloroethylene, Trichloroethane....).  
**Note : The surfaces must be allowed to dry before applying the sealant.**
- 4) Apply three or four 20 mm strips of cellulose adhesive tape (A) to hold the 2 pieces of glass 4 to 5 mm apart (Fig. 1)
- 5) Turn the glass over (the strips of tape will then be on the bottom) (Fig. 2).
- 6) Stick a strip of cellulose tape (B) on the edge of each window to protect the area adjacent to the joint.
- 7) Sprinkle talc onto the groove (to neutralize the effect of the adhesive in the bottom of the groove), then blow clean.
- 8) Squeeze a continuous strip of silicone sealant into the 4 - 5 mm groove (this is easier to achieve by applying the sealant from a cartridge with a compressed air gun).
- 9) Smooth the surface of the joint with a wet spatula, or with a wet rubber block, sliding it along the surface of the two windows.




Fig. 1




Fig. 2

- 10) Remove the 2 strips of tape applied in point 6.
- 11) Allow to dry for 48 hours (the higher the humidity level, the shorter the drying time).
- 12) Remove the strips of adhesive tape applied in point 4 and trim off any excess sealant projecting beyond the glass at both ends.

#### Health and safety

When exposed to moisture, SILICONE SEALANT may release small quantities of acetic acid. Avoid prolonged contact with the skin. If splashed in the eyes, wash out with water and seek medical attention. It is advisable to wear protective goggles.





## **3 . SPLITTING THE TRACTOR**

### **Contents**

- 3 A01 SPLITTING THE TRACTOR BETWEEN THE ENGINE AND THE GEARBOX -  
SPEEDSHIFT 3000**
- 3 A02 SPLITTING THE TRACTOR BETWEEN THE ENGINE AND THE GEARBOX -  
SPEEDSHIFT 3100**
- 3 A03 SPLITTING THE TRACTOR BETWEEN THE ENGINE AND THE GEARBOX -  
DAYNAHISFT 3000**
- 3 A04 SPLITTING THE TRACTOR BETWEEN THE ENGINE AND THE GEARBOX -  
DAYNAHISFT 3100**
- 3 B02 SPLITTING THE TRACTOR BETWEEN THE GEARBOX AND THE REAR AXLE**
- 3 C01 SPLITTING THE TRACTOR BETWEEN THE FRONT FRAME AND THE ENGINE**



## ***Splitting The Tractor***

### **3A01 *SPLITTING THE TRACTOR BETWEEN THE ENGINE AND THE GEARBOX 4 and 6 cylinder engines (3000)***

#### CONTENTS

A. Removal _____	2
B. Refitment _____	3
C. Tightening torques _____	4



# Splitting The Tractor

## A. Removal

1. Disconnect the two front differential lock (4WD) control hoses.  
Plug the pipe connections.
2. Remove the guard and the 4WD transmission shaft.
3. Remove the sheet metal panels.
4. Disconnect the earth cables only from the batteries.
5. Remove the hood rear bracket.
6. Disconnect and plug:
  - the two orbital steering ram hoses (mark their position).
  - the two air conditioning plugs and the bracket (if fitted).
  - the fuel return hose.
  - the two cooler hoses on the 17 bar valve (mark the positions).
  - the accelerator control on the injection pump.
  - the fuel cut-off control.
  - the flowmeter harness (if fitted).
  - the main wiring harness connections (on cab console or above engine depending on harness model).
  - the heater hoses on the RH rear side of the engine block (4 cyl.) on the water pump (6 cyl. - mark the position). Plug the connections to avoid draining the cooling system completely).
  - the 7.5 and 10 amp fuse harness (to release this, slightly slacken the straight rod above the radiator).
  - the fuel supply hose.
7. Immobilise the tractor:
  - apply the handbrake.
  - fit wedges between the frame and the front axle (Fig.1).
8. Support the tractor under the gearbox using a suitable stand.
9. Support the tractor under the sump using a suitable trolley jack.
10. Slacken the four 10 diam. bolts **(1)** (Fig.2) on the rubber dampers on the RH and LH cab supports, raise the cab slightly (low profile cab) and position chocks under it.
11. Remove the bolts attaching the engine to the gearbox.
12. Separate the gearbox from the engine.  
**Note: As a safety measure, remove the front weights.**




Fig. 1




Fig. 2





## Splitting The Tractor

### B. Refitment

13. Screw two dowel pins (made locally) into diametrically opposite positions on the gearbox.
14. Replace the seal /1\ on the input shaft (2) (Fig.3).
  - a) withdraw the PTO shaft (3).
  - b) extract the seal /1\.
  - c) replace the PTO shaft.
  - d) remove the circlip (4) and the washer (5).
  - e) protect the splined end of the shaft (3).
  - f) fit a new seal /1\ using service tool 3376803 M1. (see 3A02)
  - g) remove the protection from the splines.
  - h) refit the washer (5) and the circlip (4).
15. Lightly grease the gearbox input shaft splines with molybdenum disulphide grease.
16. Check that the two dowel pins are fitted on the engine.
17. Fit the engine to the gearbox by turning the flywheel ring gear with a screwdriver.
18. Fit the two attaching bolts. For 6 cylinder engines only, coat the bolts with Loctite 270. Tighten to the torque indicated in Figs. 5 and 6.
19. Carry out procedures 4 to 9 in reverse.
20. Carry out procedure 10 in reverse.  
**Note: When replacing the cab on its supports, check that the balls (1) of the gear and reverser levers are correctly located in their respective housings (2) (Fig.4).**
21. Top up the cooling system.
22. Carry out procedures 1 and 2 in reverse (4WD).
23. Start the engine.
24. Check the accelerator control and fuel cut-off setting.
25. Check:
  - the hydraulic circuits for leaks.
  - the operation of the electrical circuits.
26. Refit the sheet metal panels.
27. Road test the tractor.




Fig. 3





Fig. 4



# Splitting The Tractor

## C. Tightening torques


Engine to gearbox attachment (4 cylinder engines)



Tightening torques (1) to (15) 100 - 130 Nm

Fig. 5

Engine adaptor plate to gearbox spacer attachment (6 cylinder engines)



Tightening torques (Nm)

- |             |             |              |
|-------------|-------------|--------------|
| (1) 160-210 | (6) 450-610 | (11) 80-104  |
| (2) 80-104  | (7) 450-610 | (12) 160-210 |
| (3) 80-104  | (8) 280-370 | (13) 160-210 |
| (4) 160-210 | (9) 160-210 | (14) 100-130 |
| (5) 280-370 | (10) 80-104 |              |

Fig. 6



## ***Splitting the tractor***

### ***3 A02 Splitting the tractor between the engine and the gearbox Pull-type clutch (3100)***

#### CONTENTS

A.	Removal	2
B.	Refitment	3
C.	Fitting engine adaptor plate/gearbox spacer	4
D.	Service tools	5



## Splitting the tractor

### A. Removal

**Note: Plug or cover disconnected hydraulic pipe connections to prevent leaks and the ingress of foreign matter.**

1. Disconnect the two front differential lock (4WD) control hoses.
2. Remove the guard and the 4WD transmission shaft.
3. Remove the inspection plate under the clutch housing.
4. **Remove the pin /1\ connecting the clutch slave cylinder (2) to the release bearing (3) (Fig.1).**
5. Remove the sheet metal panels.
6. Remove the battery cover.
7. Disconnect the earth cables only from the batteries.
8. Remove the hood rear bracket.
9. Disconnect:
  - the two orbitrol steering ram hoses (**mark their position**).
  - the two air conditioning plugs and the bracket (if fitted).
  - the fuel return hose.
  - the two cooler hoses on the 17 bar valve (**mark the positions**).
  - the throttle control on the injection pump.
  - the flowmeter harness (if fitted).
  - the main wiring harness connections above the engine.
  - the heater hoses on the water pump and behind the fan pulley. (Plug the connections to avoid draining the cooling system completely).
  - the 7.5 and 10 amp fuse harness. To release this, slightly slacken the straight rod above the radiator.
  - the fuel supply hose.
10. Immobilise the tractor.  
Apply the handbrake.  
Fit wedges between the frame and the front axle (Fig.2).
11. Support the tractor under the gearbox using a suitable stand.




Fig. 1




Fig. 2



12. Support the tractor under the sump using a suitable trolley jack.
13. Slacken the bolts attaching the engine to the gearbox.
14. Separate the gearbox from the engine  
**Note: As a safety measure, remove the front weights.**



## Splitting the tractor

### B. Refitment

15. Assemble the carrier (3) on the clutch slave cylinder (2) with the pin /1\ (Fig.3).
16. **Position service tool 3376802 M1 (36 mm shim) between the end of the guide-pin (4) and the face of the control cylinder (2) (Fig.3).**
17. Screw two dowel pins (use two bolts) into diametrically opposed positions on the gearbox.
18. **Replace the seal /1\ on the input shaft (2) (Fig.4).**
  - a) withdraw the PTO shaft (3).
  - b) extract the seal /1\.
  - c) replace the PTO shaft (3).
  - d) remove the circlip (4) and the washer (5).
  - e) protect the splined end of the shaft (3).
  - f) lubricate and fit a new seal /1\ using service tool 3376803 M1.
  - g) remove the protection from the splines.
  - h) refit the washer (5) and the circlip (4).
19. Lightly grease the gearbox input shaft splines (using molybdenum disulphide grease).
20. Check that the two dowel pins are fitted on the engine.
21. Fit the engine to the gearbox by turning the flywheel ring gear with a screwdriver.  
**Note : During assembly, the release bearing must be heard to engage in the clutch cover plate. Remove the service tool through the inspection hole (Fig.3).**  
Check that the clip is correctly positioned on the cover plate.  
Remove the two dowel pins.
22. Clean the bolts attaching the engine to the gearbox and coat them with **Loctite 270** before fitting. See Section C for tightening torques.
23. Carry out procedures 6 to 12 in reverse.
24. Top up the cooling system.
25. Refit the guard and transmission shaft (4WD).
26. Reconnect the two front wheel differential lock control hoses (4WD)
27. Start the engine.
28. Check the accelerator control setting.



29. Check:
  - all hoses and pipes for leaks
  - that the electrical circuits are working.
30. Refit the inspection plate under the clutch housing.
31. Refit the sheet metal panels.
32. Road test the tractor.




3A02.4

3000/3100 SERIES TRACTORS



# Splitting the tractor

## C. Attaching engine adaptor plate/Gearbox spacer





## Splitting the tractor


### Tightening torques (Nm)

(1)	120-160	(8)	600-800
(2)	300-400	(9)	600-800
(3)	120-160	(10)	300-400
(4)	120-160	(11)	120-160
(5)	300-400	(12)	120-160
(6)	600-800	(13)	300-400
(7)	600-800	(14)	300-400

### D. Service tools


#### 3376802 M1

36 mm tool to connect engine and gearbox



#### 3376803 M1

Input shaft seal fitting tool





***Splitting the tractor - Dynashift***

3A03.1

**3A03** *Splitting the tractor between the engine  
and the gearbox (3000)*

CONTENTS

<b>A. Removal</b> _____	<b>2</b>
<b>B. Refitment</b> _____	<b>2</b>





3A03.2

3000/3100 SERIES TRACTORS



## Splitting the tractor - Dynashift

### A. Removal

1. Disconnect the two front differential lock (4WD) control hoses. Plug the pipe connections.
2. Remove the guard and the 4WD transmission shaft.
3. Remove the sheet metal panels.
4. Disconnect the earth cables only from the batteries.
5. Remove the hood rear bracket.
6. Disconnect and plug :
  - the two orbital steering ram hoses (mark their position).
  - the two air conditioning plugs and the bracket (if fitted).
  - the fuel return hose.
  - the two cooler hoses on the 17 bar valve (mark the positions).
  - the accelerator control on the injection pump.
  - the flowmeter harness (if fitted).
  - the main harness connections above the engine.
  - the heater hoses on the thermostat block to the engine front and to the water pump. Plug the connections to avoid draining the cooling system completely).
  - the 7.5 and 10 amp fuse harness (to release this, slightly slacken the straight rod above the radiator).
  - the fuel supply hose.
7. Immobilise the tractor :
  - apply the handbrake.
  - fit wedges between the frame and the front axle (Fig.1).
8. Support the tractor under the gearbox using a suitable stand.
9. Support the tractor under the sump using a suitable trolley jack.
10. Remove the tool box.
11. Remove the bolts attaching the engine to the gearbox.
12. Separate the gearbox from the engine.

**Note: As a safety measure, remove the front weights.**




Fig. 1




Fig. 2

### B. Refitment

13. Screw two dowel pins (made locally) into diametrically opposite positions on the gearbox.
14. Replace the seal /1\ on the input shaft (2) (Fig.2).
  - a) withdraw the PTO shaft (3).
  - b) extract the seal /1\.
  - c) replace the PTO shaft.
  - d) remove the circlip (4) and the washer (5).
  - e) protect the splined end of the shaft (3).
  - f) fit a new seal /1\ using service tool 3376803 M1 (see 3A04)
  - g) remove the protection from the splines.
  - h) refit the washer (5) and the circlip (4).
15. Lightly grease the gearbox input shaft splines with molybdenum disulphide grease.
16. Check that the two dowel pins are fitted on the engine.
17. Fit the engine to the gearbox by turning the flywheel ring gear with a screwdriver.
18. Fit the attaching bolts. Coat the bolts with Loctite 270. Tighten to the torque indicated in section 3A04.
19. Carry out procedures 4 to 9 in reverse.
20. Carry out procedure 10 in reverse.
21. Top up the cooling system.
22. Carry out procedures 1 and 2 in reverse (4WD).
23. Start the engine.
24. Check the accelerator control and fuel cut-off setting.
25. Check:
  - the hydraulic circuits for leaks.
  - the operation of the electrical circuits.
26. Refit the sheet metal panels.
27. Road test the tractor.



**Splitting the tractor - Dynashift**

3A04.1

**3 A04** *Splitting the tractor between the engine  
and the gearbox  
Pull-type clutch (3100)*

CONTENTS



<b>A.</b>	<b>Removal</b> _____	<b>2</b>
<b>B.</b>	<b>Refitment</b> _____	<b>3</b>
<b>C.</b>	<b>Fitting engine adaptor plate/gearbox spacer</b> _____	<b>4</b>
<b>D.</b>	<b>Service tools</b> _____	<b>5</b>



## Splitting the tractor - Dynashift

### B. Refitment

15. Fit the spring washer (4) and the release bearing (7) into the carrier (2) (Fig.3).
16. Fit the cover (3), the stop bolt (6) (Fig. 3) into the release bearing carrier notch. Press on the spring washer and place pin /1\ its bend pointed downwards (Fig. 1 and 3). Check the free rotation and radial movement of the release bearing.
17. Position service tool 3376802 M2 between the end of the release bearing carrier (2) and the seal carrier (5) (Fig. 3).
18. Screw two dowel pins into diametrically opposed positions on the gearbox.
19. **Replace the seal /1\ on the input shaft (2) (Fig.4).**
  - a) withdraw the PTO shaft (3).
  - b) extract the seal /1\.
  - c) replace the PTO shaft (3).
  - d) remove the circlip (4) and the washer (5).
  - e) protect the splined end of the shaft (3).
  - f) lubricate and fit a new seal /1\ using service tool 3376803 M1.
  - g) remove the protection from the splines.
  - h) refit the washer (5) and the circlip (4).
20. Lightly grease the gearbox input shaft splines (using molybdenum disulphide grease).
21. Check that the two dowel pins are fitted on the engine.
22. Fit the engine to the gearbox by turning the flywheel ring gear with a screwdriver.  
**Note : During assembly, the release bearing must be heard to engage in the clutch cover plate. Remove the service tool through the inspection hole (Fig.3).**  
Check that the clip is correctly positioned on the cover plate.  
Remove the two dowel pins.
23. Clean the bolts attaching the engine to the gearbox and coat them with **Loctite 270** before fitting. See Section C for tightening torques.
24. Carry out procedures 6 to 12 in reverse.
25. Top up the cooling system.
26. Refit the guard and transmission shaft (4WD).
27. Reconnect the two front wheel differential lock control hoses (4WD)
28. Start the engine.
29. Check the accelerator control setting.



30. Check:
  - all hoses and pipes for leaks
  - that the electrical circuits are working.
31. Refit the inspection plate under the clutch housing.
32. Refit the sheet metal panels.
33. Road test the tractor.



## Splitting the tractor - Dynashift

### A. Removal

**Note: Plug or cover disconnected hydraulic pipe connections to prevent leaks and the ingress of foreign matter.**

1. Disconnect the two front differential lock (4WD) control hoses.
2. Remove the guard and the 4WD transmission shaft.
3. Remove the inspection plate under the clutch housing.
4. **Remove the pin (1) connecting the release bearing carrier (2) and the cover (3) (Fig. 1).**
5. Remove the sheet metal panels.
6. Remove the battery cover.
7. Disconnect the earth cables only from the batteries.
8. Remove the hood rear bracket.
9. Disconnect :
  - the two Orbital steering ram hoses (**mark their position**).
  - the two air conditioning couplers and the bracket (if fitted). Protect both couplers using the plugs kit 3376935 M91.
  - the fuel return hose.
  - the two cooler hoses on the 17 bar valve (**mark the positions**).
  - the throttle control on the injection pump.
  - the flowmeter harness (if fitted).
  - the main wiring harness connections above the engine.
  - the heater hoses on the thermostat block to the front of the engine and on the water pump. (Plug the connections to avoid draining the cooling system completely).
  - the 7.5 and 10 amp fuse harness. To release this, slightly slacken the straight rod above the radiator.
  - the fuel supply hose.
10. Immobilise the tractor.
 

Apply the handbrake.

Fit wedges between the frame and the front axle (Fig.2).
11. Support the tractor under the gearbox using a suitable stand.




Fig. 1




Fig. 2

12. Support the tractor under the sump using a suitable trolley jack.
13. Slacken the bolts attaching the engine to the gearbox.
14. Separate the gearbox from the engine
 

**Note: As a safety measure, remove the front weights.**



# Splitting the tractor - Dynashift

## C. Attaching engine adaptor plate/Gearbox spacer

Tightening torques (Nm)

- |             |              |
|-------------|--------------|
| (1) 120-160 | (8) 600-800  |
| (2) 300-400 | (9) 600-800  |
| (3) 120-160 | (10) 300-400 |
| (4) 120-160 | (11) 120-160 |
| (5) 300-400 | (12) 120-160 |
| (6) 600-800 | (13) 300-400 |
| (7) 600-800 | (14) 300-400 |




Fig. 5




## Splitting the tractor - Dynashift

### D. Service tools


#### 3376802 M2

Tool to connect engine and gearbox




#### 3376803 M1

Input shaft seal fitting tool



#### 3376935 M91

Plugs kit for air conditioning couplers





## ***Splitting the tractor***

### *3 B02 Splitting the tractor between the gearbox and the rear axle (cab integral with rear axle)*

#### CONTENTS

A. Removal	2
B. Refitment	3



## Splitting the tractor

### A. Removal

#### 3000-3100 tractors

1. Drain the gearbox and rear axle of oil.
2. Disconnect and plug the following (on LH side of gearbox) (Fig. 1).
  - . the PTO clutch lubricating pipe (1) (at both ends)
  - . the gearbox lubricating hose (2)
  - . the return hose (3)
  - . the hydraulic hose (4) supplying the clutch slave cylinder

#### 3000 tractors

3. Carry out procedures 1 to 6 from Section 3 AO1.

#### 3100 tractors

4. Carry out procedures 1, 2, and 5 to 9 from Section 3 AO2.

#### 3000-3100 tractors

5. Disconnect the braided earth cable (from the cab support).

#### For tractors equipped with speedshift and speed limiting device :

6. Disconnect the harnesses from the speedshift solenoid valve and the limit switch.
7. Carry out procedure 9 from Section 5 KO1.
8. Carry out procedure 10 from Section 5 KO1.

#### **N.B.: Do not remove the pipe.**

9. Remove the harness guard attached to the RH side of the gearbox.
10. Disconnect the Hare/Tortoise harness.

#### 11. Remove:

- . the two sheet-metal guards over the solenoid valves on the RH hydraulic cover.
- . the 17 bar pipe from the hydraulic cover and from the gearbox connection.
- . the pipe supplying the orbitrol from the hydraulic cover.
- . the sheet-metal guard over the Autotronic unit.
- . the screen washer reservoir (as dictated by type).

#### **Disconnect:**

- . the earth cable from the selector cover.
- . the cable running from the radar (Datatronic).




12. Carry out procedures 3 and 4, Section 5 DO1.A (gearboxes with creeper gears)

#### 13. Immobilise the tractor:

- . apply the handbrake
- . fit wedges between the frame and the front axle (Fig.2)

#### 14. Position jacks:

- . at the front of the rear axle
- . at the rear of the hitch hook
- . at the rear of the gearbox (trolley jack).







## Splitting the tractor

15. Remove the bolts (1) through the shock absorbers on the RH and LH cab supports (Fig.3). Raise the cab **slightly**.
16. Support the cab under the RH and LH steps.
17. Unscrew the bolts securing the gearbox to the rear axle.
- N.B.: The bolts are of different lengths.**
18. Split the tractor between the gearbox and the rear axle (Fig.5).

### B. Refitment

19. Clean the mating faces of the gearbox and the rear axle centre housing.

#### At the rear axle

20. Fit:

- (gearboxes without creeper gears) shaft (1), with sleeves (2) and (7) connected to it by double pins (5) and (6), to differential pinion (3) (Fig.4a).
- (gearboxes with creeper gears) shaft (1), with sleeve (2) connected to it by double pin (5), to differential pinion (3) (Fig.4b).

**N.B.: Groove A in sleeve (2) should be towards the differential ring gear (4) (Fig.4).**




Fig. 4




Fig. 5



3B02.4

## Splitting the tractor

21. Check that spring (1) is present in the PTO clutch housing (Fig.6).
22. Check that locating pins (2) are present (pins are a force fit in housing) (Fig.6).
23. Check that the control finger is pointing forward (gearbox with creeper gears) (Fig.7).
24. Apply a gasketing compound, Loctite 510 or equivalent, to the mating face of the rear axle centre housing.
25. Screw two pilot pins (b) into the housing (Fig.6).

### At the gearbox

26. Replace the O-ring (1) in the Hare/Tortoise passages (Fig.8).
27. Unite the tractor between the gearbox and the rear axle.
28. Fit the connecting bolts and tighten them to a torque of 155 - 195 Nm.
29. Remove the supports under the steps.
30. Lower the cab, fit the bolts through the shock absorbers (1) (Fig.3), and tighten the bolts to a torque of 200 - 270 Nm.
31. Carry out procedure 14 in reverse.
32. Carry out procedures 30 and 31, Section 5 DO1.A (gearboxes with creeper gears)
33. Carry out procedures 5 to 11 in reverse.

### 3000 tractors




34. Carry out procedures 1 to 6, Section 3 AO1, in reverse.
35. Carry out procedures 1 and 2 in reverse.

### 3100 tractors

36. Carry out procedures 1, 2 and 6 to 9, Section 3 AO2, in reverse.
37. Carry out procedures 1 and 2 in reverse.

### 3000-3100 tractors

38. Bleed the clutch circuit, see Section 5 C01.G.
39. Check:
  - . that there are no leaks at the hydraulic unions
  - . that the electrical circuits are working.
40. Refit the sheet metal  
Take out the wedges between the frame and the front axle, release the handbrake.
41. **Carry out road test on:**
  - . clutch controls
  - . controls for creeper gears (if fitted).
42. Check that there are no leaks at the joint between the gearbox and rear axle.





## ***Splitting the tractor***

3C01.1

### *3 C01 Splitting the tractor between the front frame and the engine*

#### CONTENTS


A. <b>Uncoupling</b>	_____	<b>2</b>
B. <b>Recoupling</b>	_____	<b>3</b>




## Splitting the tractor

### A . Uncoupling

1. Disconnect the two 4WD front axle control hoses.
2. Remove the guard and the 4WD transmission shaft.
3. Remove the sheet metal panels.
4. Disconnect the earth cables only from the batteries.
5. Disconnect and mark the positions of hoses and flexible connections, as follows :
  - the two Orbitrol steering hoses,
  - the hose from the cooler on the 17-bar valve,
  - the harness for the flowmeter and its three hoses located to the left of the fuel filter (3000 series, according to option),
  - the connectors for the main harness above the engine,
  - the positive cable on the starter,
  - the inlet sleeve between the turbocharger and the air filter,
  - the suction pipe between the air filter and the exhaust pipe.
6. Drain the cooling system. Disconnect the lower and upper hoses from the radiator.
7. Remove the upper attachment on the radiator.
8. Remove the air conditioning compressor and bracket assembly and tilt it forwards with its two hoses (according to option).



9. Remove the front earth connections.
10. Immobilise the tractor. Apply the handbrake. Position wedges between the frame and the front axle (Fig. 1).
11. Loosen the bolts attaching the engine to the front frame.
12. Support the tractor under the frame using a trolley jack and separate the engine from the frame (Fig. 2).







## Splitting the tractor


3C01.3

### B. Recoupling

13. Screw two dowel pins (locally made) into diametrically opposite positions on the front frame.
14. Fit the frame to the engine.
15. Install the bolts and tighten to the specified torque:
  - 4 cyl. engines : see Fig. 3,
  - 8 cyl. engines : see Fig. 4.
16. Remove the wedges between the frame and the front axle.
17. If the tractor is equipped with a flowmeter, purge the injection pump supply system (4 cyl. engines).
18. Start the engine and check:
  - the hydraulic systems for any leaks,
  - the correct operation of the electrical systems.
19. Carry out procedures 1 to 3 in reverse order.
20. Carry out road test.









**ENGINE - General**

4A01.1

**4 A01 General**

**CONTENTS**

<b>A. Introduction</b>	<b>2</b>
<b>B. Main specifications</b>	<b>2</b>
<b>C. Viscostatic fan</b>	<b>3</b>





4A01.2

## 3000/3100 SERIES TRACTORS

**ENGINE - General****A. Introduction**

The purpose of this section is to provide general information about the engines used for the 3000/3100 range.

For all information on: technical data, adjustments and removal and fitting procedures, refer to one or other of the publication listed opposite :

1. Workshop manual for all types of Perkins engines manufactured for MF tractors, published by Massey Ferguson under reference 1856562 M1.
2. Workshop manual specifically for the 1000 series engines published by Massey Ferguson under the reference 1646906 M1.

**B. Main specifications**

	3050	3060	3065	3070	3080	3095	3115/20	3125 40
PERKINS Type	A 4.236	A 4.248 S	C 4.236	A T4 236	A 6.354 4	1006-6 HR	1006-6LR	1006-6T7
Number of cylinders	4	4	4	4	6	6	6	6
Turbocharger	-	-	yes	yes	-	-	-	yes
Bore (mm)	98,47	100,96	98,47	98,47	98,47	100	100	100
Stroke (mm)	127	127	127	127	127	127	127	127
Cubic capacity (cc)	3860	4060	3860	3860	5800	6000	6000	6000
Compression ratio	16 to 1	16 to 1	16 to 1	15,5 to 1	16 to 1	16,5 to 1	16,5 to 1	16 to 1
Max. DIN Power (Kw)	52	59	62,5	68,5	73,5	78,5	84,5	92,5
PTO power (Kw)	47	53	57	62	68	72	78	86
At engine speed of (rpm)	2200	2200	2200	2200	2200	2200	2200	2200
Maximum torque (Nm)	269	280	319	343	374	415	436	474
Engine speed at max. torque (rpm)	1400	1400	1400	1400	1200	1200	1100	1200
Idling speed (rpm)	850	850	850	850	850	850	850	850
Engine speed at max. power (rpm)	2200	2200	2200	2200	2200	2200	2200	2200
Max. no load speed (rpm)	2310	2310	2310	2310	2310	2310	2310	2310
Torque at max. speed (Nm)	230	260	276	303	325	348	367	401
Firing order	1 - 3 - 4 - 2			1 - 5 - 3 - 6 - 2 - 4				
Lubrication *	Gear type pump minimum pressure 2,1 bar at max. speed and normal running temperature							
Valves	Overhead push-rod operated							
Valve clearances	(cold)							
- Inlet (mm)	0,30	0,30	0,30	0,30	0,20	0,20	0,20	0,20
- Exhaust (mm)	0,30	0,30	0,30	0,30	0,45	0,45	0,45	0,45
Engine oil cooler	no	no	yes	yes	yes	no	no	yes

\* Turbocharged engines have piston cooling jets



## ENGINE - General

### C. Viscostatic fan

#### Description

The 1000 series engines are fitted with a cooling fan with an Eaton viscous coupling. This device increases power by 2 to 3hp.

The viscous coupling is made up of three main parts:

- The driving part powered by the engine and composed of shaft (1) integral with plate (2) with annular grooves.
- The driven part composed of hub (6) on which are mounted the fan and body (7) also with annular grooves.
- The regulating part composed of thermostatic spring (3) controlling valve (4).



The centre of the device has a reservoir (5) filled with a viscous silicone fluid.

#### Method of operation

When the temperature of the air going through the radiator reaches a predetermined value, thermostatic spring (3) acts on valve (4) which opens orifice a. The liquid is driven towards the annular grooves on hub (2) and body (7) by centrifugal force. The torque is transmitted by the internal friction of the very viscous fluid and its adhesion to the walls. The fan is thus driven, thereby increasing airflow and overall cooling efficiency.

The speed of the fan varies continually over the whole regulatory range depending on the temperature.

When the temperature of the air going through the radiator decreases, the spring closes the valve and stops the liquid from coming into contact with the friction area. The fluid gradually returns to reservoir (5) via pipe b. The fan is disengaged, leaving only a slight residual torque.





**ENGINE - Adaptor plate**

*4 B01 Engine adaptor plate*

CONTENTS

A. 3000 Tractor with 6 cylinder engine	2
B. 3100 Tractor engine	3



4B01.2

## 3000/3100 SERIES TRACTORS



# ENGINE - Adaptor plate

### A. 3000 Tractor with 6 cylinder engine

#### Disassembly

1. Split the tractor between the engine and the gear-box. Chapter 3 A01.
2. Remove the engine clutch. Chapter 5 B01.A.
3. Remove the starter motor attaching bolts. Withdraw the starter motor without disconnecting the cable.  
**Note: Support the starter motor by suspending it to avoid its weight damaging the cable.**
4. Remove the flywheel, chapter 5B01.B.
5. Remove two attaching bolts from the engine adaptor plate.
6. Screw two dowel pins into the holes vacated by the two bolts (two bolts can be used).
7. Remove the five bolts and the engine adaptor plate.

8. Remove the locating dowels.


9. Withdraw the three starter motor attaching studs on the engine adaptor plate.

#### Reassembly

10. Clean the flanges between the engine and the adaptor plate.
11. Carry out procedures 8 and 9 in reverse.
12. Carry out procedures 6 and 7 in reverse.
13. Fit the seven adaptor plate bolts on the engine. Tighten to the torque shown.
14. Carry out procedures 1 to 4 in reverse.

#### Tightening torque

(1) to (7) 39-53 Nm





## ENGINE - Adaptor plate

### B. 3100 Tractor engine

#### Disassembly


1. Split the tractor between the engine and the gearbox. Chapter 3 A02.
2. Remove the engine clutch. Chapter 5 C01.A.
3. Remove the starter motor attaching bolts. Withdraw the starter motor without disconnecting the cable.  
**Note : Support the starter motor by suspending it to avoid its weight damaging the cable.**
4. Remove the flywheel, chapter 5C01.B.
5. Remove two attaching bolts from the engine adaptor plate.
6. Screw two dowel pins into the holes vacated by the two bolts (two bolts can be used).
7. Remove the five bolts and the engine adaptor plate.
8. Remove the locating dowels.
9. Withdraw the three starter motor attaching studs on the engine adaptor plate.

#### Reassembly

10. Clean the flanges between the engine and the adaptor plate.
11. Carry out procedures 8 and 9 in reverse.
12. Carry out procedures 6 and 7 in reverse.
13. Fit the seven adaptor plate bolts on the engine. Tighten to the torque shown.  
**Note: Do not insert a bolt into hole A.**
14. Carry out procedures 1 to 4 in reverse.

#### Tightening torques

- (1) to (6) 50-70 Nm  
(7) 100-130 Nm







# 5 . GEARBOX

## Contents

### SPEEDSHIFT GEARBOX

- 5 A01 TRANSMISSION ASSEMBLY
- 5 A02 DISASSEMBLY AND REASSEMBLY
- 5 B01 PUSH-TYPE CLUTCH (3000)
- 5 C01 PULL-TYPE CLUTCH (3100)
- 5 D01 SELECTOR RAIL AND FORKS
- 5 E01 INPUT UNIT
- 5 E02 SPEEDSHIFT
- 5 E03 REVERSE SHUTTLE
- 5 F01 A/B RANGE GEARS AND SYNCHROMESH  
MECHANISM
- 5 G01 MAINSHAFT
- 5 H01 LAYSHAFT
- 5 I01 OUTPUT SHAFT
- 5 J01 CREEPER GEARS
- 5 J02 SUPER CREEPER GEARS
- 5 K01 SELECTOR COVER (4 X 4)
- 5 K02 SELECTOR COVER (4 X 2)
- 5 K03 ADJUSTING SELECTOR COVER
- 5 L01 SPACER
  
- 5 M01 16<sup>TH</sup> GEAR LOCKOUT (3100)

### DYNASHIFT GEARBOX

- 5 D01 SELECTOR RAIL AND FORKS
  
- 5 J01 CREEPER GEARS
  
- 5 L02 SPACER
- 5 M01 16<sup>TH</sup> GEAR LOCKOUT (3100)
- 5 N01 DYNASHIFT TRANSMISSION ASSEMBLY
- 5 P01 PUSH-TYPE CLUTCH (3000)
- 5 Q01 PULL-TYPE CLUTCH (3100)
- 5 R01 INPUT UNIT
- 5 R02 DYNASHIFT INPUT UNIT
- 5 R03 REVERSE SHUTTLE
- 5 S01 MAINSHAFT
- 5 T01 LAYSHAFT
- 5 V01 OUTPUT SHAFT
- 5 X01 SELECTOR COVER



## Gearbox

### 5 A01 Transmission assembly

#### CONTENTS

A. General description	_____	2
B. Gearbox assembly	_____	2
C. Main gearbox	_____	5





5A01.2

## 3000/3100 SERIES TRACTORS



# Gearbox

### A. General description

The 3000 and 3100 series tractors have a transmission which consists of five main housings :

- the gearbox assembly, which also serves as a clutch housing.
- the centre housing which includes the differential assembly, the power take off line and 4 wheel-drive clutch. It also holds the side hydraulic covers.
- the axle housings right and left.
- the lift cover.

These five parts are common to the whole series 3000 and 3100 range. The models fitted with 6 cylinder engines have an adapter plate located between the engine and gearbox.

#### Clutch

The clutch is a single-plate unit. The mechanism has a diaphragm which is hydraulically operated by a piston. For the 3000 models, the operating system is pushed and for the 3100 models it is pulled.

A shaft driven by a splined hub connected to the engine flywheel passes through the gearbox assembly and transmits rotation to the power take-off clutch. The power take-off clutch housing drives the hydraulic pump via drive gear.

### B. Gearbox assembly

#### Main box

The main gearbox has eight basic speeds(2x4). It consists of a train of four gears to which a set of two gears is added so that a slow (Tortoise) range and a fast (Hare) range can be obtained.

All the gears are in constant mesh and the speeds are selected by synchro-mesh units, except the Hare/Tortoise range. These eight speeds can be selected with a single lever.

#### Reverse gear assembly and A/B range

This consists of an assembly of two sets of gears placed in front of the main box; one driving, fitted on a hollow shaft, the other driven, fitted on the main box countershaft. The two ranges are selected by two synchro-mesh units operated by the reversing gear lever when it is moved to the neutral position. With this layout, the number of speeds can be doubled and 16 forward and reverse speeds can be obtained.

With a compound gear cluster located between the hollow shaft and the countershaft, the direction of rotation of the countershaft can be reversed.

In reverse, speed is :

- . 7% faster than in forward in range A
- 7% slower than in forward in range B

#### Speedshift

In addition to the main box and the reversing assembly, by means of a hydraulic device with an epicyclic train placed before the reversing gear, operated by a solenoid, two input speeds can be added, taking the number of possible speeds to 32.



#### Creep gear housing

By means of a housing fitted on the output shaft, after the main box, a range of greatly reduced travel speeds can be obtained. This housing consists of an epicyclic type reduction gear, with a ratio of 4:1, driven mechanically, which should be engaged only if the main box is in the slow (Tortoise) position.





**TRANSMISSION ASSEMBLY WITH 4X4 BOX**  
**(Longitudinal section)**



Pressure lubrication




Splash lubrication



4 x 2



5A01.3





## Gearbox

### C. Main gearbox

#### General

In order, the gearbox housing has the following major components:

- the engine clutch operating device.
- the input housing enclosing the speedshift (if fitted) and the reverse gears.
- the main gearbox.
- the creeper gear housing (if fitted).

We will restrict ourselves to describing only the main box, as each major component is covered by an individual description in the section dealing with it.

#### Construction

The main gearbox has four synchro-mesh speeds. With a gear fitted free running on the output shaft, to which it can be locked by a coupler, the initial four speeds can be doubled to obtain the basic eight speeds. The mainshaft and layshaft are supported by taper roller bearings. The output shaft is fitted in two taper roller bearings and one needle roller bearing. All the gears are helical and in constant mesh.

The lubricating oil comes from the front housing and passes through an oilway drilled along the centre line of the mainshaft and output shaft. Radial oilways direct oil to the various different lubrication points of the gears, bearings and bushes.

The top shafts are lubricated by the film of oil circulating between the PTO shaft and the layshaft. This film lubricates the end taper roller bearings and the needle roller bearing (62). Radial oilways in the shaft (54) and radial recesses on the driven gear make oil pass between all the gears. The contact area between teeth of the shaft (54) and the gear (36) is also lubricated by a radial hole drilled in the shaft. To ensure correct operation according to the forces to which the transmission is subjected, the bearings are fitted with preload (in the case of the mainshaft) or with end float (in the case of the layshaft). The output shaft can be shimmed with either a small amount of play or light preload.

#### Description

In the 16 speed (4x4) version, the main gearbox drive is taken by gear (67) or (76), locked to the mainshaft (69) by the action of the synchromesh device (78) (see section 5 F01).

In the case of an 8 speed gearbox (4x2), gear (67) is fitted on shaft (69) by means of splines.

The two hubs of synchro-mesh devices (11) and (23) are locked to the mainshaft (69) by splines. The 1st

speed driving gear (7) is fitted free-running on a bush (8), the 2nd speed driving gear (14) and 3rd speed driving gear or 4th speed driving gear (4x2) (18) are fitted free running on the shaft direct. The 4th speed driving gear or 3rd speed driving gear (4x2) (29) is fitted on needle roller bearings (28) and (30). These act as axial thrust bearings. The hub (33) of coupler (31) is solid with the output shaft (44).

Driven gears (55), (56), (59) and (60) drive the layshaft (54) by splines. The teeth of shaft (54) is in constant mesh with the Tortoise gear (36), fitted free-running on the output shaft.

#### Operation

##### Low (Tortoise) range

This speed is engaged by moving one of the couplers of the synchro-mesh devices (11) and (23) to link in rotation the countershaft (69) with one of the 4 gears fitted free-running. Which ever gear is selected, the movement is transmitted to the layshaft (54). The output shaft (44) is driven by the layshaft machined teeth in constant mesh with the free-running gear (36) solid with the output shaft by moving the coupler (31) of hub (33) back.

##### High (Hare) range



This range is selected by moving forward the coupler (31) which puts the driving gear (29) and the output shaft in direct mesh.

Therefore, in 4th speed (4x4) and in 3rd speed (4x2), the layshaft (54) is non-functional. The other speeds are obtained by movement of the couplers of the synchro-mesh devices (11) and (23) as in the Tortoise range. Movement is transmitted to the output shaft (44) by driven gears (55) and (29).




# Gearbox

## 16-SPEED (4X4) MAIN GEARBOX



Position of the synchro-mesh devices.





## Gearbox

### Synchromesh units (Fig. 1)

#### Locking position

The axial displacement of the coupler (A) presses the synchro brake (B) against the friction cone of the flange (C) via the balls (D) and pressure elements (E). The speed difference existing between the parts to be coupled creates a radial rotation limited by the pressure elements (E) which, in turn, cause pressure of the chamfered teeth of the synchro brake (B) against the coupler (A), opposing any relative displacement of the latter. The pressure exerted by the coupler (A) and the angular staggering of the synchro brake (B) create axial pressure between the friction cones of the synchro brake (B) and the flange (C), via the chamfers of the teeth, this axial pressure establishing synchronisation by the progressive reduction of the speed difference of the parts to be coupled.

Synchronisation having been established, the persisting pressure exerted by the coupler (A) against the synchro brake (B) causes the latter to go back until the teeth of the coupler (A) are in front of the tooth spaces of the synchro brake (B). At this moment, the resistance which has, so far, been opposing displacement of the coupler (A) during shifting of the speed is overcome and the coupler (A) can then engage noiselessly with the teeth of the flange (C) of the gear to be engaged. The rigid connection between the shaft and the gear is established and the speed is shifted.

If, during shifting of the speed, the two elements come up against each other, tooth-to-tooth, the chamfers provided on the tooth flanks move the gear to be engaged until each tooth is in front of a tooth space.

#### Neutral position

The coupler (A) is in the middle position. The balls (D) are pushed back into the «V» groove of the coupler (A) by the pressure springs (F). The gear can turn freely on the shaft.

#### Overhaul

In the event of removal of the synchro-mesh units (11), (23) and (78) or the reversing gear, check the wear of the brakes (B).

Place the flange (C) on a flat surface.

Correctly position the brake (B) by turning it through several revolutions and applying hand pressure to it. Using a set of gauges, measure dimension X at several places (Fig. 2). If it is less than 0.8 mm, fit a new synchro brake (B), after checking the cone.

If new synchro brakes are being fitted, measure dimension X, which must be within the following limits:

- 1st/2nd speed synchro (11) = 0.9 to 1.5 mm
- 3rd/4th speed synchro (23) = 0.9 to 1.5 mm
- A/B speed synchro (78) = 1.1 to 1.6 mm
- Reversing gear synchro = 1.4 to 2.1 mm

**Note: the Hare/Tortoise synchro-mesh unit was replaced by a coupler from serial number V252037. For tractors earlier than this number, refer to workshop manual 1646640 M1.**




Fig. 1




Fig. 2



## Gearbox

### 5 A02 Disassembly and reassembly

#### CONTENTS

General	2
A. Gearbox assembly - Removal and preparation	2
B. Shifter rail mechanism cover - Removal	3
C. Shifter rail and forks - Disassembly	3
D. Input shaft housing - Removal	5
E. Layshaft - Disassembly	6
F. Creeper gearbox - Removal	7
G. Output shaft - Disassembly	7
H. Mainshaft: 4 x 2 gearbox	8
J. Mainshaft: 4 x 4 gearbox	9
K. Mainshaft: 4 x 4 gearbox - Reassembly	10
L. Mainshaft: 4 x 2 gearbox - Reassembly	13
M. Output shaft - Reassembly	14
N. Creeper gearbox - Refitment	17
P. Layshaft - Reassembly	17
Q. Input shaft housing - Refitment	18
R. Shifter rail and forks - Refitment	20
S. Selector cover mechanism housing (4 x 2 and 4 x 4) - Refitment	24
T. Gearbox assembly - Preparation and refitment	26
U. Service tools	26
- 4 x 4 gearbox - Key to diagram	31
- 4 x 2 gearbox - Key to diagram	33





5A02.2





# Gearbox

## General

This section concerns the procedures which require the gearbox to be completely disassembled. In these cases, the complete gearbox is removed from the tractor and placed on a work bench. For those procedures which can be carried out with the gearbox fitted to the tractor, see Sections 5 D01 to 5 M01.

### A. Gearbox assembly - Removal and preparation

1. Split the tractor between the gearbox and the rear axle (See 3 B02).
2. **3000 Tractor:**  
Place a sling under the gearbox (Fig. 1). Split the tractor between the gearbox and the engine (See 3 A01 Procedures 11 and 12). Remove the PTO shaft (1), Fig. 1).
2. **3100 Tractor:**  
Place a sling under the gearbox (Fig. 1). Separate the gearbox from the engine (See 3 A02 Procedures 3, 4, 13 and 14). Remove the PTO shaft (1), (Fig. 1).
3. (Fig. 2) Remove:
  - the PTO clutch hydraulic feed pipe (1),
  - the engine clutch slave cylinder supply pipe (2),
  - the T-piece (3) and 1.5 bar valve (4),
  - the 90° oil return pipe connection (5),
  - the Datatronic sensor and its bracket (6) (if fitted),
  - the LH cab support (7)
4. Lay the gearbox on its LH side and lift it on to a suitable stand or work bench (Fig. 3).





## Gearbox

### B. Selector cover - Removal

**Note:** Remove the A/B range (4 x 4 gearbox) feed pipe (1) (17 bar) (Fig.4).

5. Remove the bolts (2). (Fig. 4)

**Note:** On gearboxes fitted with a creeper range, remove the control cable bracket and mark the position of the centring bolt /3/.

6. Remove the cover (4) and bolt (5). (Fig. 4)




Fig. 5

### C. Shifter rail and forks - Removal

**Note:**

1) Gearbox fitted with creeper range.

Remove the pin (1), the locknut (2), the adjustable setscrew (3), the fork (4) with the sleeve (5). (Fig.5)

2) A mechanical locking device for the Hare/tortoise range cut into production from serial

number P107048. For tractors prior to this number, see Workshop Manual 1646640 M1

7. Remove the plugs (1), the springs (2) and locking plungers (3) from forks (5) and (6) (Fig.6)




Fig. 6






5A02.4


## Gearbox

8. Slacken the castellated nut (21) using spanner 3615334 M01 (Fig.7).
9. Engage 4th gear (4 x 2 gearbox) or 3rd gear (4 x 4 gearbox).
10. Release the cone (24) on the shifter rail (7) using a bronze drift (Fig.8).
11. Remove the setscrew (8).
12. Eject the plug (9) forwards by tapping the end of the rail (7) (Fig. 9).
13. Remove:
  - the bearing (15)
  - the shifter rail (7) rearwards
  - 1st and 2nd gear fork (5) and 3rd and 4th gear fork (6)
  - the lock assembly (25)
14. Disassemble:
  - the castellated nut (21)
  - the latch (22)
  - the tapered bearing (23)Remove:
  - the screws (19)
  - the piston (13)
  - the High/Low range fork (20)
  - the bolt and washer assembly (17) and the guide (18)
  - the cylinder (10)

**Note: Discard the seals (12) and (14) from piston (13) and the seal (11) from the cylinder (10).**

**The A/B fork (4) stays in the housing (4 x 4 gearbox).**










## Gearbox

### D. Input shaft housing - Removal

15. Immobilise the layshaft assembly using the locally made-up tool (See Section U) (Fig. 10).
16. Remove the drain pipe (1) from the clutch slave cylinder and the union (2) on the housing (Fig. 11).
17. Place a sling under the housing assembly, taking care to avoid damaging the needle roller bearing (4) (Fig. 12).
18. Remove the eight 10 mm diam. bolts (3) (Fig. 11).  
**Note: It is not necessary to remove the selector (5) (Fig. 13) in order to remove the housing.**
19. Release and withdraw the housing assembly by tilting it to the left (Fig 12).  
**Note: (Fig.13 and 14) Retrieve the locating dowel (8). Discard the oil seals (6) and (7).**





# Gearbox

## E. Layshaft - Disassembly

- 20. Withdraw the layshaft complete (Fig.15).
- 21. Remove the washer (50). See page 32.
- 22. Remove the shims [51]. See page 32.
- 23. Remove the cup (52).  
**Disassembly of shaft (54) (Fig.16). A new shaft fitting was introduced from serial number P345012 (version b). Tractors prior to this number are fitted with version a.**
- 24. Withdraw the taper roller bearings (53) and (63).  
**Note: Keep the bearings and cups in matched pairs for possible re-use.**
- 25. Remove the circlip (61).
- 26. a) Remove 1st gear (60) and 2nd gear (59).  
 b) Remove 1st gear (60), the shims [58] and 2nd gear (59).
- 27. a) Remove circlips (58) and (57) (Fig.16).  
 b) Remove spacer (57)
- 28. Remove 4th gear (56) (4 x 2 gearbox) and 3rd gear (55) (4 x 2 gearbox)
- 29. Remove 3rd gear (56) (4 x 4 gearbox) and 4th gear (55) (4 x 4 gearbox).
- 30. Drift out the needle roller bearing (62) (Fig.17) and discard it.




Fig. 16




Fig. 15




Fig. 17



## Gearbox

### F. Creeper gearbox - Removal (Fig.18)

31. Remove the bolts (1).
32. Remove the creeper gearbox assembly (2).  
**Note:** The locating dowels (3) are held in the gearbox.




Fig. 18

### G. Output shaft - Disassembly

**Note:** If the tractor is fitted with a creeper gearbox, see above.

33. Remove the 3 bolts (41) (see page 32).
34. Remove the lock plate (46).
35. Remove the bearing cup (48).  
**Note:** Keep the bearings and cups in pairs for possible re-use.
36. Remove the circlip (45).
37. Remove the spacer (43) and shims (42).
38. Remove the taper roller bearing (40).  
**Note:** Where shims have had to be inserted between bearings, remove the shim adjuster(s) (47)
39. Remove the roller bearing (39).
40. Remove the shims (38).  
**Note:** On all types, the High/Low range synchromesh has been replaced by a coupler from serial number V252037. For tractors prior to this number see Workshop Manual 1646640 M1.
41. Engage the High/Low range coupler (31) (Fig. 19) on the Low range pinion (36)
42. Withdraw the shaft (44) rearwards.
43. Remove the circlip (34) using tool MF 460 and discard it (Fig. 19 and 20).
44. Remove the shaft.
45. Through the inspection panel in the selector rail mechanism cover, withdraw: the hub (33) and its coupler, the gear (29) (3rd gear 4 x 2 gearbox and 4th gear 4 x 4 gearbox), the synchromesh cup (25), the two thrust washers (32)-(27) and the Low range gear (36).
- Note:** Keep the synchro cup (25) with the pinion (29) for possible re-use.
46. Remove the cup (37).
47. Remove the circlip (49).
48. Remove the circlip (19), the washer (22) and the needle roller bearing (24)




Fig. 19




Fig. 20



5A02.8

## Gearbox

### H. Mainshaft - 4 x 2 gearbox - Disassembly

- 49 Remove the circlip (26).
- 50 Remove 3rd and 4th gear synchromesh (23). Mark the direction of fitting.
- 51 Remove the synchromesh cup (21)
- 52 Remove the synchromesh cone (20) and the gear (18).  
**Note: Retain the synchromesh cup and cone as a pair for possible re-use.**
53. Position MF 458 locking tool (Fig.21) and the locally manufactured retainer sleeve for the mainshaft (69) (Fig.22) (See Section U).
- 54 Remove the oil feed pipe (71) and spring (72).
55. Unlock the nut (68) and slacken it using tool 3376805 M1 (Fig.23).
- 56 Remove the input shaft gear (67) and cone (1).
- 57 Remove the washer (6).
- 58 Remove tool MF 458 and the sleeve (Fig.21 and 22)
- 59 Withdraw the shaft from the housing rearwards retaining 1st and 2nd gear train in place.
- 60 From inside the housing remove, in the following order, 2nd gear (14), cone (13), 2nd gear synchromesh cup (12), 1st and 2nd synchromesh (11), cone (9), synchromesh cup (10), 1st gear (7) and its bush (8).
- 61 Withdraw the bearing cups (16) and (2).  
**Note: Retain the cups and cones as a pair for possible re-use.**
- 62 Remove the shims [3], the shim /4\ and circlips (15) and (5).  
**Note: Make a note of the thickness of the shims for use on the mainshaft during reassembly.**
63. Remove the bearing cone (17) and circlip (70) from the shaft.




Fig. 21




Fig. 22




Fig. 23



## Gearbox

### J. Mainshaft - 4 x 4 gearbox - Disassembly

64. Carry out procedures 49 to 54 in Section H.  
65. Remove the lock from the nut (68) and slacken the nut using spanner MF 456 (Fig. 24)

**Note: A new A/B range synchromesh assembly fitted with sintered cone rings was introduced from the following tractor serial numbers:**

- 40 kph tractors: P089036
- 30 kph tractors: P297030

66. Remove the spur washer (73), B gear (76) with the needle roller bearing (75) and bush (74)  
67. Slacken the two screws (1) attaching the pads (2) to the A/B fork (3) (Fig. 25).  
Remove the A/B synchromesh (78) and the cups (77) and (80).

**Note: Take care not to remove the synchromesh hub sliding block.**

68. Move the A gear (67) slightly forwards to disengage the fork.  
69. Remove the fork.  
70. Withdraw the A gear (67) with the double needle roller bearing (79) and the bush (81).  
71. Remove the sleeve (82) and the bearing cone (1).  
72. Carry out procedures 57 to 59.  
73. Remove the 1st and 2nd gear train complete (Fig. 26).  
74. Carry out procedures 61 to 63




Fig. 24




Fig. 25




Fig. 26





5A02.10

## Gearbox

### K. Mainshaft - 4 x 4 gearbox - Reassembly

75. The gearbox housing must be clean and free from swarf.
76. Mating faces must be scraped clean.
77. Use a jet of compressed air to check that all the hydraulic oilways in the gearbox and shafts are free of obstructions.
78. If the gearbox is fitted with Speedshift, fit the solenoid valve (1) and tighten to a torque of 18-20 Nm (Fig.27).
79. Fit the T-piece (2) for the A/B feed pipe (Fig.27).
80. Examine all parts for wear and discard any which are faulty.
81. Before assembling lightly lubricate the cones, cups, bearing bores, bushes, gaskets and needle roller bearings.
82. Using a press, fit the bearing cone (17) on to the shaft (69).
83. Fit the circlip (70).
84. Fit the circlips (5) and (15).
85. Refit the shim (4).  
**Note: (Fig.28) Position the shim (4) on the circlip (5) side.**
86. Reduce the thickness of the shims [3] whose measurement was noted on disassembly (Section H Operation 62) by approximately 0.3 mm to obtain a shaft end play of 0.10 to 0.15 maximum to obtain an exact fit.
87. Fit the shims [3] and cups (2) and (16).
88. Assemble 1st gear (7) and its bush (8), the lock plate (9), the 1st gear synchromesh cup (10), the 1st and 2nd gear synchromesh (11), the 2nd gear synchromesh cup (12), the cone (13) and the 2nd gear (14).
89. Refit the 1st and 2nd gear train assembly between the two partitions.
90. Insert the shaft through the rear of the housing retaining the synchromesh/gear assembly (Fig.29).  
**Note: Check that the bush (8) is correctly positioned in the gear (7).**




Fig. 27




Fig. 28




Fig. 29



## Gearbox

91. Fit the locking tool MF 458 and the locally made retaining sleeve (Fig.30 and 31).
92. Fit the washer (6)
93. Using a press, fit the bearing cone (1) on the sleeve (82).
94. Fit the sleeve on the shaft.  
**Note: To shim using formula P1, do not fit the A/B gear train (Fig.32).**
95. Fit the bush (81), the A/B synchromesh (78), the bush (74) and the spur washer (73) on the shaft.
96. Fit nut (68) and tighten to a torque of 80-100 Nm using tool MF 456 (Fig.32).

### Method of shimming

97. Carry out Procedures 98 to 108 to obtain a preload (Fig.33) of **P1= minus 0.14mm to minus 0.20mm** (0.0055in to 0.008in)
98. Remove tool MF 458 and the sleeve (Fig.30 and 31).




Fig. 30




Fig. 31




Fig. 32




Fig. 33



## Gearbox

99. Position a dial gauge pointer at the end of the shaft (Fig.34).
100. From the front of the housing, while pulling on the shaft, turn it first to the right then to the left so that the cones bed properly into the cups.
101. Zero the dial gauge.
102. Repeat operation 100 by pushing on the shaft.
103. On the basis of the dial gauge reading; select the shim thickness required to obtain P1.
104. Fit tool MF 458 and the locally made-up sleeve (Fig.30 and 31).
105. Reverse procedures 95 and 96.
106. Remove the sleeve (82) and its cone (1).
107. Withdraw the cup (2).
108. Position the adjusting shims [3] which were selected in operation 103.

**Note: Position the shim /4/ on the circlip (5) side (Fig.28).**

109. Fit the cup.
110. Fit the sleeve.
111. Slide the A gear (67) on to the shaft with the bush /81\ (stepped side facing the synchromesh) and the double needle roller bearing (79) inserting the A/B fork into the housing (Fig.35).

**Note: Use the shifter rail to retain the fork (Fig.36).**

112. Locate the synchromesh cup (80) and A/B synchromesh (78).
113. Position the pads (1) and (2) for the fork (3). coat the screws (4) and (5) with Loctite 241 and tighten them by hand (Fig.37 and 38).

**Note: Check that the pads move freely in the synchromesh sliding coupling.**




Fig. 34




Fig. 35




Fig. 36




Fig. 37



## Gearbox

114. Slide the B gear (76) on to the shaft with the cup (77), the bush (74) and the needle roller bearing (75).

**Note:** Rotate gear A (67) and B (76) from right to left to ensure that the synchromesh cups are correctly positioned (80) (77).

115. Fit the spur washer (73).

**Note:** The oil grooves should face the B gear.

116. Using a solvent degrease the shaft thread.

117. Lightly coat the nut (68) with Loctite 241 then tighten to a torque of 80-100 Nm.

118. Lock the nut by flattening the collar with a suitable drift punch (Fig.39).

119. Insert the spring (72) and the oil feed pipe (71) into the shaft.

120. Remove tool MF 458 and the retaining sleeve (Fig. 30 and 31).

121. Fit the gear (18) and the synchromesh lock plate (20), the brake (21) and 3rd and 4th gear synchromesh (23).

122. Fit the circlip (26).

**Note:** Check that the synchromesh faces the correct way.

123. Manually check:

- a) gear end play
- b) shaft and gear train rotation

124. Check that 1st and 2nd gear and A/B gear synchromesh function correctly.




Fig. 38




Fig. 39

### L. Mainshaft - 4 x 2 gearbox - Reassembly

125. Carry out procedures 75 to 78 and 80 to 87.

126. Assemble the following in the order shown in the housing: 1st speed gear (7) and its bush (8), the cone (9), 1st gear synchromesh cup (10), 1st and 2nd gear synchro (11), 2nd gear synchro cup (12), cone (13) and 2nd gear (14).

127. Carry out procedures 90 to 92.

128. Press the bearing cone (1) on to the gear (67).

129. Fit the gear (67) on to the shaft (69).

130. Fit the nut (68) using special tool 3376805 M1. Tighten to a torque of 80-100 Nm (Fig.40).




Fig. 40



5A02.14

## Gearbox

131. Carry out procedures 97 to 103.
132. Fit tool MF 458 and the retaining sleeve (Fig.30 and 31).
133. Remove the lock from the nut.
134. Remove the gear.
135. Carry out procedures 107 to 109.
136. Refit the gear.
137. Carry out procedures 116 to 123.
138. Check that 1st and 2nd gear synchromesh functions correctly.

### M. Output shaft - Reassembly

139. Fit the circlip (49) and the bearing cup (37).  
**Note: The High/Low range synchromesh has been replaced by a coupler from serial no. V252037.**  
**For tractors prior to this number see Workshop Service Manual 1646640 M1.**
140. Refit the needle roller bearing (24), washer (22) and circlip (19) on to the shaft (44). Insert the shaft into the housing without the gears.
141. Slide the bearing cones (39) and (40) on to the shaft.

### J3 shimming

142. The aim of this procedure is to prepare J3 shimming (Fig.41). Hold the cones (39) and (40) against the step in the shaft (44) using hand pressure.  
Take up the clearance Y between the rear of cone (40) and the groove for the circlip (45) with shim adjuster [42] and spacer /43\'. Select a new circlip of a size that fits snugly into the groove (Fig.42).
143. Shim to obtain (Fig.43):  
**J3 = minus 0.05 to plus 0.05**  
The aim of this procedure is to take up the play between the cones (39) and (40) and the cups (37) and (48) while keeping the above-mentioned shimming tolerance.
144. Fit the circlip (45).  
**Note: Position the spacer on the circlip side.**
145. Fit the cup (48) and the lock plate (46).
146. Tighten the bolts (41) to a torque of 27-32 Nm.




Fig. 41




Fig. 42




Fig. 43



## Gearbox

5A02.15

147. Position the dial gauge pointer at the end of the shaft (44) (Fig.44).

**Note: For gearboxes fitted with the creeper range, use the gearbox plate (Fig.45) instead of the lock plate. Tighten the bolts to a torque of 34-52 Nm.**

148. Push on the shaft and turn it to right and left so that the cones bed correctly into the cups.

149. Zero the dial gauge.

150. Carry out procedure 148 but pull on the shaft.

151. If end play exceeds 0.05 mm select the number of shims X [47] to obtain:

**J3 = minus 0.05 to plus 0.05**

**Important: The shim(s) X [47] selected for J3 should be fitted between the cones for the following shimming procedures.**




Fig. 44

### J4 shimming

152. Remove the circlip (45).

153. Remove the shim /43\ and the shim adjusters [42].

154. Measure the thickness Y of all the shims [42] and /43\ (this measurement will be useful for J5 shimming).

155. Remove the bolts (41) and the lock plate (46).

156. Remove the cup (48), the cones (40) and (39) and the shaft (44).

157. Assemble in the housing : the Low range gear (36), the coupler (31), the hub (33), the thrust washer (32), the 4 x 4 gearbox 4th gear/4 x 2 gearbox 3rd gear (29) with its combined needle roller bearings (30) and (28), the thrust washer (27) and the synchromesh cup (25).

**Note: If the bush (35) is worn, replace the gear assembly (because the bush is bored out after it has been fitted).**

**If the combined bearings (30) and (28) are worn, replace the gear assembly (it is factory fitted).**

158. Engage the input shaft (44) retaining the gear train assembly (Fig.46) .

159. Gently pull the shaft rearwards to expose the circlip (34) groove.




Fig. 45




Fig. 46



5A02.16

## Gearbox

160. Fit the circlip (34) using tool MF 459 (Fig.47).  
**Note: Check that the circlip is correctly fitted.**
161. Slide the following on to the shaft: the cone (39), the shim(s) X [47] selected in operation 151, the cone (40) and the cup (48).
162. Fit the lock plate (46). Tighten the bolts (41) to a torque of 27-32 Nm.
163. Fit shims to obtain (Fig.48) :  
**J4 = plus 0.20 to plus 0.40**  
 This shimming procedure produces end play on the gear (29) (4th Low 4 x 4 gearbox) (3rd Low 4 x 2 gearbox).
164. Carry out procedures 147 to 150.
165. On the basis of the reading obtained on the dial gauge select the thickness of shims Z [38] to obtain J4.
166. Remove the bolts (41) and the lock plate (46).
167. Remove the cup (48).
168. Withdraw the cones (40) and (39) and the shim(s) X [47].
169. Slide the following on to the shaft: the shims Z [38], the cone (39), the shim(s) X [47] and the cone (40).

### J5 shimming

170. (Fig.49) Shim to obtain:  
**J5 = Zero play**  
 The aim of this shimming procedure is to lock the cones (40) and (39) on to the shaft (44).
171. From the thickness of shims Y [42] /43\, selected in operation 154, deduct the thickness of shims Z [38] and X [47] to obtain:  
**J5 = Y - (Z+X).**
172. Carry out procedures 145 and 146.
173. Slide the number of shims selected in operation 171 on to the shaft.
174. Fit the circlip (45).  
**Note: Position the shim /43\ on the circlip side.**  
 The circlip must be a snug fit in its groove. Check that it is correctly positioned.  
**Note: Refit the creeper gearbox (optional fit). See Section N.**
175. Check the shaft and gear train rotation manually.
176. Check that the 3rd and 4th speed synchromesh and the High/Low range coupler operate normally.





Fig. 48




Fig. 49



## Gearbox

### N. Creeper Gearbox - Refitment (Fig.50)

177. Position the lock plate (1) and the ring gear (2) on the housing.
178. Attach the friction washers (3) and (4) to the planetary carrier (5) using «Amber Technical» grease.
179. Slide the pinion carrier on to the output shaft.
180. Position the cover plate (6).
181. Fit the bolts (7) and tighten to a torque of 34-52 Nm.




Fig. 50

### P. Layshaft - Reassembly

A new designed shaft was introduced from serial no. P345012 (version b). Tractors prior to this are built using version a.

182. Fit the needle roller bearing (62) against the shoulder on the shaft (54) using a press (Fig.51).  
**Note: Check that the needle roller bearings turn freely in the cage.**
183. a) Carry out procedures 25 to 29 in reverse order.  
**Note: Ensure that the circlips fit easily into their grooves.**  
**The gap J1 is calculated according to machining tolerances (Fig.52).**  
b) Carry out procedures 28 and 29 in reverse. Slide the spacer (57) on to the shaft. Fit the 2nd gear (59), the 1st gear (60) and the circlip (61).

Using a set of shims, measure the space between the 1st gear (60) and the 2nd gear (59). On the basis of the measurement, select a thickness of shims to obtain (Fig.52):

**J1 = 0 to plus 0.25**

Remove the circlip (61) and the gear (60).

Slide the shims already selected on to the shaft.

Fit the gear and the circlip.

**Note: Ensure that the circlip is correctly fitted.**




Fig. 51




Fig. 52





5A02.18

## Gearbox

184. Using a press, fit the bearing cones (63) and (53) holding the assembly in a suitable jig (Fig.53).  
185. Carry out procedures 23 and 20 in reverse.

### Q. Input shaft housing - Refitment

186. Carry out procedures 15 and 17.  
187. Clean the mating face.  
188. **Check that the cup (1) and the «O» ring (2) are fitted (Fig.54).**  
189. (Fig.55) Fit the «O» rings (3) and the locating dowel (4) in the housing.  
190. (Fig.56) Offer up the input shaft housing assembly (66) into the housing by tilting it to the left then tilting it to the right to engage the reverser gear train into the A/B gear train.  
191. At the same time, check through the selector cover that the reverse shuttle selector (5) (Fig.54) is not in contact with the housing partition and that the layshaft cone (63) engages in the cup (64) (Fig.56)  
192. Position the housing assembly over the locating dowel.  
193. Fit the bolts and tighten to a torque of 45-60 Nm. Remove the retaining tool.  
194. Carry out procedure 16 in reverse.  
195. (Fig.57) Shim to obtain:  
**J2 = plus 0.04 to plus 0.12**  
196. (Fig.59) Fit the locally made-up tool (see Section U) into the layshaft.  
197. Lightly compress the spring by tightening the nut on the tool so that the cones seat correctly in the cups.  
198. Rotate the shaft several times.  
199. Measure the space X using a depth gauge between face A of the cup (52) and face B of the housing (Fig.58).  
200. Measure the thickness Y of the washer (50).  
201. Calculate the difference between X and Y.  
202. Determine the thickness of shims required to obtain a play of plus 0.04 to plus 0.12.  
203. Remove the compression tool.  
204. Position the shims [51] selected in procedure 202.  
205. Press the washer into the housing.




Fig. 53




Fig. 54








Fig. 55



# Gearbox





5A02.20

## Gearbox

### R. Shifter rail and forks - Reassembly (Fig.60)

206. Check that the hydraulic ports of the High/Low cylinder (10) are unobstructed.
207. Fit the cylinder (10) together with the «O» ring (11) in the housing.
208. Position the High/Low fork (20) in the coupler.
209. Fit the seals (12) and (14) on the piston (13) then insert it into the cylinder bore.  
**Note: The setscrew holes should face the tapped holes in the fork. Immobilise the fork with a setscrew (19).**
210. Clean and assemble the mechanical lock (22), the tapered bearing (23), the cone (24) and castellated nut (21).

211. Fit the 3rd and 4th speed gear forks (6), 1st and 2nd gears (5) and the lock assembly (25).
212. Insert the selector rail (7) through the rear of the housing and slide it into the piston, the lock assembly and the forks.  
**Note: For the 4 x 4 gearbox, do not forget the A/B fork (4).**
213. Fit the bearing (15) and tighten the bolts (16) to a torque of 27-32 Nm.
214. Clean the setscrew (8) with solvent, coat with Loctite 542 and tighten to a torque of 28-43 Nm.




Fig. 60



## Gearbox

215. Clean the insert (9). coat with Loctite 542 and press it in level with the housing.

216. Fit the locking plungers (3), the springs (2) and tighten the plugs (1) to a torque of 50-70 Nm.

**Note: Gearbox fitted with creeper gears (Fig.61).**

**Fit the sleeve (5), the fork (4) and the pin (1). Position the fork and the locking plunger (3) on the flat of the shifter rail (6) (between the two locking notches). Tighten the locking peg to compress the ball.**

**Slacken the screw a quarter turn.**

**Clean the nut (2) with solvent and coat with Loctite 241.**

**Tighten to a torque of 15-20 Nm.**

**Check that the fork is correctly locked.**




217. **Setting the High/Low range fork.**

Principle: Positioning of the selector fork (20) on the rail is made possible by the different centre to centre distances of the tapped holes **Y** and of the notches **Z** on the piston (13).

The fork's position is altered by turning either the front screw or the rear screw as necessary (Fig.62).

218. Position the control piston (13) and the coupler (31) in the High range.

219. Keep the coupler in contact with the high range gear (29) (Fig.63) (3rd gear on the 4 x 2 gearbox - 4th gear on the 4 x 4 box).





5A02.22

# Gearbox

220. Adjust the position of the fork (20) by turning the two adjusting screws (19) after cleaning them with a solvent and lightly coating them with Loctite 221 to obtain a play of  $J1 = 0.3 \text{ mm}$  between the rear face of the plate and the coupler (Figs. 63 & 64).

**Note:** Use the locally made-up tool to carry out the adjustment (see Section U).

221. Position the control piston (13) and the coupler (31) in Low range.

222. Check that there is a play of  $J2 = 0.3 \text{ minimum}$  (value obtained by J1 adjustment) between the plate and the coupler with the latter in contact with the Low range gear (36) (Fig. 65).

Tighten the screws to a torque of 35 Nm without changing the adjustment.

**Note:** In Low range position, if the face X of the fork (20) plate is in contact with the coupler (Fig. 65) increase the play J1.





223. Move the fork into the Low range position.

224. Slightly slacken the castellated nut (21).

Lightly coat the thread of the cone (24) with Loctite 270.

225. Move the forks into the neutral position.

226. Divide the J3 and J4 play (minimum 0.3 mm) equally so that the mechanical lock (22) moves freely (Figs. 66 & 67).





## Gearbox

227. Tighten the castellated nut (21) to a torque of 50 Nm using spanner 3615334 M01 and a spring balance (Fig.68).
228. Coat the inner face of the slider (18) with Loctite 648 and the bolt (17) with Loctite 241. Fit the washer and the bolt.
229. Equalize the J5 and J6 clearances (minimum 0.3 mm) between the slider and the lock in the High and Low range positions (Figs.63, 65, 69 and 70).
230. Tighten the bolt to a torque of 27-32 Nm.
231. Check the operation of the High/Low range and of the lock.
232. Check the operation of the gears and of the A/B range.

### Reverse shuttle selector - Adjustment (Fig.71)

233. Move the selector (1) into neutral.  
Fit and tighten service tool 3582434 M01 with two centring bolts fitted with spacers.
234. Coat the setscrews (2) with Loctite 221.
235. Position face X of the reverse shuttle selector in contact with the service tool using the screws (2).  
**Note: See procedure 217 for the principle of adjustment.**
236. Tighten the screws to a torque of 35 Nm.
237. Remove the tool.




Fig. 68




Fig. 69




Fig. 70




Fig. 71



5A02.24

## Gearbox

### S. Selector cover - Refitment

#### 4 x 2 Gearbox

238. Clean the mating face of the cover (56).
239. Move the reverse shuttle selector into neutral.
240. Engage 1st gear.
241. Coat the mating face of the gearbox housing with a gasket sealant (Loctite 510 Master Joint or equivalent).
- Note: Remember to position the bolt (1) on the housing (Fig.72).**
242. Turn the two cover levers to the left, keeping them parallel.
243. Lay the cover on the gearbox ensuring that the levers are correctly positioned in the selectors (Fig.73).
244. Carry out procedure 5 in reverse.

**Note: Tightening torque 50-70 Nm.**

245. Check:
  - the movement of all the gears and the position of the High/Low (Hare/Tortoise) range,
  - the operation of the reverse shuttle.

#### 4 x 4 Gearbox




246. Clean the mating face of the cover (57).

#### On the gearbox:

247. Check that the reverse shuttle selector is in neutral and the A/B fork in position B (forwards).
248. Engage 1st gear.

#### On the cover:

249. Remove the pressure valve (58) and the plunger (59) (Fig. 74).
250. Lock the control shaft (53) in position B with lugs (66) and (54) lined up (Fig. 76) using tool 3615053 M01 (Fig.74) (tighten but not fully).





## Gearbox

251. Move the lug /61\ of the A/B fork into position B (forwards) (Fig.75).
252. Move the gear lever to the left (into 1st) (36) (Fig. 76).
253. Carry out procedure 241.
254. Assemble the cover on the gearbox by engaging the lugs (54) and (66) in the reverse shuttle selector and the lug /61\ into the A/B fork, then engage the lug (36) into the 1st and 2nd gear fork and the mechanical lock (Fig.76).
255. Position the cover.
256. Fit the bolts and tighten to a torque of 50-70 Nm. Remove tool 3615053 M01.  
**Note: For a gearbox fitted with creeper gears, fit the cable bracket (1) (Fig.77)**  
**To correctly centre the cover, first tighten bolt /3\ (Fig.77). Carry out a manual check, using the levers, that the lugs have been correctly fitted into the selectors.**
257. Install the plunger /59\ and the pressure valve (58) and tighten to a torque of 18-20 Nm.
258. Check:
  - the free movement of all gears
  - the High/Low range positions
259. Adjust the A/B range. See Section 5 K03.




Fig. 75




Fig. 76




Fig. 77





5A02.26


## Gearbox

### T. Gearbox - Preparation and Refitment

260. Reverse procedures 3 and 4, section A.
261. **3000 Tractor**  
Refit the gearbox to the engine (Section 3 A01)
- 3100 Tractor**  
Refit the gearbox to the engine (Section 3 A02)
262. Refit the gearbox to the rear axle housing (See Section 3 B02).

### U. Service Tools

#### 1. Tools to be made up locally



**Mainshaft retaining tool**







5A02.28



# Gearbox



# Feeler gauge




# Layshaft retaining tool



## Gearbox


### 2. Tools available on the M.F. network

Mainshaft nut socket  
(Gearbox 4 x 4)




MF 456

Snap ring remover




MF 460

Mainshaft retaining tool




MF 458

Mainshaft nut socket  
(gearbox 4 x 2)




3376805 M1

Snap ring replacer



MF 459

Reverse shuttle setting gauge



3582434 M1






# Gearbox

## 4 x 4 Gearbox - Key to illustration

- |      |                                    |      |                                     |
|------|------------------------------------|------|-------------------------------------|
| (1)  | Bearing cone                       | (44) | Output shaft                        |
| (2)  | Bearing cup                        | (45) | Circlip                             |
| [3]  | Shims                              | (46) | Lock plate                          |
| /4\  | Spacer                             | [47] | Shims                               |
| (5)  | Circlip                            | (48) | Bearing cup                         |
| (6)  | Washer                             | (49) | Circlip                             |
| (7)  | 1st drive gear                     | (50) | Washer                              |
| (8)  | Bush                               | [51] | Shims                               |
| (9)  | 1st gear synchro cone              | (52) | Bearing cup                         |
| (10) | 1st gear synchro cup               | (53) | Bearing cone                        |
| (11) | 1st and 2nd gear synchro           | (54) | Layshaft                            |
| (12) | 2nd gear synchro cup               | (55) | 4th driven gear                     |
| (13) | 2nd gear synchro cone              | (56) | 3rd driven gear                     |
| (14) | 2nd drive gear                     |      | <b>Version a</b>   <b>Version b</b> |
| (15) | Circlip                            | (57) | Circlip   Spacer                    |
| (16) | Bearing cup                        | (58) | Circlip   -                         |
| (17) | Bearing cone                       | [58] | -   Shim                            |
| (18) | 3rd drive gear                     | (59) | 2nd driven gear                     |
| (19) | Circlip                            | (60) | 1st driven gear                     |
| (20) | 3rd gear synchro cone              | (61) | Circlip                             |
| (21) | 3rd gear synchro cup               | (62) | Needle roller bearing               |
| (22) | Washer                             | (63) | Bearing cone                        |
| (23) | 3rd and 4th gear synchro           | (64) | Bearing cup                         |
| (24) | Needle roller bearing              | (65) | Gearbox housing                     |
| (25) | 4th gear synchro cup               | (66) | Input shaft housing assembly        |
| (26) | Circlip                            | (67) | A range gear                        |
| (27) | Thrust washer                      | (68) | Nut                                 |
| (28) | Combined bearing                   | (69) | Mainshaft                           |
| (29) | 4th gear drive pinion (High range) | (70) | Circlip                             |
| (30) | Combined bearing                   | (71) | Oil feed pipe                       |
| (31) | Coupler                            | (72) | Spring                              |
| (32) | Thrust washer                      | /73\ | Spur washer                         |
| (33) | Coupler hub                        | (74) | Bush                                |
| (34) | Circlip                            | (75) | Needle roller bearing               |
| (35) | Bush                               | (76) | B range gear                        |
| (36) | Gear (Low range)                   | (77) | B range synchro cup                 |
| (37) | Bearing cup                        | (78) | A/B synchro                         |
| [38] | Shims                              | (79) | Needle roller bearing               |
| (39) | Bearing cone                       | (80) | A range synchro cup                 |
| (40) | Bearing cone                       | /81\ | Bush                                |
| (41) | Bolt                               | (82) | Sleeve                              |
| [42] | Shims                              |      |                                     |
| /43\ | Spacer                             |      |                                     |



5A02.31










## Gearbox

### 4 x 2 Gearbox - Key to illustration

- |   |                                     |
|---|-------------------------------------|
| (1) Bearing cone                        | [38] Shims                          |
| (2) Bearing cup                         | (39) Bearing cone                   |
| [3] Shims                               | (40) Bearing cone                   |
| /4\ Spacer                              | (41) Bolt                           |
| (5) Circlip                             | [42] Shims                          |
| (6) Washer                              | /43\ Spacer                         |
| (7) 1st drive gear                      | (44) Output shaft                   |
| (8) Bush                                | (45) Circlip                        |
| (9) 1st gear synchro cone               | (46) Lock plate                     |
| (10) 1st gear synchro cup               | [47] Shims                          |
| (11) 1st and 2nd gear synchro           | (48) Bearing cup                    |
| (12) 2nd gear synchro cup               | (49) Circlip                        |
| (13) 2nd gear synchro cone              | (50) Washer                         |
| (14) 2nd drive gear                     | [51] Shims                          |
| (15) Circlip                            | (52) Bearing cup                    |
| (16) Bearing cup                        | (53) Bearing cone                   |
| (17) Bearing cone                       | (54) Layshaft                       |
| (18) 4th drive gear                     | (55) 3rd driven gear                |
| (19) Circlip                            | (56) 4th driven gear                |
| (20) 4th gear synchro cone              | <b>Version a</b>   <b>Version b</b> |
| (21) 4th gear synchro cup               | (57) Circlip   Spacer               |
| (22) Washer                             | (58) Circlip   -                    |
| (23) 3rd and 4th gear synchro           | [58] -   Shim                       |
| (24) Needle roller bearing              | (59) 2nd driven gear                |
| (25) 3rd gear synchro cup               | (60) 1st driven gear                |
| (26) Circlip                            | (61) Circlip                        |
| (27) Thrust washer                      | (62) Needle roller bearing          |
| (28) Combined bearing                   | (63) Bearing cone                   |
| (29) 3rd gear drive pinion (High range) | (64) Bearing cup                    |
| (30) Combined bearing                   | (65) Gearbox housing                |
| (31) Coupler                            | (66) Input shaft housing assembly   |
| (32) Thrust washer                      | (67) Input gear                     |
| (33) Coupler hub                        | (68) Nut                            |
| (34) Circlip                            | (69) Mainshaft                      |
| (35) Bush                               | (70) Circlip                        |
| (36) Gear (Low range)                   | (71) Oil feed pipe                  |
| (37) Bearing cup                        | (72) Spring                         |



5A02.33





*5 B01 Push-type Clutch (3000)*

CONTENTS

. General	2
. Operation	2
A. Clutch assembly	5
B. Engine flywheel	6
C. Ring gear replacement	7
D. Clutch release bearing assembly	7
E. Clutch hydraulic slave cylinder assembly	8
F. Slave cylinder seal replacement	8
G. Removing air from the system	11
H. Checking piston travel in slave cylinder	11
I. Clutch pedal adjustment	11
J. Service tools	12



5B01.2

## Gearbox - Clutch

### General

#### Description

This is a diaphragm push-type clutch. The master cylinder is supplied by the low pressure hydraulic system. Drive to the gearbox is through the disc (6) which engages with the splined gearbox input shaft.

#### Construction

The slave cylinder (11) and guide (17) are fitted on the front face of the input shaft housing. The release bearing carrier (9) moves between the guide (17) and the cylinder (11). "Composite" seals /14\ and /14A\ seal the release bearing carrier and the slave cylinder. Seals /15\, /15A\ and /16\ seal the guide and the release bearing carrier. The clutch release bearing (19) is a force fit on the bearing carrier. The self-centring release bearing is sealed. The ball bearing races are sealed and the lubrication is maintained by the grease during rotation.

### Operation

#### Clutch disengagement

Depressing the clutch pedal moves the control rod which in turn operates the piston of a master cylinder. The quantity of oil displaced by this piston passes through the hole drilled in the side of the slave cylinder (11) and moves the release bearing carrier (9) and release bearing (19) assembly forwards. The diaphragm in the clutch cover (7) is compressed, releasing pressure on the clutch plate and the disc (6) is released.

#### Clutch engagement

Releasing the clutch pedal causes a drop in pressure in the slave cylinder. The diaphragm pushes the release bearing carrier rearwards and the pressure plate forwards. The disc (6) is held between the pressure plate and the engine flywheel and transmits drive to the gearbox input shaft.

#### Specifications

Clutch control	: Push-type
Plate load	: 1300 kg
Number of vanes	: 6
Type of vane	: Non-progressive
Disc diameter	: 330 mm
Friction linings	: Cerametallic

### Key to illustrations on pages 3 and 4

- |   |  |
|---|--|
| (1) Engine flywheel                         | /14A\ Cylinder "O" ring                  |
| (2) Flywheel ring gear                      | /15\ Clutch release bearing carrier seal |
| (3) PTO shaft drive hub                     | /15A\ Clutch release bearing "O" ring    |
| (4) Engine flywheel attaching bolts         | /16\ Scraper ring                        |
| (5) Clutch cover plate dowel pins           | (17) Guide                               |
| (6) Clutch friction disc                    | (18) Dowel                               |
| (7) Clutch cover plate                      | (19) Clutch release bearing              |
| (8) Bolts attaching cover plate to flywheel | (20) Supply pipe grommet                 |
| (9) Clutch release bearing carrier          | (21) Supply pipe                         |
| (10) Rubber boot                            | (22) Cylinder supply 90° union           |
| (11) Cylinder                               | (23) Cylinder bleed straight union       |
| (12) Cylinder attaching bolt                | (24) Bleed pipe                          |
| (12A) Cylinder attaching bolt               | (25) Bleed pipe union                    |
| (13) "O" ring                               | (26) Bleed point                         |
| /14\ Cylinder oil seal                      |  |




3000/3100 SERIES TRACTORS

Gearbox - Clutch



SB01.3

General view






5B01.4

3000/3100 SERIES TRACTORS



**Gearbox - Clutch**

Exploded view





## Gearbox - Clutch

### A. Clutch cover plate

#### Disassembly



1. Split the tractor between the engine and the gearbox. See Section 3 A01.
2. Locate tool MF 457 (4 cyl Fig. 1) - (6 cyl. Fig.2) to retain the cover plate/disc assembly.
3. Gradually slacken the bolts (8) attaching the cover plate (7) to the engine flywheel (1).
4. Remove the cover plate and the disc (6).
5. Remove the three dowel pins (5) on the flywheel.

#### Reassembly

6. Clean the flywheel with a solvent.
7. Check the flywheel friction surface.

**Note : if the flywheel friction surface is scored it can be skimmed. (See Section B procedure 6).**

8. **Lightly** coat the PTO shaft hub splines in the flywheel with Molybdenum disulphide grease.
9. Fit the three dowel pins (5).
10. Using tool MF 457, centre the clutch disc (6) on the flywheel. The longest section of the hub must face the diaphragm.
11. Refit the clutch cover plate.
12. Progressively tighten the bolts (8) to a torque of:  
50-70 Nm (4 cyl.)  
30-35 Nm (6 cyl.)
13. Withdraw tool MF 457.
14. Refit the gearbox to the engine (section 3 A01).





# Gearbox - Clutch

## B. Engine flywheel

### Disassembly

1. Split the tractor between the engine and gearbox (Section 3 A01).
2. Remove the engine clutch (see Section 3 A01). Carry out procedures 2 to 5 in Section A.
3. Immobilize the flywheel (1).
4. Remove the six bolts (4) attaching the flywheel to the crankshaft.
5. Remove the flywheel and the PTO shaft hub (3).

### Reassembly

6. If the friction surface of the flywheel is scored, it can be skimmed.  
Grind surface **A** as necessary to obtain dimension **X** = 26 mm mini. Surface finish 2.5 microns maximum.  
Measure dimension **Y**, reduce surface **B** to obtain a measurement of 34.1 mm to 34.2 mm (4 cyl. Fig.3) (6 cyl. Fig.4).  
Shorten the three dowel pins (5) accordingly.

**Note:**

- 1) Check that the cover plate attaching bolt holes drilled in the flywheel are the correct depth; if not, drill to the correct depth. After skimming the flywheel clean it with a solvent.
- 2) The release bearing PN3384863 M92 (45,5 mm long) is only used as repair part (Fig. 4A). If the flywheel has been skimmed on a tractor equipped with the old bearing (41 mm long) it is mandatory to replace it by the 45,5 mm long bearing.  
**Do not fit a 3100 clutch disc if the flywheel has been skimmed.**

7. Fit two dowel pins into the flywheel attaching holes.
8. Refit the flywheel and the hub (3).
9. Coat the bolts (4) with Loctite 241.
10. Refit the six bolts (4) and tighten to a torque of 110-140 Nm (4 and 6 cyl.)  
Release the engine flywheel.
11. Carry out procedures 6 to 13 (Section A).
12. Refit the gearbox to the tractor (Section 3A01)




Fig. 3




Fig. 4




Fig. 4A





## Gearbox - Clutch


### C. Flywheel ring gear replacement

#### Disassembly

1. Remove the engine flywheel (Section B, procedures 1 to 5).
2. Carry out procedures 2 and 3 (Section 5C01.C).

#### Reassembly

3. Carry out procedures 4 and 5 (Section 5 C01.C).
4. Refit the engine flywheel (Section B, procedures 7 to 12).



### D. Clutch release bearing

**Note:** As disassembly of the clutch release bearing entails its removal from the slave cylinder, seal replacement is recommended to avoid the risk of leakage during service. See Section F.



#### Disassembly

1. Using a suitable drift punch, remove the release bearing through the three holes in the slave cylinder (Fig.5).

#### Reassembly

2. Using a suitable assembly to support the outer collar, press the release bearing up against the release bearing carrier shoulder (Fig.6).

**Note:** Coat the contact surface of the release bearing and carrier with Loctite 270 (Fig.7). Do not put Loctite into the bearing.





5B01.8

## Gearbox - Clutch

### E. Hydraulic slave cylinder assembly

#### Removal

1. Split the tractor between the engine and the gearbox (Section 3 A01).
2. Disconnect the bleed pipe and supply pipe from the slave cylinder assembly.

**Note:** To remove the hydraulic slave cylinder assembly complete, do not separate the bearing carrier fully from the cylinder to gain access to the attaching bolts.

#### Method (Fig.8)

3. Pull the release bearing carrier 40 mm away from the cylinder and remove the boot (10).
4. Using short Allen keys, unscrew the two bolts (12) and bolts (12A).

#### Refitment

5. Coat the bolts with Loctite 241. Fit and tighten the bolts to a torque of:
  - 8 diam. : 25-35 Nm
  - 10 diam. : 40-70 Nm
6. Refit the boot (10). Refit the bleed pipe (24) and supply pipe (21).
7. Refit the gearbox to the tractor (Section 3 A01).
8. Remove air from the clutch hydraulic control system (see Section G).

**Note:** To avoid damage to the release bearing carrier (9) use plastic protective jaws and grip the collar lightly.




Fig. 8

4. Withdraw the clutch release bearing carrier (9) from the slave cylinder (11).
5. Remove the two bolts (12) and the bolt (12A).
6. Remove the slave cylinder-guide assembly.
7. Separate the slave cylinder and the guide (17).
8. Remove the "O" ring (13)
9. Remove:
  - the elbow union (22).
  - the straight union (23).
10. Remove the rod (18)
11. Remove the clutch release bearing (Section D, procedure 1)

#### Disassembly

12. Remove:
  - on the release bearing carrier (9): the scraper ring /16\, the seal /15\ and the "O" ring /15A\ (Fig.9).
  - on the slave cylinder (11): the seal /14\ and the "O" ring /14A\ (Fig.10).

**Note:** To remove the seals and "O" rings, use a suitably protected screwdriver (Fig.9). The bores and grooves of the parts must be free from scoring and damage.

### F. Slave cylinder seal replacement

1. Split the tractor between the engine and the gearbox (Section 3 A01).
2. Disconnect the bleed pipe (24) and the supply pipe (21).
3. Remove the rubber boot (10).



## Gearbox - Clutch

### Reassembly of "O" ring /14A\ and bush /14\ in cylinder (Fig.11).

13. Clean the cylinder (11).
14. Position the cylinder with the groove facing upwards.
15. Lubricate and fit the "O" ring /14A\ in the groove. Do not twist it.
16. Form the seal /14\ into a heart-shape.  
**Important: The lip of the seal must face outwards.**
17. Fit the seal /14\ into the groove and push it gradually towards the "O" ring /14A\.
18. Lubricate the seal and the cylinder bore.  
**Note: To ensure seal seated properly, use bearing carrier as a mandril.**

### Method

Lubricate the release bearing carrier (9)  
Insert the release bearing carrier (9) in the front of the cylinder (11) using the tool (Fig. 12) (See Section J)  
Turn the release bearing carrier approximately one turn in the cylinder to bed in seal.  
Remove the release bearing carrier: the seal /14\ is now fitted.




Fig. 9




Fig. 10




Fig. 11




Fig. 12





5B01.10



## Gearbox - Clutch


### Reassembly of "O" ring /15A\ and seal /15\ on release bearing carrier (9).

19. Clean the release bearing carrier.
20. Position the release bearing carrier with the groove facing upwards.
21. Lubricate and fit the "O" ring /15A\ in the groove. Do not twist it (Fig. 13).
22. Form the seal /15\ into a heart-shape (Fig. 14).  
**Important: The lip of the seal /15\ must face outwards.**
23. Fit the seal /15\ into the groove and push it gradually towards the "O" ring /15A\.  
**Note: To ensure seal seated properly, use guide as a mandril.**



### Method

- Lubricate the seal /15\ and the guide (17).  
Insert the guide (17) into the front of the release bearing carrier (9) using the tool shown Fig. 15. (See Section J).  
Turn the guide approximately one turn.  
Remove the guide. The seal /15\ is now fitted.





## Gearbox - Clutch

24. Using a suitable arrangement to support the bearing carrier, press in the scraper ring /16\ (Figs. 16 and 17).
25. Fit the release bearing. See procedure 2 (Section D).
26. Lubricate the seal /15\, the seal /16\ and the release bearing carrier bore.
27. Fit the rod (18) after coating it with Loctite 241. Tighten to a torque of 25-35 Nm.
28. Lubricate the guide (17), the seal (14) and the release bearing carrier (9).
29. Position the "O" ring (13) on the guide.
30. Assemble the cylinder (11) with the guide (17).
31. Refit the bolts (12) and (12A).
32. Press the release bearing carrier (9) into the cylinder (11) so as to leave a gap of 40 mm to allow access for the Allen keys to tighten bolts (12) and (12A) (Fig. 8).
33. Screw on the unions (22) and (23).
34. Locate the slave cylinder assembly on the Speedshift cover.
35. Coat the bolts (12) and (12A) with Loctite 241. Using the short Allen keys, tighten to a torque of:
  - 8 diam. : 25-35 Nm
  - 10 diam. : 40-70 Nm
36. Fit the boot (10). Refit the bleed pipe (24) and supply pipe (21).
37. Refit the gearbox to the tractor. See Section 3 A01.
38. Remove air from the clutch hydraulic control system.

### G. Removing air from the clutch hydraulic system

1. Carry out procedures 1 to 5, Section 5 C01.G.

### H. Checking piston travel in the slave cylinder

1. Carry out procedures 1 to 3, Section 5 C01.H.

### I. Clutch pedal adjustment

Before assembly coat the pins (3) and (4) with molybdenum disulphide grease. Coat the threads of the rod (1) (Fig. 18) with Loctite 542. Adjust the rod to obtain a pedal travel of 170 mm between the disengaged position (pedal up against the stop (2)) and the engaged position.




Fig. 16




Fig. 17




Fig. 18



**Gearbox - Clutch**

5C01.1

**5 C01 Pull-type Clutch (3100)**

**CONTENTS**

. General	2
. Operation	2
A. Clutch assembly	5
B. Engine flywheel	6
C. Ring gear replacement	6
D. Clutch release bearing assembly	7
E. Clutch hydraulic slave cylinder assembly	8
F. Slave cylinder seal replacement	9
G. Removing air from the system	12
H. Checking piston travel in slave cylinder	12
I. Clutch pedal adjustment	12
J. Service tools	13



5C01.2

## Gearbox - Clutch

### General

#### Description

This is a diaphragm pull-type clutch. The master cylinder is supplied by the low pressure hydraulic system. Drive to the gearbox is through the disc (6) which engages with the spined gearbox input shaft during rotation.

#### Construction

The slave cylinder (19) is fitted on the front face of the input shaft housing. The piston/cylinder assembly is sealed by composite seals /14\ and /16\ and the slave cylinder guide by rings /13\ and /17\.

The boot holder (11) is screwed on to the end of the piston (15) and retains the clutch release bearing carrier (9) and clutch release bearing (23). The spring clip (10) retains the clutch release bearing carrier (9) on the boot holder (11).

The clutch cover plate (7) is connected to the release bearing by a circlip fitted on the cover plate and which locates in the groove of the release bearing (23).

**Warning:** Any operation which requires splitting the tractor between the engine and the gearbox requires removal of the spring clip (10) (see Section 3 A02)

### Operation

#### Clutch disengagement

Depressing the clutch pedal moves the control rod which in turn operates the piston of a master cylinder. The quantity of oil displaced by this piston passes through the lower hole in the slave cylinder (19) and moves the piston (15) and release bearing (23) assembly rearwards. The diaphragm is then compressed and the disc (6) is released.

#### Clutch engagement

Releasing the clutch pedal causes oil to escape from the slave cylinder pressure chamber and the release bearing to return.

The diaphragm is compressed and the disc (6) is held against the engine flywheel by the friction plate in the clutch cover (7).

#### Specifications

Clutch control type	Pull
Plate load	1300 kg
Number of vanes	7
Type of vane	Progressive
Type of pressure plate	Ventilated
Disc diameter	330 mm
Friction linings	Cerametallic

### Key to illustrations

(1)	Engine flywheel	/16A\	Slave cylinder piston "O" ring
(2)	Flywheel ring gear	/17\	Slave cylinder piston guide ring
(3)	PTO shaft drive hub	(18)	bolts attaching slave cylinder to gearbox
(4)	Engine flywheel attaching bolts	(18A)	Speedshift housing
(5)	Clutch cover plate dowel pins	(19)	Slave cylinder
(6)	Clutch friction disc	(20)	Retaining ring (clutch release bearing)
(7)	Clutch cover plate	(21)	Flat washer (clutch release bearing)
(8)	Bolts attaching cover plate to flywheel	(22)	Spring washer (clutch release bearing)
(9)	Clutch release bearing carrier	(23)	Clutch release bearing
(10)	Spring clip	(24)	Guide pin
(11)	Rubber boot carrier	(25)	Supply pipe grommet
(12)	Rubber boot	(26)	Supply pipe
/13\	Clutch slave cylinder guide ring	(27)	Cylinder supply elbow connector
/14\	Clutch slave cylinder seal	(28)	Slave cylinder straight bleed connector
/14A\	Slave cylinder "O" ring	(29)	Bleed pipe
(15)	Slave cylinder piston	(30)	Bleed pipe union
/16\	Slave cylinder piston seal	(31)	Bleed take-off point




3000/3100 SERIES TRACTORS

Gearbox - Clutch



5C01.3

General view








5C01.4

3000/3100 SERIES TRACTORS

Gearbox - Clutch



Exploded view





## Gearbox - Clutch


### A. Clutch cover plate

#### Disassembly

1. Split the tractor between the engine and the gearbox. See Section 3 A02.
2. Separate the release bearing carrier from the cover plate (7).
3. Position tool MF 457 to retain the cover plate/disc assembly (Fig.1).
4. Progressively slacken the bolts (8) attaching the cover plate (7) to the engine flywheel (1).
5. Remove the cover plate (7) and the disc (6).
6. Remove the three dowel pins (5) on the flywheel (1).

#### Reassembly

7. Clean the flywheel (1) with a solvent.
8. Check the flywheel friction surface.  
**Note: If the flywheel friction surface is scored it can be skimmed. (See 5 C01.B procedure 6).**
9. Lightly coat the PTO shaft hub splines (3) with a molybdenum disulphide grease.  
Fit the three dowel pins (5) on the flywheel (1).
10. Using tool MF 457, centre the clutch disc (6) on the flywheel. (The longest section of the hub must face the diaphragm). (Fig.1).
11. Refit the clutch cover plate.
12. Progressively tighten the bolts (8) to a torque of 25-35 Nm.
13. Withdraw tool MF 457.
14. Refit the gearbox to the engine (see 3 A02).





# Gearbox - Clutch

## B. Engine flywheel

### Disassembly (Fig.2)

1. Split the tractor between the engine and gearbox. Section 3A02.
2. Remove the engine clutch, see Section 5 C01A.
3. Immobilize the engine flywheel (1).
4. Remove the six bolts (4).
5. Remove the engine flywheel (1) and the hub (3).

### Reassembly

6. If the friction surface of the flywheel (1) is scored, it can be skimmed ; a maximum of 1.5 mm can be removed. Surface finish 2.5 micrometers maximum. Shorten the dowel pins (5) accordingly.
- NOTE: After skimming clean the flywheel with a solvent.**
7. Fit two dowel pins into the flywheel attaching holes.
  8. Refit the nub (3) and the flywheel (1).
  9. Clean the bolts (4) and coat them with Loctite 241.
  10. Refit bolts (4) and immobilize the flywheel. Tighten to a torque of 110-140 Nm.
  11. Carry out procedures 1 and 2 in reverse.




Fig. 2

## C. Flywheel ring gear replacement

### Disassembly

1. Remove the flywheel, see 5 C01.B.
2. Drill a 5 mm diameter hole in the ring gear halfway between the inner diameter of the ring (2) and the bottom of any tooth to a depth of 16 mm (Fig. 3).
3. Place a cold chisel in the space above the hole and split the ring gear.

**Important: Wear protective equipment when removing the ring gear to avoid flying metal particles.**

### Reassembly

4. Heat a new ring gear to 245°C in an oven. Do not use a blow torch or any other naked flame.
5. Fit the ring gear (2) on to the flywheel (1) with the chamfered lead on the teeth pointing towards the front (engine side) of the flywheel. Push the ring gear quickly into position. Allow the ring to cool slowly
6. Refit the flywheel.





Fig. 3



## Gearbox - Clutch

### D. Clutch release bearing

#### Disassembly

1. Split the tractor between the engine and the gear-box. Operation 3 A02.
2. Release the carrier from the clutch cover plate.
3. Grip the tool (Fig. 4) made up locally (see Section J) in a vice. Locate the release bearing carrier on the tool.
4. Screw up the nut on the tool to compress the spring washer (22).
5. Press the circlip (20) near the centre with a small screwdriver.
6. (Fig.5) Press on the carrier (9) and remove the circlip (20).
7. Remove the washer (21), the spring washer (22) and the release bearing (23) from the carrier.




Fig. 4

#### Reassembly

8. Carry out procedures 3, 7 and 4.
9. Locate the circlip (20) in the groove of the carrier (9) and **ensure that it is correctly located**.
10. Check the radial clearance of the release bearing (23) in the housing of the carrier (9). (Fig.6)
11. Refit the gearbox to the tractor. Section 3 A02.




Fig. 5




Fig. 6



5C01.8



## Gearbox - Clutch

### E. Hydraulic slave cylinder assembly

#### Removal

1. Split the tractor between the engine and the gearbox. Section 3 A02.
2. Disconnect
  - the supply pipe (26) (plug the pipe),
  - the bleed pipe (29)
3. Remove the two bolts (18) and the bolt (18A).
4. Remove the slave cylinder assembly.

#### Refitment

5. Clean the threads of the slave cylinder attaching holes.
6. Position the slave cylinder assembly on the gearbox cover.

7. Clean the two bolts (18) and the bolt (18A) and coat them with Loctite 241.
8. Refit bolts (18) and (18A) and tighten to the torque:
  - 8 diam. : 25-35 Nm
  - 10 diam. : 50-70 Nm
9. Reconnect: pipes (26) and (29).
10. Clean the clutch housing with a solvent.
11. Refit the gearbox to the tractor. Section 3 A02.
12. Remove air from the clutch hydraulic control system (see Section 5 C01.G).




Fig. 7



## Gearbox - Pull-type clutch

5C01.9

### F. Slave cylinder seal replacement

1. Split the tractor between the engine and the gearbox. Section 3 A02.
2. Remove the clutch hydraulic slave cylinder. Section 5 C01.E.
3. Remove the rubber boot (12).
4. Remove :
  - the elbow union (27),
  - the straight union (28),
  - the guide pin (24) on the boot carrier (11),
  - the boot carrier (11) using the locally made-up tools shown in Figs.8 and 9 (see section J)
5. Remove the guide pin (24).
6. Withdraw the piston (15) from the cylinder (19).

#### Disassembly

7. Remove the piston seals /16\ - /16A\ and the ring /17\.  
Remove the cylinder seals /14\ and /14A\ and ring /13\.
- Note :** 1) To remove the seals, use a suitably protected screwdriver (Fig. 10).  
2) The bores and grooves of the parts must be free from scoring and damage.

#### Reassembly

##### Reassembly of "O" ring /14A\ and bush /14\ in cylinder :

8. Clean the cylinder (19).
9. Position the cylinder with the grooves facing upwards.
10. Lubricate and fit the "O" ring /14A\ in the deepest groove. Do not twist it. (Fig. 11)
11. Compress the seal /14\ into a heart-shape (Fig. 11)  
**Important: The lip of the seal /14\ must face outwards.**
12. Fit the seal /14\ into the groove and push it gradually towards the "O" ring /14A\.
13. Lubricate the seal /14\ and the bore of the cylinder (19).
14. **Important: To ensure seal seated properly, use piston /15\ as a mandril.**




Fig. 8




Fig. 9




Fig. 10



5C01.10



## Gearbox - Pull-type clutch

### To fit seal /14\

Protect the threaded part of the piston (15) (Fig.11).  
 Locate the piston in the cylinder (the threaded portion of the piston (15) facing the front of the cylinder (19)).  
 Centre the piston and introduce it into the cylinder using the fitting tool Fig.12 (See Section J).  
 Turn the piston approximately one turn in the cylinder.  
 Remove the piston (15). The seal /14\ is now fitted.




Fig. 11

### Reassembly of "O" ring and seal on piston

15. Clean the piston (15).
16. Fit the seal /16\ on the small diameter of the piston.  
**Important: The lip of the seal /16\ must face outwards.**
17. Place the piston (with the groove facing you) on a pipe gripped in a vice. Immobilise the piston (Fig.13).
18. Lubricate and fit the oil seal /16A\ in the deepest groove. Do not twist it.
19. Work the seal /16\ gradually into the groove using two lengths of tape (Fig.13).
20. **Important: To ensure seal seated properly use cylinder (19) as a mandril.**
21. Fit the guide ring /13\ into the cylinder. Ensure that it is correctly seated in the groove. (Clearance 2 - 5 mm).

### To fit seal /16\

Fit the seal using the torsion bar and tool 3376804 M1 (Fig.14).

Lubricate the seal and the piston (15).

Insert the piston (15) into the cylinder (19) using the tool shown in Fig.15. Turn the piston approximately one turn.

Remove the piston (15). The seal /16\ is now fitted.

22. Make the guide ring /13\ round. Lightly grease the two ends (Use grease made by Under Technical Soci(t) WITCO 76320 Saint Pierre des Elfes).

**Note: To reduce friction on the guide ring /13\, its contact surface with the piston has been milled from serial no. R023005. The milled surface MUST face the piston.**




Fig. 12




Fig. 13



## Gearbox - Clutch

23. Lubricate the cylinder bore, the piston, the seals /14\, /16\ and guide ring /13\.
24. Place the assembly in a vice.
25. Push the piston approximately 10 mm into the cylinder using the tool (Fig. 16)
26. Make the long guide ring /17\ round. Lightly grease the two ends (Use grease «Amber technical» made by WITCO. co 76320 Saint Pierre des Elfes France) or equivalent miscible grease.  
**Note: To reduce friction on the guide ring /17\, its contact surface with the piston has been milled from serial no. R023005. The milled surface MUST face the piston.**
27. Fit the guide ring into the piston groove manually. (Clearance 2 to 5 mm).
28. Complete the assembly of the piston into the cylinder using the tool (Fig. 17).
29. Clean and refit the guide pin (24).
30. Clean the thread of the boot carrier (11) and of the piston (15). Apply Loctite 542 to the boot carrier and tighten it on the piston using the tools (Figs.8 and 9)
31. Line up one of the threaded holes in the boot carrier with the rod (24).
32. Coat the rod (24) with Loctite 241 and tighten to a torque of 25-35 Nm.
33. Tighten the unions (27) and (28).
34. Carry out procedures 2 and 3 in reverse.
35. Refit the gearbox to the tractor, operation 3 AO2.
36. Remove air from the clutch hydraulic system. See Section G.




Fig. 15




Fig. 16




Fig. 14




Fig. 17





# Gearbox - Clutch

## G. Removing air from the clutch hydraulic system

1. Run the engine at approximately 1200 r.p.m and restrict the return hose (1) Fig. 18 with suitably protected pliers or clamp.
2. Connect the union 3582045 M1 (1) together with its hose (Fig.19) to the bleed point (RH side of gear-box).
3. Immerse the end of the hose into a receptacle partly filled with transmission oil.
4. Operate the clutch pedal. Repeat the action several times until oil free of air bubbles comes out of the hose.
5. Remove the union 3582045 M1 and release the return hose.

**NOTE: On this type of clutch, pedal travel is taken up automatically.**

**However, if the clutch does not operate correctly, repeat the air removal procedure. If the problem persists, refer to Section H.**




Fig. 18

## H. Checking piston travel in the slave cylinder

1. Disconnect the two hoses supplying the front differential lock (4WD) and plug the connections.
2. Remove the guard and the 4WD transmission shaft.
3. Remove the inspection plate.  
Switch off the engine. Using a pair of dividers, measure the distance between the slave cylinder (19) and the boot carrier (11)  
Fully depress the clutch pedal. Measure the distance again.  
The difference between the two measurements (travel) must be 8-10 mm.




Fig. 19

## I. Clutch pedal adjustment

Before assembly coat the pins (3) and (4) with molybdenum disulphide grease.

Coat the threads of the rod (1) (Fig.20) with Loctite 542. Adjust the rod to obtain a pedal travel of 200 mm between the disengaged position (pedal against the stop (2)) and the engaged position.





Fig. 20




# Gearbox - Pull-type clutch

## J. Service Tools


### 1. Tools to be made up locally



Boot carrier removal tool



Piston retaining tool



Piston fitting and spring washer compression tool



5C01.14


3000/3100 SERIES TRACTORS




## **Gearbox - Pull-type clutch**

### **2. Tools supplied by M-F.**


**MF 457**  
**Clutch centraliser**



**3582045 M1**  
**Hydraulic connector (coupler)**



**3376804 M1**  
**Oil seal calibrating tool**





***Gearbox - Selector rail and forks***

***5 D01 Selector rail and forks***

CONTENTS

General	2
A. Creeper gear fork	2
B. Hare/Tortoise range fork - Mechanical lock assembly - 1st/2nd - 3rd/4th forks - Selector rail	6
C. A/B range fork	7



5D01.2



# Gearbox - Selector rail and forks

## General

The selector rail (7) which supports the various forks and the latch assembly is located on the RH side of the gearbox on the selector cover side. It crosses the gearbox housing and the Hare/Tortoise range control piston (13). It is held in place by a setscrew (8). A plug (9) seals the front end of the rail and a cover (15) seals the rear end. The forks for the A/B range (4), 1st/2nd gears (5), 3rd/4th gears (6) and the creeper gears (28) cannot be adjusted (except locking pressure for the creeper gears). The Hare/Tortoise range fork (20) is adjustable.  
**Note: The 4 x 2 gearboxes (8-speed) have no A/B fork (4).**

## A. Creeper gear fork

### Disassembly

1. Carry out procedures 1 to 7 (Section 5 K01).
  2. Carry out procedures 2 to 14 (Section 8 I01)
  3. Disconnect the creeper gear control cable.
  4. Remove the bolt (1), withdraw the rod (2) to disengage the lever from the fork (Fig. 1).
  5. Unscrew nut (26) and the locking screw (27) on the fork (28) (Fig. 2).
  6. Remove the setscrew (8) (Fig. 5)
  7. Turn the selector rail (7) and drive out the roll pin (29) (Figs. 2 and 3).
- Note: Take care not to let the roll pin fall into the gearbox housing.**
8. Drive out the double pin (1) from the coupling sleeve (2) (Fig. 4). If the pin is inaccessible, carry out procedures 9 to 12.




Fig. 1




Fig. 2




Fig. 3




Fig. 4



# Gearbox - Selector rail and forks

5D01.3




Fig. 5

### Key to Figure 5

- |                       |                                 |                        |
|-----------------------|---------------------------------|------------------------|
| (1) Plug              | (11) 'O' ring                   | (21) Castellated nut   |
| (2) Spring            | (12) 'O' ring                   | (22) Latch             |
| (3) Locking plunger   | (13) Hare/Tortoise range piston | (23) Tapered bearing   |
| (4) A/B range fork    | (14) 'O' ring                   | (24) Cone              |
| (5) 1st/2nd gear fork | (15) Cover                      | (25) Latch assembly    |
| (6) 3rd/4th gear fork | (16) Bolt                       | (26) Nut               |
| (7) Selector rail     | (17) Bolt                       | (27) Locking screw     |
| (8) Setscrew          | (18) Slider                     | (28) Creeper gear fork |
| (9) Plug              | (19) Adjusting screw            | (29) Roll pin          |
| (10) Cylinder         | (20) Hare/Tortoise range fork   |                        |



5D01.4



# Gearbox - Selector rail and forks

### On 4WD tractors.

9. Disconnect the front hose from the differential lock control (front axle side).
10. Remove the guard (1) (Fig. 6).
11. Unscrew the centre bearing (2) from the 4WD shaft (3) (Fig. 6).
12. Remove the split pin (4) from the rear sleeve (5), disengage the 4WD clutch shaft by sliding off the sleeve (Fig. 6). Turn the halfshaft to bring the coupling sleeve (2) into position (Fig. 4).
13. Fit the setscrew (8) temporarily to hold the selector rail in order to remove the fork (28) (Fig. 5)
14. Slide the sleeve (1) and the coupler (2) towards each other on the connecting shaft (3) (Fig. 7).
15. Move the sleeve assembly, connecting shaft and coupler to the outer LH edge, then withdraw it from the fork (28) (Fig. 7).
- Note: Mark the direction in which the sleeve is assembled (1) (Fig. 7).**
16. Remove the fork (28) from the selector rail (7) (Fig. 8).
17. Remove the rod (3) (Fig. 1).
18. To remove the creeper gear control shaft (1), turn it so that it goes under the selector rail (7) (Fig. 9). Discard the 'O' ring (3).




Fig. 6




Fig. 7




Fig. 8




Fig. 9



## Gearbox - Selector rail and forks

### Reassembly

19. Check the parts and replace any which are faulty.
20. Refit the control rod. Pull the rod as far as possible to the right. Lubricate and fit a new 'O' ring (Fig. 10).
21. Refit the rod (3) (Fig. 11).  
Coat the bolts with Loctite 241 and tighten them.
22. Refit the fork on the selector rail.  
**Note: Ensure that the lever (1) of the creeper gear control rod faces the front of the tractor (Fig. 11).**
23. Engage the sleeve assembly, connecting shaft and coupler at the LH outer edge, then fit it in the fork.  
**Note: The machining groove on the sleeve (1) should face the rear of the tractor (Fig. 12).**
24. Slide the sleeve and the coupler on to the connecting shaft.
25. Press a new double pin (1) into the sleeve (2) (Fig. 4).
26. Remove the setscrew (8) (Fig. 5).
27. Press in a new pin (29) and turn the selector rail (7) (Figs. 2 and 3)
28. Clean the setscrew (8), coat it with Loctite 542 and tighten to a torque of 28 - 43 Nm.
29. Locate the fork (28) and the locking screw (27) on flat M of the selector rail (7) (between the two detent notches) (Fig. 5).  
Tighten the screw to compress the ball. Slacken the screw a quarter turn. Clean the nut (26) and coat it with Loctite 241, then tighten to a torque of 15 - 20 Nm (Fig. 5).  
Check that the fork is correctly tightened.
30. Turn and push the rod (2) to engage the lever in the fork. Fit the bolt (1) after coating with Loctite 241 (Fig. 1).  
**Note: Check the operation of the rod.**
31. Reconnect and adjust the creeper gear control cable.  
**Note: See Section 5 J01 for adjustment procedure.**
32. Carry out procedures 15 to 17 (Section 8 I01).
33. Check that the transfer pipe 'O' rings are in good condition and insert the pipe into the LH cover (see Fig. 2 - Section 8 I01).
34. Carry out procedures 20 and 18 (Section 8 I01).
35. Refit the RH cover and the bolts. Tighten to a torque of 72-96 Nm.
36. Carry out procedures 7 - 11 in reverse (Section 8 I01).
37. Fit the wiring harnesses and secure with a clip.




Fig. 10




Fig. 11




Fig. 12



**Gearbox - Selector rail and forks**



38. Refit the trailer braking valve (if fitted). Check that the 'O' rings are in good condition. Tighten to a torque of 25-35 Nm.
39. Carry out procedure 6 in reverse (Section 8 I01).
40. Refit the trailer braking valve pipe (if fitted) and the filter.
41. Carry out procedures 9 - 12 in reverse (Section 5 D01).
42. Refit the wheel. Remove the stand and the trolley jack.
43. Tighten the wheel nuts to a torque of 400 - 450 Nm.
44. Carry out procedures 1 to 4 in reverse (Section 5 K01).
45. Start the engine and carry out procedures 32 and 33 (Section 8 I01).
46. Road test the tractor and check the creeper gear control.
61. Remove the cylinder (10) (Fig. 5) and discard the seal.
62. Turn the pump suction pipe (1) upwards.  
**Note: Do not slacken the bolt (2) on the pipe clip (Fig. 13).**
63. Move the selector rail rearwards to free the A/B (4 x 4 gearbox), 1st, 2nd, 3rd, 4th and Hare/Tortoise forks.
64. Withdraw the 1st, 2nd, 3rd and 4th forks and the lock assembly.
65. Withdraw the Hare/Tortoise fork.
66. Remove the slider (18) (Fig. 7).
67. Withdraw the selector rail through the selector cover access panel after passing it through the High/Low range cylinder bore (Fig. 15).
68. Remove the lock assembly.

### B. Hare/Tortoise range fork - Mechanical lock assembly - 1st/2nd and 3rd/4th forks - Selector rail

#### Disassembly with or without creeper gears

**Note: For gearboxes fitted with creeper gears, carry out the additional procedures marked \*.**

47. Carry out procedures 1 to 12, Section 5 K01.
- 48\* Disconnect the creeper gear control cable.
49. Carry out procedures 5 and 6, Section 5 A02.B.
50. Carry out procedures 2 to 14, Section 8 I01.
51. Remove the plugs (1), the springs (2) and the detent plungers (3) (Fig. 5).
- 52\* Carry out procedures 4 to 7.
- 53\* Refit the setscrew (8) temporarily.
54. Carry out procedures 8 to 11, Section 5 A02.C.
55. Tap the rear end of the selector rail (7) with a copper tipped mallet to drive out the plug (9) (Fig. 5).  
**Note: This procedure gives access to the selector rail from the front.**
- 56\* Remove the creeper gear fork (28) (Fig. 5) by moving the selector rail forwards.
57. Position the Hare/Tortoise range fork (20) (Fig. 5) in the Low position.
58. Remove the adjusting screws (19) (Fig. 5).
59. Remove the bolts (16) and the cover (15) (Fig. 5).
60. Remove the Hare/Tortoise piston (13) (Fig. 5) and discard the seals.





## Gearbox - Selector rail and forks

### Reassembly

69. Check the parts and replace any that are worn.
70. Clean the cone threads and the nut tapping.
71. Refit the latch assembly.
72. Carry out procedure 67 in reverse (Fig. 15).
73. Refit the forks and the latch assembly.
74. Check that the ports of the Hare/Tortoise range hydraulic cylinder (10) are not blocked.  
Fit the cylinder complete with the 'O' ring (11).
75. Slide the selector rail forwards into the Hare/Tortoise range fork, the latch assembly, 1st/2nd, 3rd/4th and the A/B range forks (4 x 4 gearbox).  
**Note: For gearboxes fitted with creeper gears, move the selector rail far enough forward to refit the fork (28) (Fig. 16).**
76. Carry out procedure 209, Section 5 A02.R.
77. Fit the cover (15) with the bolts (16) and tighten to a torque of 27 - 32 Nm.
- 78\* Fit the creeper gear fork lugs into the coupler.  
**Note: The fork control lever (1) should face forwards (Fig. 11).**
- 79\* Slide the selector rail rearwards into the creeper gear fork.
- 80\* Press in a new pin (Fig. 3) to facilitate fitting, turn the selector rail (Fig. 2).
81. Clean the setscrew, coat it with Loctite 542 and tighten to a torque of 38 - 43 Nm.
82. Coat the plug (9) with Loctite 542 and press it in level with the housing.
- 83\* Fit the locking screw (27) on the fork (28) and nut (26) on the bolt (Fig. 5).
- 84\* Carry out procedure 29.
85. Turn and push the rod (2) until it engages with the lever in the fork. Fit the bolt (1) after coating it with Loctite 241 (Fig. 1).
86. Fit the detent plungers, springs and locking nuts. Tighten the nuts to a torque of 50-70 Nm.
87. Carry out procedures 217 to 232, Section 5 A02.R
88. Carry out procedures 15 to 27, Section 8 I01.
89. Carry out procedures:  
246 to 256, Section 5 A02.S (4 x 4)  
238 to 244, Section 5 A02.S (4 x 2)
90. Fit the plunger and the hydraulic spool valve (4 x 4).
- 91\* Reconnect and adjust the creeper gear control cable. See Section 5 J01.
92. Carry out procedures 8 to 12 in reverse (Section 5 K01).
93. Refit the wheel. Remove the stand and the trolley jack.




Fig. 15




Fig. 16

94. Tighten the wheel nuts to a torque of 400 - 450 Nm.
95. Top up the oil in the gearbox, remove the chocks and release the parking brake.

### Road test the following controls:

- . Creeper gears (if fitted)
- . Hare/Tortoise range
- . 1st, 2nd; 3rd, 4th gears

96. Check all cover gasket faces and hydraulic unions for leaks.

### C. A/B range fork

**Note: Since the A/B fork disassembly and reassembly procedures are identical to the A/B range procedures, refer to Section 5 F01.**



**Gearbox - Input unit**

*5 E01 Input unit*

CONTENTS

-	General	2
A.	Removal	2
B.	Refitment	2



5 E01.2

## 3000/3100 SERIES TRACTORS



# Gearbox - Input unit

### General

The input gearbox is in the form of an interchangeable module fitted at the input end of the gearbox. It is made up of two quite separate parts: the speedshift (if fitted) and the reversing mechanism.

**The speedshift** : This is an independant device which allows the input speed to the main gearbox to be doubled. It is situated at the front of the input gearbox and consists of a hydraulic clutch coupled to epicyclic reduction gearing. For operation see Section 5 E02.

**Reverse shuttle** : This is housed in the enclosure at the rear of the input gearbox and consists a set of two gears operated via a synchromesh mechanism. Paired idler gears allow the direction of rotation to be reversed. For operation see Section 5 E03.

### A. Removal

**N.B.:**

1) *To enable the layshaft bearings to be shimmed correctly, the gearbox must be removed from the tractor.*

2) *If the input gearbox is to be replaced as a complete assembly, the layshaft will need to be shimmed again.*

**3000-3100 tractors**

1. Split the tractor between the gearbox and the rear axle (Section 3 BO2).

**3000 tractors.**

2. Separate the gearbox from the engine. Carry out procedures 11 and 12, Section 3 AO1 (after suspending the gearbox in slings). Remove the PTO shaft. Remove the input gearbox: carry out procedures 7 to 12, Section 5 E03.

### Remove the clutch slave cylinder assembly.

**N.B.:** *To avoid damaging the seals, it is best not to remove the release bearing mounting from the slave cylinder.*

3. Withdraw the release bearing from the slave cylinder for a distance of approx. 40 mm (Fig.8 - 5 BO1), take off the rubber boot.
4. Undo the three bolts holding the slave cylinder assembly in position.

**3100 tractors**

5. Separate the gearbox from the engine. Section 5 A02A, procedure 2.
6. Carry out procedures 6 to 12 (Section 5 E03).

### Removing the clutch slave cylinder assembly

7. Carry out procedures 3 and 4, Section 5 C01E.

### B. Refitment

**3000 tractors**

Refit the clutch slave cylinder assembly.

8. Clean the 3 bolts and apply Loctite 421 to them. Fits the bolts and tighten them to torques of :  
8 mm : 25-35 Nm  
10 mm : 50-70 Nm
9. Refit the rubber boot and push the thrust washer mounting back in. Refit the input gearbox; carry out procedures 72 to 83, Section 5 E03. Refit the gearbox to the engine.

The following procedures are to be carried out from Section 3 A01:13 and 14 (except a)  
15, 16, 17 and 18 (after the gearbox has been suspended in slings).

**3100 tractors**

Refit the clutch slave cylinder assembly.

10. Carry out procedures 7 and 8, Section 5 C01E.
11. Carry out procedures 72 to 83, Section 5 E03. Fit the gearbox to the engine. The following procedures are to be carried out from Section 3 A02:15 to 18 (except a)  
19 to 22.

**3000 - 3100 tractors**

12. Re-unite the tractor at the joint between the gearbox and rear axle (Section 3 BO2).
13. Perform road test on speedshift, reversing mechanism and gears.
14. Check that there are no leaks at the selector cover joint and the gearbox to rear axle joint.



## 5 E02 Speedshift

### CONTENTS

-	General	2
-	Operation	2
A.	Removing the front cover	6
B.	Disassembling the front cover	7
C.	Separating planetary carrier and cover assembly	7
D.	Disassembling the planetary carrier assembly	8
E.	Disassembling hydraulic cover	8
F.	Reassembling the planetary carrier	9
G.	Reassembling the hydraulic cover	10
H.	Refitting the planetary carrier assembly	11
I.	Reassembling the front cover	11
J.	Refitting the front cover	13



5E02.2

Gearbox - Speedshift

General

The speedshift unit is mounted at the front of the gearbox input. It is a hydraulically operated gearchange device which provides two different input ratios to the main gearbox. It does this by means of:

- a multidisc hydraulic clutch,
  - an epicyclic gear train consisting of a planetary carrier with three twin planetary gears, an input sun gear and an output sun gear,
  - a system for braking the planetary carrier hydraulically.
- The design of the speedshift allows the ratios to be changed on the move, even under full load, without declutching.

Different versions

The following versions can be obtained as a function of the number of teeth on sun gears /6\ and /7\ and the order in which they are fitted:

- 30 km/h or 40 km/h version (Fig. 1)
- version with super creeper gears (Fig. 2).

Operation

30 Kph and super creeper version : stepdown  
40 Kph version : stepup (Fig. 3)

In this mode (Fig. 3), there is no supply to the hydraulic components and the speedshift operates as a purely mechanical transmission. Oil in chamber of pistons (28) and (48) returns to the housing via the gallery C and the solenoid. The drive from the hollow primary shaft (36) is transmitted to the input sun gear /7\ by the splines which secure the gear to the shaft. Sun gear /7\ drives the compound planetary gears /12\ which are mounted to rotate freely on spindles /8\.

The planetary gears in turn drive the output sun gear /6\, which is splined to the hollow secondary shaft (5), in one of the following ratios: 30 km/h 1.26 stepdown - 40 km/h 1.26 stepup - super creeper 7.8 stepdown. Since no hydraulic pressure is applied, the planetary carrier assembly (50) is locked against rotation by a Belleville spring disc (18) which applies pressure to pressure plate (20) and thus stops disc (21) from turning, the latter being locked to the planetary carrier assembly in rotation by splines.




Fig. 1




Fig. 2

List of parts

- |                               |                             |                            |                                 |
|-------------------------------|-----------------------------|----------------------------|---------------------------------|
| (1) O-ring                    | (13) Housing                | (27) Front cover           | (41) Pressure plate             |
| (2) O-ring                    | (14) Spacer                 | (28) Clutch piston         | (42) Disc                       |
| (3) Bolt                      | (15) Hub                    | (29) O-ring                | (43) Spring washer              |
| (4) Bush                      | (16) Needle-roller bearing  | (30) Sealing               | (44) Pressure plate             |
| (5) Secondary shaft           | (17) Thrust washer          | (31) Sealing               | (45) Disc                       |
| /6\ Output sun gear           | (18) Belleville spring disc | (32) Needle-roller bearing | (46) Spring washer              |
| /7\ Input sun gear            | (19) O-ring                 | (33) Seal carrier          | (47) Pressure plate             |
| /8\ Planetary gear spindles   | (20) Pressure plate         | (34) Seal                  | (48) Piston                     |
| /9\ Planetary carrier cover   | (21) Disc                   | (35) Wide seal             | (49) Bolt                       |
| (10) Thrust washer            | (22) O-ring                 | (36) Primary shaft         | (50) Planetary carrier assembly |
| (11) Needle-roller bearing    | (23) O-ring                 | (37) Circlip               | (51) Circlip                    |
| /12\ Compound planetary gears | (24) Bolt                   | (38) Lug washer            | (52) Seal                       |
|                               | /25\ Hydraulic cover        | (39) Washer                | (53) Needle-roller bearing      |
|                               | (26) O-ring                 | (40) Ball                  |                                 |



# Gearbox - Speedshift




Fig. 3



5E02.4



# Gearbox - Speedshift

## Hydraulic operation : direct transmission (Fig.4)

The range is changed by actuating the solenoid valve, which then feeds hydraulic oil to the chambers behind pistons (48) and (28) simultaneously. Braking piston (48) is then applied to pressure plate (20), which compresses the Belleville spring disc (18), thus releasing disc (21) and the planetary carrier assembly (50). At the same time clutch piston (28) clamps together pressure plates (41), (44), (47) and the discs

(42), (45) which are driven by hub (15). Since the pressure plates are secured to the planetary carrier by three lugs, drive is transmitted from the primary input shaft (36) to the hub (15) and from there to the clutch assembly which transmits it to the planetary carrier (50). The primary shaft (36) and the planetary gear and sun gear assembly turn at the same speed as the secondary shaft (5) thus giving direct transmission in the ratio of 1/1.




Fig. 4





# Gearbox - Speedshift

Exploded view




Fig. 5



5E02.6



## Gearbox - Speedshift

### A. Removing the front cover

#### 3000 tractors

1. Split the tractor between the engine and gearbox (Section 3 A01).

#### 3100 tractors

2. Split the tractor between the engine and gearbox (Section 3 A02).

#### 3000-3100 tractors

3. Remove the PTO shaft.
4. Withdraw seal (52).
5. Remove the bleed and supply pipes to the clutch assembly.
6. Drain the gearbox only of oil.
7. Unscrew bolts (24) (Fig.6).
8. Screw two pilot pins into the gearbox housing in diametrically opposed positions (Fig.6).
9. Unscrew the three bolts (49) a little at a time, taking them in order (Fig.6).
10. Remove cover (27) together with shaft (36) (Fig.6). Discard O-rings (1) and (2), (19) and (51).  
**N.B.: In anticipation of future rationalisation of the design of the speedshift, the former 6-lugged friction disc has been replaced by one with 40 internal splines. The hydraulic cover and the planetary carrier cover, and the bolts for securing them, have also been replaced by new covers and bolts adapted to the design with the splined disc.**  
**These new parts were introduced as from serial no.P179018.**  
**For tractors with lower serial numbers see Workshop Manual 1646640M1.**
11. Take out disc (21), pressure plate (20), Belleville spring disc (18) and planetary carrier assembly (50).




Fig. 6



## Gearbox - Speedshift

### B. Disassembling the front cover

12. Extract circlip (37) and take out lug washer (38).
13. Withdraw shaft (36) from the front of the cover.
14. Take out needle-roller bearing (53).
15. Remove washer (39).

#### 3000 tractors

Take out the clutch slave cylinder assembly

**N.B.:** You are advised not to take the release bearing out of the slave cylinder to avoid damage to the seals.

16. Withdraw the release bearing from the slave cylinder for a distance of approx. 40 mm (Fig.8 - 5 B01), take off the bellows.
17. Unscrew the three bolts holding the cylinder in place.

#### 3100 tractors

Take out the clutch slave cylinder assembly

18. Unscrew the bolts holding the slave cylinder assembly in place and take the assembly out. Withdraw piston (48) from the cover (Fig.7).

#### 3000-3100 tractors

19. Remove seals (22) and (23) and discard them.  
**N.B.:** In 3000-3100 series tractors, new speedshift rings made of PTFE rather than cast iron and with gaps increased to 2.1/2.4 mm were introduced as from serial no. N155012.  
For tractors with serial numbers lower than this see Workshop Manual 1646640M1.
20. Remove seal rings /30\ and /31\ (discard these rings).
21. Remove lip seals /34\ and /35\ and discard them.
22. Take out needle-roller bearing (32) and discard it.
23. Drive ring carrier (33) out of cover (27) (Fig.8) (Work from the rear of the ring carrier using a plastic-faced mallet as a drift).




Fig. 7




Fig. 8

### C. Separating planetary carrier and cover assembly.

24. Place the planetary carrier assembly (50) down on a bench (with the planetary carrier cover /9\ on top).
25. Unscrew bolts (3).
26. Separate planetary carrier cover /9\ from hydraulic cover /25\ while holding sun gears /6\ and /7\ in position in planetary carrier cover (Fig.9).




Fig. 9



5E02.8



# Gearbox - Speedshift

## D. Disassembling planetary carrier assembly

- 27. Take out the 1st sun gear :
  - /7\ 36 tooth in 30 km/h version (Fig.1)
  - /6\ 30 tooth in 40 km/h version (Fig.1)
  - /7\ 30 tooth in super creeper version (Fig.2)

**N.B. : Mark the direction in which the lubricating grooves in the sun gear should face when the gear is refitted.**
- 28. Drive out spindles /8\ with a drift and a mallet (Fig.10).
- 29. Take out the planetary gears /12\.
- 30. Take out needle-roller bearings (11) and (16), spacers (14), and washers (10) and (17).
- 31. Take out the second sun gear :
  - /6\ 39 tooth in 30 km/h version (Fig.1)
  - /7\ 36 tooth in 40 km/h version (Fig.1)
  - /6\ 39 tooth in supper creeper version (Fig.2)

**N.B. : Bush (4) is a force fit in planetary carrier cover /9\.**




Fig. 10

## E. Disassembling the hydraulic cover

- 32. Take out splined hub (15).
- 33. Take out pressure plate (41), disc (42), spring washer (43), pressure plate (44), disc (45), spring washer (46) and pressure plate (47).
- 34. Withdraw piston (28) from cover /25\ (Fig.11).
- 35. Remove O-rings (26) and (29) and discard them.
 

**N.B. : In the supper creeper version, cover /25\ and piston (28) differ from those in the 30 and 40 km/h versions. The cross-sectional area of the piston is greater and this means that the diametric cutouts in the cover are larger.**




Fig. 11



## Gearbox - Speedshift

### Reassembling the planetary carrier

Clean and check the parts and replace any which are faulty.

Lubricate the needle-roller bearings.

Check that the oilways in spindles /8\ are not blocked.

#### km/h version

Fit the 39 tooth sun gear /6\ into the planetary carrier cover (Fig.12).

#### km/h version

Fit the 36 tooth sun gear /7\ into the planetary carrier cover (Fig.12).

#### super creeper version

Fit the 39 tooth sun gear /6\ into the planetary carrier cover (Fig.12).

**N.B. :** In all versions, fit the gear so that the lubricating grooves in it are facing towards face F of the planetary carrier cover (Fig.12).

Fit a needle-roller bearing (11), a spacer (14) and a needle-roller bearing (16) into a planetary gear /12\.

Fit an assembled planetary gear into the cover, with the following gears closer to face F in the respective cases (Fig.13) :

- 21 tooth: 30 km/h version
- 18 tooth: 40 km/h version
- 27 tooth: super creeper version.

**N.B. :** The planetary gear is marked with three punch marks made in a single face. Each punch mark indicates two teeth which line up.

In the case of the 40 km/h version, mark the unpunched face with three paint lines in the same positions as the punch marks made in the factory.

Fit washers (10) and (17).

Line up the planetary gear and washers with a locating rod made up locally : diameter = 16 mm, length = 80 mm (Fig.13).

Insert spindle /8\ into the unobstructed bore in face F and drive it home with a mallet until it is slightly recessed below the face (Fig.14).

**N.B. :** The oilway opening onto the circumference of spindle /8\ must face outwards.

The oilway opening onto the endface of spindle /8\ must face towards face F of the planetary carrier cover (Fig.13).




Fig. 12




Fig. 13




Fig. 14



5E02.10



# Gearbox - Speedshift

47. Repeat procedures 42 to 46 to fit the other two planetary gears.

**N.B.:** The marks (punch marks) on the three planetary gears must line up with the centre on line spaced 120° apart, as shown in Fig.15.

Once fitting of the spindles /8\ has been completed, re-check that the marks on the planetary gears line up as above.

If the marks do not line up properly, this will cause damage to the speedshift.

48. Fit the following sun gears in the respective versions :

- /7\ 36 tooth: 30 km/h version (Fig.1)

- /6\ 39 tooth: 40 km/h version (Fig.1)

- /7\ 30 tooth: super creeper version (Fig.2)

**N.B. :** In all versions, fit the gear so that the lubricating grooves in it are facing towards face F of the cover.




Fig.15

## G. Reassembling the hydraulic cover

49. Clean and check the parts and replace any which are faulty.

50. Make sure that the three openings into the 17 bar passage in the hydraulic cover /25\ are not blocked (Fig. 16).

51. Lubricate O-rings (26) and (29) and fit them to piston (28).

52. Lubricate the faces against which the piston seals bear in the hydraulic cover.

53. Place the piston in the cover with the grooves facing towards the operator.

54. Tap the piston (28) gradually home into the cover by working progressively round its face with a plastic-faced mallet (Fig. 17).

**N.B.:** Once the piston is fitted, check that no pieces have been detached from the O-rings.

55. Refit the splined hub (15) making sure it is correctly orientated.

56. Refit pressure plate (47), spring washer (46), disc (45), pressure plate (44), spring washer (43), disc (42) and pressure plate (41).

**N.B. :** Place the gaps in spring washers (43) and (46) in diametrically opposed positions.




Fig. 16





Fig. 17



## Gearbox - Speedshift


### H. Reassembling the planetary carrier assembly

57. Screw two pilot pins into the hydraulic cover /25\ in diametrically opposed positions.
58. Fit the planetary carrier cover /9\ to the hydraulic cover /25\, while holding the sun gears /6\ and /7\ in position.  
**N.B. : Position the two covers so that the balancing marks (milled grooves or paint lines) are as far away from each other as possible (Fig.18).**
59. Refit bolts (3). Bolts must be tightened to a torque of 10 - 14 Nm.
60. Tap spindles /8\ in with a pin punch so that they butt against the hydraulic cover /25\.
61. Check :
  - that discs (42) and (45) are not compressed
  - that planetary gears /12\ and sun gears /6\ and /7\ can turn freely.
62. Fit planetary carrier assembly (50) to shaft (5).
63. Fit Belleville spring disc (18).
64. Fit pressure plate (20) into housing (13).  
**N.B. : Apply three spots of grease («Amber Technical» or equivalent) to the lugs on the pressure plate.**
65. Engage friction disc (21) onto the planetary carrier assembly.



### I. Reassembling the front cover

66. Clean the mating face and the rest of the cover. Make sure that the 17 bar passage and the lubricating passage are not blocked.
67. Fit seals (22) and (23) to piston (48).
68. Lubricate the surfaces in the speedshift cover against which the piston seals bear.
69. Position the piston on the cover with its grooves facing towards the operator.
70. Tap piston (48) gradually home into the cover by working progressively round its face with a plastic-faced mallet (Fig.19).  
**N.B. : Once the piston is fitted, check that no pieces have been detached from the O-rings.**





5E02.12



# Gearbox - Speedshift

71. Clean the ring carrier and its mating face (check that the 17 bar passage and the lubricating passage are not blocked).

**N.B. : Ball (40) is crimped into the ring carrier.**

72. Position (Fig.20) :

- needle-roller bearing (32) at  $29.3 \pm 0.1$  mm from face G

- seal /34\ at 43.8 mm from face H

- wide seal /35\ at 0.3 - 0.8 mm from face G.

**N.B. : Use a press and a suitable press tool to position the bearing and seals perpendicular to the axis of the ring carrier.**

**Having fitted seals /34\ and /35\, check that the two pressure-relief passages are not blocked (Fig.21).**

73. Apply a gasketing compound (Loctite Masterjoint 510 or equivalent) to the mating face of the cover to allow the ring carrier (33) to be fitted.

74. Screw two pilot pins (1) into the cover. Engage the ring carrier in the cover bore (Fig.22).

**N.B. : Check that the openings of the 17 bar passage and the lubricating passage in the ring carrier match up with the passages in the cover.**

75. Tap the ring carrier home in the cover (Fig.22).

76. Lubricate seals /34\ and /35\.




Fig.20




Fig.21

### 3000 tractors

Refit the clutch slave cylinder assembly

77. Apply Loctite 241 to the three bolts and tighten them to torques of :

8 mm : 25 - 35 Nm

10 mm : 50 - 70 Nm.

78. Refit the bellows and push in the release bearing.

### 3100 tractors

Refit the clutch slave cylinder assembly

79. Apply Loctite 241 to the bolts which hold the clutch slave cylinder assembly in place and tighten them to the following torques :

8 mm : 25 - 35 Nm

10 mm : 50 - 70 Nm.




Fig.22





## Gearbox - Speedshift

### 3000-3100 tractors

80. Fit needle-roller bearing (1) (Fig.23) so that it is 15 - 16 mm from the front face of the shaft.

81. Lubricate shaft (36) and insert it in ring carrier (33) from the front.

**N.B. :**

**1) Make sure that the lubricating passages in the shaft are not blocked.**

**2) Cover the splines in the shaft temporarily to avoid damage to seals /34\ and /35\.**

82. Refit washer (38) and circlip (37).

83. Refit rings /30\ and /31\ and make sure that they turn freely in the grooves.

84. Having made this check, remove the rings, preform them by reducing them to approximately 1/3 of their original diameter, and coat them with miscible grease (Amber Technical or equivalent) to ensure that they will be held in position effectively when the front cover is being refitted.

85. Fit the rings into their respective grooves, making sure that :

- they do not project from the circumference of the ring carrier,

- their ends are correctly overlapped (Fig.24).

**N.B. : Even the slightest damage to the rings may give rise to leaks followed by pressure dropping in operation.**

86. Grease washer (39) and fit it into cover (27).

87. Fit new O-rings (1) and (2), (19) and (51).

88. Check that the locating pin is present in the reversing mechanism housing and that the two pilot pins are fitted.




Fig.23




Fig.24

## J. Refitting the front cover

89. Fit front cover (27) together with shaft (36).

**N.B. :**

**1) Use the PTO shaft to make mating-up easier (only when fitting on tractor).**

**2) Check that the 17 bar and lubricating passages in the cover match up with the openings in the housing.**

90. Refit bolts (24) and tighten them to a torque of 45 - 60 Nm.

91. Fit bolts (49) and tighten them to a torque of 25 - 35 Nm.

92. Reconnect the supply and bleed pipes to the clutch slave cylinder assembly.

### 3000 tractors

93. Re-unite the tractor between engine and gearbox (Section 3 A01).

### 3100 tractors

94. Re-unite the tractor between engine and gearbox (Section 3 A02).

### 3000-3100 tractors

95. Top up the oil in the housing.

96. Bleed the clutch circuit (Section 5 C01G).

97. Carry out a road test on the speedshift control.



**Gearbox - Reverse shuttle**

*5 E03 Reverse shuttle*

CONTENTS

- General	2
- Operation	2
A. Removal	4
B. Refitment and adjustment of reverse gear fork	7
- List of parts	13



5E03.2



## Gearbox - Reverse shuttle

### General

The function of the reversing mechanism is to transmit motion from the speedshift (if fitted) or the mainshaft to the secondary shaft mounted at the front of the main gearbox. In the A/B range version (4 x 4), it provides two forward speeds and two reverse speeds.

The reversing mechanism is housed in the enclosure at the back of the input gearbox behind the speedshift. It consists of :

- two helical gears **(5)** and **(23)**, carried on two roller bearings **(6)** and **(20)**. These gears are in constant mesh with the A range gear **(67)** and the B range gear **(76)** respectively (4 x 4 version), these latter gears being mounted on the secondary shaft which forms the input to the main gearbox. In the 4 x 2 version, there is only the rear gear **(5)** in constant mesh with input gear **(67)** to the main gearbox.
- a synchronmesh assembly **(18)** including a body and outer member assembly **(2)**. The body of assembly **(2)** is splined to the hollow input shaft **(19)**.
- an assembly comprising a guide rail and synchroniser control fork.
- a hollow shaft **(19)** carried in roller bearings **(24)** or **(44)** (depending on version) and **(9)**. The roller bearings are supported in two seatings in the reversing mechanism housing.
- an idler gear set **(15)** in constant mesh with gear **(23)** and the A range gear **(67)** (4 x 4 version) or the input gear (4 x 2 version) of the gearbox.

### Operation

#### Forward

##### A range

If they are moved in the rearward direction, the couplers of synchronmesh assemblies **(18)** and **(78)** respectively connect gear **(5)** to shaft **(19)** and gear **(67)** to shaft **(69)**. Gear **(5)** then applies drive to gear **(67)**, with which it is in constant mesh, to synchronmesh assembly **(78)** and to secondary shaft **(69)**.

##### B range

If they are moved in the forward direction, the couplers of the synchronmesh assemblies respectively connect gear **(23)** to shaft **(19)** and gear **(76)** to shaft **(69)**. Gear **(23)** then applies drive to gear **(76)**, with which it is in constant mesh, to synchronmesh assembly **(78)** and to secondary shaft **(69)**.

#### Reverse

The reverse speeds are obtained by means of the reverse idle gear set **(15)**. When either of the reverse speeds is selected (in the same range as was previously selected in forward), only synchronmesh assembly **(18)** moves. Drive is transmitted from hollow shaft **(19)** to secondary shaft **(69)** via the two sets of teeth on idler gear **(15)**.

#### A range

When moved forward, synchronmesh assembly **(18)** connects gear **(23)** to shaft **(19)**. Drive is transmitted from gear **(23)**, via sets of teeth **(c)** and **(d)** on gear **(15)**, gear **(67)** and synchronmesh assembly **(78)**, to secondary shaft **(69)**.


#### B range

When moved rearward, synchronmesh assembly **(18)** connects gear **(5)** to shaft **(19)**.

Gear **(5)** transmits drive to turn gear **(67)**. Gear **(67)** is in mesh with set of teeth **(d)**, which rotate with set of teeth **(c)**. Teeth **(c)** drive gear **(23)** and this turns secondary shaft **(69)** via gear **(76)** and synchronmesh assembly **(78)**.



**Gearbox - Reverse shuttle**





5E03.4



# Gearbox - Reverse shuttle

## A. Removal

Procedure where intermediate shaft has to be set up, e.g. when reverse mechanism housing (26) is being replaced.

To allow the intermediate shaft bearings to be set up correctly, the gearbox has to be removed from the tractor.

### 3000-3100 tractors

1. Split the tractor between the gearbox and the rear axle ; see Section 3 BO2.

### 3000 tractors

2. Separate the gearbox from the engine ; see Section 3 A01. Carry out procedures 11 and 12 after suspending the gearbox in slings (Fig.1).

### 3100 tractors

3. Separate the gearbox from the engine ; see Section 5 A02.A, procedure 2.

Procedure where intermediate shaft does not have to be set up.

**N.B.:** Take off the RH step. Gearbox only should be drained of oil.

### 3000 tractors

4. Split the tractor between the engine and gearbox, Section 3 A01.

### 3100 tractors

5. Split the tractor between the engine and gearbox, section 3A02.

### 3000-3100 tractors, with or without shimming.

6. Remove the PTO shaft and take out seal (6) (Fig.2).
7. Remove the bleed pipe (1) and supply pipe (2) and connector (3). Plug the passage openings (Fig.2).
8. Carry out the following procedures from Section 5 K01
  - 9 to 14 (procedure with no shimming)
  - 13 and 14 (procedure with shimming).
9. Unscrew set-screws (34) and take off the selector dog (33).
10. Unscrew the 8 bolt diam. 10 mm (4) (Fig.2).

**N.B.:** Do not remove the three bolts (5) (Fig.2) (with speedshift).




Fig. 1




Fig. 2



## Gearbox - Reverse shuttle

11. Release and withdraw the reversing mechanism by tilting it forward and down (Fig.3).

**N.B.:** Save the locating pin (1) but discard the O-rings (2) and (3) (Fig.4).

12. Place the reversing mechanism on a bench.  
13. Remove plug (29), spring (28) and locking plunger (27).

**N.B.:** Remember that this plunger is not interchangeable with the locking plungers used for 1st, 2nd, 3rd, 4th and 5th gears in the gearbox (different length).

14. Unscrew bolts (32).

**N.B.:** To prevent jerky operation of the reversing mechanism, the locked position of the guide rail was modified as from serial no P188030. For tractors with serial number prior to the above, see Workshop Manual 1646640M1.

15. Remove guide rail (31) and fork (30).

**N.B.:** To avoid the risk of wear to the bearings carrying the reverse idler gear in the reversing mechanism, the following modifications were introduced as from these serial numbers:

- P090012 : units with speedshift
- P251008 : units without speedshift
- The shape of the thrust washers was altered to prevent them from turning.
- The cast housing of the reversing mechanism was strengthened.

For tractors with serial numbers prior to the above, see Workshop Manual 1646640 M1.




Fig. 4




Fig. 3



5E03.6



# Gearbox - Reverse shuttle

- 16. Unscrew set-screw (10).
- 17. Withdraw the shaft (13) carrying the reverse idler gear (15).
- 18. Take out the two washers (12) and (17), the reverse idler gear, the two needle roller bearings (14) and (16), and the spacer (11).
- 19. Carry out procedures 9 to 11, Section 5 E02 (reversing mechanism with speedshift).
- 20. Extract circlip (25) (reversing mechanism with speedshift).
- 21. Remove spacer (36), sealing ring (37) and pipe (42) (reversing mechanism without speedshift).
- 22. Remove the shims [1].
- 23. Press out the secondary shaft (19) using a press and a suitable press tool (Fig.5 - reversing mechanism with speedshift) - (Fig.6 - reversing mechanism without speedshift).

**N.B. : There have been two alternative suppliers for the 114 mm diameter reversing synchronism assembly : CGT and ZF.**

**All 3000 series tractors produced from the beginning of production to serial no. V058034 and from serial no. P054040 onwards are fitted with a CGT assembly.**

**All 3000 series tractors produced between serial nos. V058035 and P054039 are fitted with a ZF assembly.**

- 24. Take out washer /8\.
- 25. Remove the gear and synchronism assembly (18) (Fig.7).
- 26. Take out bearing (9).
- 27. From the gear and synchronism assembly, separate: gear (5), bush (7), single-row needle-roller bearing (6), end ring (4), synchroniser brake (3), synchroniser (2), synchroniser brake (21), end ring (22), gear (23), and double-row needle-roller bearing (20).
- 28. From the secondary shaft, separate :
  - bearing (24) and washer /35\ (with speedshift).**N.B. : Mark which way round the washer fits.**
  - bearing /44\ (without speedshift).**N.B. : Mark which way round the bearing fits.**
- 29. Withdraw seal /41\ from spacer (36) and discard it (if necessary).




Fig. 5




Fig. 6




Fig. 7



## Gearbox - Reverse shuttle

### B. Refitting and adjusting the reverse gear selector fork

#### Refitment

30. Clean and check all parts and replace any which are faulty.
31. Check that oilways and their openings are not blocked in secondary shaft (19), shaft (13) and housing (26).
32. Oil shaft, bearings and seals.
33. Check the clearance between the synchroniser brakes (3) and (21) and the end rings (4) and (22).  
**N.B. : See Section 5 A01, p.9.**
34. Fit washer /35\ to shaft (19) (lubrication grooves facing towards shoulder E) (Fig.8).
35. Press bearing /24\ on until tight against washer /35\ with a press and a suitable press tool (units with speedshift) (Fig.9).
36. Press bearing /44\ on until tight against shoulder E on shaft (19) with a press and a suitable press tool.  
**N.B.: The sealed side of the bearing should face towards shoulder E (units without speedshift) (Fig.10).**
37. Carry out procedures 25 to 27 in reverse.




Fig. 8




Fig. 9




Fig. 10









5E03.8



# Gearbox - Reverse shuttle

- 38. Fit and centralise washer /8\ with its lubrication grooves facing towards gear (5) (Fig.11).
- 39. Insert secondary shaft (19) into the gear and synchromesh assembly (18).
- 40. Check that the splines on shaft (19) are engaged in the splines in the synchroniser body (2). Press the shaft in until it is fully home against the inner races of bearings (24) or /44\, and (9) with a press and a suitable press tool.
  - reversing unit with speedshift (Fig.12a)
  - reversing unit without speedshift (Fig.12b).
- 41. Refit circlip (25) (units with speedshift).
- 42. Fit spacer (36) (units without speedshift) (Fig. 14). Tighten bolt (38) to a torque of 25-30 Nm. Tighten bolts (40) to a torque of 45-60 Nm.
- 43. Hold the unit in a suitable position in a vice.
- 44. Shim up the shaft bearings
  - J1 = +0.05 to +0.2 mm**
  - units with speedshift (Fig.13).
  - units without speedshift (Fig.14).





## Gearbox - Reverse shuttle

45. Set up dial gauge with stylus against end of shaft (Fig. 15).
46. Pull on shaft to position bearing (24) correctly against circlip (25), or bearing /44\ correctly against spacer (36), depending on version.
47. Set dial gauge to zero.
48. Push on the shaft to position bearing (9) correctly, hard against the shoulder in the housing.
49. As dictated by the reading taken from the dial gauge, select shims of the appropriate thickness to give J1.
50. Remove circlip (25) (units with speedshift).
51. Remove spacer (36) (units without speedshift).
52. Fit the shims [1] selected in operation 49.
53. Refit circlip (25) (units with speedshift).
54. Where required, fit a new seal /41\ in spacer (36) so that it is a distance of 27.5 mm from face F (units without speedshift) (Fig. 16)  
**N.B. : Use a suitable tool to set up the seal perpendicular to the axis of the spacer.**
55. Cover the splines in shaft (19) temporarily so that seal /41\ will not be damaged (units without speedshift).
56. Lubricate seal /41\ and refit spacer (36), with a new sealing ring (37), and pipe (42) (units without speedshift).  
Remove the temporary covering and tighten bolts (38), smeared with Loctite 542, to a torque of 25-30 Nm. Tighten bolts (40), smeared with Loctite 542, to a torque of 45-60 Nm. Remove the temporary covering (units without speedshift).
57. Check the rotation of shaft (19) and the end float of gears (5) and (23) manually.
58. Carry out procedures 17 and 18 in the reverse order.
59. Apply Loctite 241 to set screw (10) and tighten screw to a torque of 28-43 Nm.  
**N.B.: Check the end float and backlash of the reverse idler gear (15).**
60. Carry out procedures 62 to 65 from Section 5 E02 (units with speedshift).
61. Carry out procedures 83 to 87 from Section 5 E02 (units with speedshift).
62. Carry out procedure 89 from Section 5 E02 (units with speedshift).
63. Fit the three 8 mm bolts holding the speedshift cover to the unit and tighten them to a torque of 25-35 Nm (units with speedshift).




Fig. 15




Fig. 16

64. Clean out the tapped holes in fork (30) and slide the fork onto the guide rail (31).
65. Fit locking plunger (27), spring (28) and plug (29). Tighten the plug to a torque of 50-70 Nm.
66. Coat screws (32) lightly with Loctite 221 and tighten them gently to allow the selector fork to be adjusted.



5E03.10



## Gearbox - Reverse shuttle

### Adjusting the selector fork (procedures 67 to 71)

#### General principle

The fork (30) is positioned by means of the difference in the spacing Y of the tapped holes and the spacing Z of the spot-facings in the guide rail (31).

The fork can be adjusted to move to different points by acting on either the front or rear screw (32) depending on what adjustment is required (Fig. 17).

67. Position the fork so that it is locked in the forward position.
68. Hold the synchro outer member against the gear.
69. Check that the front pad on the fork is not touching the synchro outer member.
70. Repeat the procedure (with the fork locked in the rearward position), checking that the rear pad on the fork is not touching the synchro outer member. If it is, adjust the fork by acting on screws (32) (Fig. 17).
71. Tighten the screws to a torque of 35 Nm without disturbing the adjustment.
72. On the reversing mechanism, check that cup (1) and O-ring (2) are in position (Fig. 18).
73. Fit locating pin (4) and new O-rings (3) to the housing (Fig. 19).
74. Offer up the reversing mechanism to the gearbox housing and tilt it downwards to engage its gearing in the A/B gearing (4 x 4 gearboxes).
75. At the same time, with the help of an assistant, lift the front of the intermediate shaft slightly through the opening in the selector cover to allow the cone to be engaged in the cup.
76. Locate the reversing mechanism on the locating pin.
77. Fit the bolts and tighten them to a torque of 45-60 Nm.
78. Refit pipes (1) and (2), and connector (3) (Fig. 2).

#### Version with shimmed intermediate shaft

79. Carry out procedures 21 and 22 from Section 5 A02.E.  
Carry out procedures 195 to 205 from Section 5 A02.Q.
80. Fit the reverse selector dog (33) (shimmed and unshimmed units)
81. Carry out procedures 233 to 237 from Section 5 A02.R (shimmed and unshimmed units).




Fig. 17




Fig. 18




Fig. 19



## Gearbox - Reverse shuttle

### Refitting 4 x 2 selector cover

82. Carry out procedures 238 to 243, Section 5 A02.S (shimmed and unshimmed units)

From Section 5 K01, carry out in reverse order:

- procedure 13. Tighten the bolts to a torque of 50-70 Nm (shimmed and unshimmed units).
- procedures 11 and 12 (unshimmed units).
- procedure 10 (unshimmed units).

**N.B.: Grease ball-joints (8) (14) and (21) (27) (Loctite anti-seize grease or equivalent).**

Carry out procedure 50, Section 5 K01 (unshimmed units).

Carry out procedures 8 and 9, Section 5 K01 in reverse (unshimmed units).

### Refitting 4 x 4 selector cover

83. Carry out procedures 246 to 255 from Section 5 A02.S (shimmed and unshimmed units)

Fit the earth cable lug to the cover (shimmed and unshimmed units).

Carry out procedures 256 and 257, Section 5 A02.S (shimmed and unshimmed units).

Carry out procedures 48 to 51, Section 5 K01 (unshimmed units).

### Version with shimmed intermediate shaft

#### 3000 tractors

84. Connect the gearbox to the engine. Carry out the following procedures from Section 3 A01:

- 13, 14 (except a and b)
- 15, 16
- 17, 18 (after suspending the gearbox in slings)

#### 3100 tractors

85. Connect the gearbox to the engine. Carry out the following procedures from Section 3 A02:

- 15 to 17
- 18 (except a and b)
- 19 to 22.

#### 3000-3100 tractors

86. Join the tractor at the joint between the gearbox and the rear axle, Section 3 B02.

### Version with unshimmed intermediate shaft

#### 3000 tractors

87. Connect the tractor at the joint between the engine and gearbox, Section 3 A01.

#### 3100 tractors

88. Connect the tractor at the joint between the engine and gearbox, Section 3 A02.

#### 3000-3100 tractors

89. Top up the oil in the housing and bleed the clutch circuit, Section 5 C01.F.

90. Carry out a road test on all the controls.

91. Check the selector cover joint and the joint between the gearbox and rear axle for leaks.




5E03.12


3000/3100 SERIES TRACTORS



# Gearbox - Reverse shuttle







**Gearbox - Reverse shuttle**




5E03.13

**List of parts - Reverse shuttle**


	With speedshift	Without speedshift
(1) Shims	•	•
(2) Synchroniser	•	•
(3) Synchroniser brake	•	•
(4) Synchroniser end ring	•	•
(5) Gear	•	•
(6) Single-row needle-roller bearing	•	•
(7) Bush	•	•
/8\ Thrust washer	•	•
(9) Bearing	•	•
(10) Set screw	•	•
(11) Spacer	•	•
(12) Thrust washer	•	•
(13) Shaft	•	•
(14) Needle-roller bearing	•	•
(15) Reverse idler gear	•	•
(16) Needle-roller bearing	•	•
(17) Thrust washer	•	•
(18) Synchromesh assembly	•	•
(19) Secondary shaft	•	•
(20) Double-row needle-roller bearing	•	•
(21) Synchroniser brake	•	•
(22) Synchroniser end ring	•	•
(23) Gear	•	•
(24) Bearing	•	-
(25) Circlip	•	-
(26) Housing	•	•
(27) Locking plunger	•	•
(28) Spring	•	•
(29) Plug	•	•
(30) Fork	•	•
(31) Guide rail	•	•
(32) Adjusting screw	•	•
(33) Selector dog	•	•
(34) Adjusting screw	•	•
/35\ Thrust washer	•	-
(36) Spacer	-	•
(37) O-ring	-	•
(38) Bolt	-	•
(39) Connector	-	•
(40) Bolt	-	•
/41\ Seal	-	•
(42) Pipe	-	•
(43) Connector	-	•
/44\ Bearing	-	•




5E03.13



WITH SPEEDSHIFT



WITHOUT SPEEDSHIFT







**Gearbox - A/B range and synchromesh**

5F01.1

*5 F01 A/B range gears and synchromesh mechanism*

CONTENTS

General	2
A. Disassembly	2
B. Reassembly	4



5F01.2



# Gearbox - A/B range and synchromesh

## General

Drive from the reverse shuttle gears is transmitted to the train of two gears fitted at the front end of the layshaft to give two additional forward and reverse speeds to the main gearbox.

For a general description of the A/B range operation, refer to Sections 5 E03 and 5 K01.

The A range (67) and B range (76) gears, separated by the synchromesh assembly, are located on the front end of the gearbox layshaft.

They are fitted respectively on the needle roller bearings (79), (75) and the bushes /81\, (74) and retained by the sleeve (82), the washer /73\ and the nut (68).

## 3100 Tractors

14. Split the tractor between the engine and the gearbox. Section 3 A02.

## 3000-3100 Tractors

- 15. Drain the gearbox.
- 16. Carry out procedures 8 to 14. Section 5 K01.
- 17. Carry out procedures 7 and 10 to 12, Section 5 E03.
- 18. Carry out procedures 2 to 14. Section 8 I01.
- 19. Carry out procedures 4 to 6, Section 5 D01.A.
- 20. Carry out procedures 7 to 10. Section 5 A02.C.
- 21. Remove the slider (7) (Fig.2).
- 22. Carry out procedures 62 and 55 in Section 5 D01.B
- 23. Move the selector rail rearwards to release the A/B fork.

## A . Disassembly

### Without creeper gears

#### 3000 Tractors

- 1. Split the tractor between the engine and the gearbox. Section 3 A01.

#### 3100 Tractors

- 2. Split the tractor between the engine and the gearbox. Section 3 A02.

#### 3000-3100 Tractors

- 3. Drain the gearbox.
- 4. Carry out procedures 8 to 14, Section 5 K01.
- 5. Carry out procedures 7 and 10 to 12, Section 5 E03.
- 6. Carry out procedures 7 to 11, Section 5 A02.C
- 7. Remove the slider (7) (Fig. 2).
- 8. Extract the insert (1) (Fig. 1).
- 9. Withdraw the selector rail forwards.
- 10. Remove the latch assembly (1) (Fig. 2)
- 11. Remove and clean (Fig.2) :
  - the castellated nut (2)
  - the latch (3)
  - the tapered bearing (4)
  - the cone (5)

### Tractors fitted with creeper gears

The RH hydraulic lift cover must be removed.

- 12. Set the RH rear wheel on wide track to gain access to the cover.

#### 3000 Tractors

- 13. Split the tractor between the engine and the gearbox. Section 3 A01.




Fig. 1




Fig. 2



## Gearbox - A/B range and synchromesh

### Disassembly with or without creeper gears

24. Release the lock from the nut (68) and remove it using special tool M-F 456 by engaging the synchromesh mechanism and immobilising the B gear.

**Note :** To improve the performance of the synchromesh and A/B range cones, rings with sintered grooved cones are now fitted. The new synchromesh assembly was introduced on 40 kph tractors from serial number P089036 and on 30 kph tractors from serial number P297030.

25. Remove the spur washer /73\.

26. Remove the B gear (76) together with the needle roller bearing (75) and the bush (74) (Fig.3).



27. Remove the attaching bolts (1) from the shoes (2) on the A/B fork (3) (Fig.4)

28. Remove the brake (77), the synchromesh ring (78) and the brake (80) (Fig.3) without unfastening the synchromesh hub slide.

29. Remove the fork.

**Note:** Move the A gear (67) to release the fork.

30. Remove the A gear together with the needle roller bearing (79) and the bush /81\





5F01.4



## Gearbox - A/B range and synchronesh

### B. Reassembly

#### Tractors without creeper gears

31. Clean and check the parts. Replace any which are faulty.
32. Lubricate the bushes and bearings.
33. Refit the A gear together with the needle roller bearing (79) and the bush (81) with its shoulder facing the synchronesh mechanism.
34. Move the A gear slightly forwards to refit the fork.
35. Carry out procedures 9 to 11 in reverse.
36. Refit the brake (80) and the synchronesh mechanism (78).
37. Position the shoes (2), fit the bolts after coating them with Loctite 241 and tighten them but not fully (Fig.4).
38. Check that the shoes move freely in the synchronesh slider.
39. Refit the gear (76), the brake (77), the bearing (75) and the bush (74) and check that the synchronesh brakes (77) and (80) are correctly positioned.
40. Refit the spur washer (73), the oil grooves must face the B gear.
41. Clean the thread of the shaft and of the nut (68). Coat it with Loctite 241 and tighten to a torque of 80-100 Nm. Lock the nut by bending the collar into the shaft groove.
42. Check manually that the A/B synchronesh operates correctly.
43. Carry out procedures 214 to 216 in Section 5 A02.R.
44. Carry out procedures 223 to 232 in Section 5 A02.R.
45. Carry out procedures 72 to 78 in Section 5 E03.
46. Clean the selector cover joint and carry out procedures 45 to 51 in Section 5 K01.

#### Tractors with creeper gears

47. Clean and check the parts. Replace any which are faulty.
48. Lubricate the bushes and bearings.
49. Refit the A gear together with the needle roller bearing (79) and the bush (81) with its shoulder facing the synchronesh mechanism.
50. Move the A gear slightly forwards to refit the fork.
51. Move the selector rail forwards to insert it into the A/B fork.
52. Fit the setscrew after coating it with Loctite 542 and tighten to a torque of 28-43 Nm.
53. Press in the insert coated with Loctite 542 flush with the housing.

54. Refit the brake (80) and the synchronesh mechanism (78).
55. Position the shoes (2), fit the bolts after coating them with Loctite 241 and tighten them but not fully (Fig.4).  
**Note: Check that the shoes move freely in the synchronesh slider.**
56. Refit the gear (76), the brake (77), the bearing (75) and the bush (74) and check that the synchronesh brakes (77) and (80) are correctly positioned.
57. Refit the spur washer (73), the oil grooves must face the B gear.
58. Clean the thread of the shaft and of the nut (68). Coat it with Loctite 241 and tighten to a torque of 80-100 Nm. Lock the nut by bending the collar into the shaft groove.
59. Manually check that the A/B synchronesh operates correctly.
60. Carry out procedure 216 in Section 5 A02.R.
61. Carry out procedure 83, Section 5 E01.B.
62. Carry out procedure 29, Section 5 E01.A.
63. Carry out procedures 223 to 232 in Section 5 A02.R.
64. Clean the selector cover joint and carry out procedures 15 to 27, Section 8 J01.
65. Carry out procedures 72 to 78 in Section 5 E03.
66. Clean the selector cover joint and carry out procedures 45 to 51 in Section 5 K01.

#### Tractors with or without creeper gears

##### 3000 Tractors

67. Refit the gearbox to the tractor, Section 3 A01.
68. Refit the gearbox to the tractor, Section 3 A02.

##### Tractors with creeper gears

69. Fit the creeper gear control.
70. Adjust the creeper gear control, Section 5 J01.
71. Position the wheel on normal track (creeper gears). Tighten the nuts to 400 - 450 Nm.

#### Tractors with or without creeper gears

72. Fill the gearbox with oil.
73. Remove air from the hydraulic clutch circuit, Section 5 C01G.
74. Road test the A/B range, the gears, the Hare/Tortoise range and the creeper gears (if fitted).
75. Check the following for leaks:
  - the selector cover gasket faces
  - the RH hydraulic lift cover gasket faces
  - the hydraulic unions



**Gearbox - Mainshaft**

5G01.1

5 G01 Mainshaft

CONTENTS

- General	2
A. Preliminary procedures	2
B. Disassembly and reassembly	2



5G01.2

## 3000/3100 SERIES TRACTORS



# Gearbox - Mainshaft

### General

The mainshaft (69) is fitted on the two taper roller bearings (1) (2) and (16) (17) which are supported by the two lower bearings of the main gearbox. The front end houses the A/B range gears and synchromesh assembly 4x4 (16 speed) version or the input gear 4x2 (8 speed) version.

Between the two lower bearings it supports the 1st (7) and 2nd (14) drive gears which run free and the 1st and 2nd synchromesh assembly (11) whose hub is splined on to it. At the rear end, it supports the 3rd (4x4) or 4th (4x2) (18) drive gear and the 3rd/4th synchromesh assembly (23).

The rear end carries a needle roller bearing (24) which supports the front end of the output shaft (44). The moving parts are lubricated by a central oilway and holes drilled radially. The taper roller bearings are preloaded by means of the shim (4) and shim adjusters (3) located behind the bearing cup (2).

### A. Preliminary procedures

**The gearbox must be removed in order to dismantle the mainshaft.**

#### 3000-3100 Tractors

1. Split the tractor between the gearbox and the rear axle. Section 3 B02.

#### 3000 Tractors

2. Split the tractor between the gearbox and the engine. Section 3 A01.

Support the gearbox on a sling and carry out procedures 11 and 12. Remove the PTO shaft.

#### 3100 Tractors

3. Split the tractor between the gearbox and the engine. Section 5 A02.A, procedure 2.

### B. Disassembly and reassembly

4. Carry out the following operations in Section 5 A02:

4x2 gearbox	4x4 gearbox
5 to 63	5 to 48
125 to 245	64 to 124
-	139 to 237
-	246 to 259

**Refit the gearbox to the engine.**

#### 3000 Tractors

5. Carry out procedures 13 to 18. Section 3 A01.

#### 3100 Tractors

6. Carry out procedures 15 to 22. Section 3 A02.


#### 3000-3100 Tractors

**Refit the gearbox to the rear axle (see Section 3 B02).**

7. Road test the control assembly
8. Check the selector cover and gear box gasket faces for leaks.



# Gearbox - Mainshaft





## **Gearbox - Layshaft**

### *5 H01 Layshaft*

#### CONTENTS

- General	2
A. Preliminary procedures	3
B. Disassembling layshaft	4
C. Reassembling layshaft	5
D. Refitting input gearbox	6





5H01.2

## Gearbox - Layshaft

### General

The layshaft and the gears it carries form the upper drive line in the gearbox. The shaft (54) carries the driven gears for 1st speed (60), 2nd speed (59), 3rd speed (56) and 4th speed (55). In the 4 x 2 version (8 speeds), (55) is the 3rd speed gear and (56) the 4th speed gear. The set of teeth at the rear are in constant mesh with the Lo gear. The front of the shaft is carried by a taper roller bearing (63) (64) in the rear of the input gearbox and at the rear it is carried in a bearing (52) (53) mounted in the bearing at the rear of the gearbox.

The front of the shaft is carried by a taper roller bearing (63) (64) in the rear of the input gearbox and at the rear it is carried in a bearing (52) (53) mounted in the bearing at the rear of the gearbox.

Gears (56) and (59) are held in position either by two circlips (57) and (58) in version A, or by a spacer (57) in version B. The running clearance the gears require is obtained by machined tolerances in version A and by inserting shims [58] in version B.




Fig. 1



## Gearbox - Layshaft

### A. Preliminary procedures

To allow the bearings carrying the layshaft to be correctly shimmed, the gearbox must be removed.

#### 3000-3100 tractors

1. Split the tractor between gearbox and rear axle. Section 3 B02.

#### 3000 tractors

2. Separate the gearbox from the engine. Carry out procedures 11 and 12, Section 3 A01 (having suspended the gearbox in slings). Remove the PTO shaft.

#### 3100 tractors

3. Separate the gearbox from the engine. Carry out procedure 2, Section 5 A02.A.
4. Remove bleed pipe (1), supply pipe (2) and connector (3) (plug the openings into the passages) (Fig.2).

#### 3000-3100 tractors

##### Removing the selector cover

5. Carry out procedures 13 and 14, Section 5 K01.
6. Unscrew the 8 x 10 mm bolts (4) (Fig.2).  
**N.B.: Do not unscrew the three bolts (5) (Fig.2)**
7. Release and withdraw the input gearbox by tilting it forwards and down (Fig.3).  
**N.B.: Keep locating pin (1) but discard O-rings (2) and (3) (Fig.4).**
8. Position the input gearbox on a bench.




Fig. 2




Fig. 4




Fig. 3



5H01.4

## Gearbox - Layshaft

### B. Disassembling the layshaft

9. Withdraw the assembled shaft (Fig.5).
10. Remove washer (50).
11. Remove shims [51]
12. Remove cup (52).

#### Disassembling shaft (54) (Fig.6)

A new shaft arrangement was introduced as from serial number P345012 (version b).

Previous tractors were fitted with version a.

13. Extract bearing cones (53) and (63).  
*N.B.: Keep the cups and cones together in pairs if they are going to be re-used.*
14. Remove circlip (61).
15. a) Take off the 1st speed gear (60) and the 2nd speed gear (59).  
b) Take off the 1st speed gear (60), shims [58], and the 2nd speed gear (59).
16. a) Remove circlips (58) and (57).  
b) Remove spacer (57).
17. Take off the following gears:
  - 4th speed (56) (4 x 2 gearbox)
  - 3rd speed (55) (4 x 2 gearbox)
18. Take off the following gears:
  - 3rd speed (56) (4 x 4 gearbox)
  - 4th speed (55) (4 x 4 gearbox)
19. Drive out needle-roller bearing (62) (Fig.7) and discard it.




Fig. 6




Fig. 5




Fig. 7



## Gearbox - Layshaft

### C. Reassembling layshaft

20. Clean and check the parts and replace any which are faulty.

**A new shaft arrangement was introduced as from serial number P345012 (version b).**

**Previous tractors were fitted with version a.**

21. In a press, press needle-roller bearing (62) in until it is bearing against the shoulder in shaft (54) (Fig.8).

**N.B.: Check that the needle-rollers can turn normally in their cages.**

22. a) Carry out procedures 14 to 18 in reverse.

**N.B.: Make sure that the circlips seat cleanly in their grooves.**

**Clearance J1 is set by machined tolerances (Fig.9).**

b) Carry out procedures 17 and 18 in reverse.

Slide spacer (57) onto the shaft.

Fit 2nd speed gear (59), 1st speed gear (60) and circlip (61).

With a set of feeler gauges, measure the gap between 1st speed gear (60) and 2nd speed gear (59).

As a function of the gap measured, select shims of a thickness to give (Fig.9) :

**J1 = 0 to +0.25 mm**

Remove circlip (61) and gear (60).

Slide the shims selected as above onto the shaft.

Refit the gear and circlip.

**N.B.: Make sure that the circlip is correctly fitted.**

23. Press on cones (63) and (53) with a suitable press tool (Fig.10).

24. Refit cup (52) and replace the assembled shaft.




Fig. 8




Fig. 9




Fig. 10



## Gearbox - Layshaft

### D. Refitting input gearbox

25. Fit new O-rings (3) and the locating pin (4) to the gearbox housing (Fig. 11).  
Check that cup (1) is present in the input gearbox housing and fit a new O-ring (2) to the housing (Fig. 12).
26. Engage the input gearbox assembly in the gearbox housing by tilting it back and down to engage the gears of the reverse shuttle in the A/B gearing (4 x 4 gearbox).
27. At the same time, with the help of an assistant, raise the front of the layshaft slightly through the opening in the selector cover to engage the cup in the cone.
28. Locate the input gearbox on the locating pin.
29. Fit the bolts and tighten them to a torque of 45 - 60 Nm.
30. Refit pipes (1) and (2) and connector (3) (Fig. 2).




Fig. 11

#### Shimming the layshaft.

Carry out procedures 195 to 205 from Section 5 A02.Q.

#### Refitting 4 x 2 selector cover

31. Carry out procedures 238 to 243 from Section 5 A02.S.  
Fit the earth cable lug to the cover.  
Carry out procedure 13, Section 5 K01, in reverse.  
Tighten bolts to a torque of 50 - 70 Nm.

#### Refitting 4 x 4 selector cover

32. Carry out procedures 246 to 255 from Section 5 A02.S.  
Fit the earth cable lug to the cover.  
Carry out procedures 256 and 257 from Section 5 A02.S.




Fig. 12

#### Fit gearbox to engine.

##### 3000 tractors

33. Carry out procedures 13 and 14 (except a), Section 3 A01.
34. Carry out procedures 15 and 16, Section 3 A01.
35. Carry out procedures 17 and 18 (after suspending the gearbox in slings), Section 3 A01.

##### 3100 tractors

36. Carry out procedures 15 to 17, Section 3 A02.
37. Carry out procedures 18 (except a), Section 3 A02.
38. Carry out procedures 19 to 22, Section 3 A02.

##### 3000-3100 tractors

Join the tractor between gearbox and rear axle, Section 3 B02.

39. Check .
  - all circuits for leaks
  - that electrical circuits are working

40. Carry out road test on controls.

41. Check that there are no leaks at the joints (selector cover joint and joint between gearbox and rear axle) or the connections.



**Gearbox - Output shaft**

5101.1

*5 101 Output shaft*

CONTENTS

- General	2
A. Removing selector cover	3
B. Removing guide rail and selector forks	3
C. Removing output shaft	4
D. Refitting and shimming output shaft	5
E. Refitting guide rail and selector forks	8
F. Refitting selector cover	11



5101.2

# Gearbox - Output shaft

## General

The output shaft transmits the drive provided by the various gear ratios to the rear axle transfer shaft. It is mounted at the rear of the gearbox on the lower transmission drive line.


At the front it is carried in a needle-roller bearing located in the bore in the mainshaft and at the rear in two taper bearings mounted with their tapers opposed.

The shaft (44) carries :

- a driving gear (29) which is mounted to rotate freely on combination bearings (28) and (30).
- an assembly consisting of gear (36) and spacer (35), which are mounted to turn freely.
- a coupler (31) and its hub (33) which are splined to rotate together.

To ensure that the complete assembly will operate correctly under the forces applied to the transmission, various settings have to be made with shims :

- **setting J3** : by means of shim or shims [47], this setting allows the clearance to be taken up between cones (39) and (40) and their respective cups.
- **setting J4** : shims or shims [38] placed between the shoulder on shaft (44) and cone (39) allow end float for gear (29).
- **setting J5** : shim or shims [42] placed between cone (40) and packing shim [43] take up the axial clearance which cones (39) and (40) have on shaft (44).






## Gearbox - Output shaft

### A. Removing selector cover (Fig.2)



1. Before doing anything to the selector cover, split the tractor between gearbox and rear axle. Section 3 B02.
2. Remove the A/B range supply pipe (1). (4 x 4 gearbox). Remove bolts (2)  
**N.B.:** On gearboxes with creeper gears, remove the control cable support and mark the position of bolt (3).
3. Remove cover (4) and bolt (5).



### B. Removing guide rail and selector forks

**N.B. :**

- 1) Gearbox fitted with creeper gears.  
Remove pin (1), locknut (2), adjustable locking screw (3), and fork (4) together with sleeve (5) (Fig.3).
- 2) Mechanical locking for the Hi-Lo (Hare/Tortoise) range was introduced in production as from serial number P107048.  
For tractors with numbers lower than this, see Workshop Manual 1646640M1.
4. Remove plugs (1), springs (2) and locking plungers (3) from forks (5) and (6) (Fig.4).
5. Slacken off lock ring (21) with spanner 3615334 M01 (Fig.5).
6. Engage 4th gear (4 x 2 gearbox ) or 3rd gear (4 x 4 gearbox).







5101.4

## Gearbox - Output shaft

7. Free off cone (24) on guide rail (7) with a bronze drift (Fig.6).
8. Unscrew set screw (8).
9. Remove : bearing (15), guide rail (7) from the rear, forks (5) and (6), and locking assembly (25).
10. Remove : lock ring (21), locking gate (22), bearing (23), and cone (24).  
Remove : set screw (19), piston (13), Hi-Lo fork (20), bolt and washer (17), slider (18), and cylinder (10).  
**N.B.:** Discard O-rings (11), (12) and (14). Leave the A/B fork (4) in the housing.

### C. Removing output shaft

**N.B.:** Remove the creeper gearbox if the tractor is fitted with one (see 5 AO2.F).

11. Unscrew the three bolts (41).
12. Take off the retainer ring (46).
13. Withdraw bearing cup (48).  
**N.B.:** Keep cups and cones together in pairs if they are to be re-used.
14. Take off circlip (45)
15. Remove packing shim /43\ and adjusting shims [42].
16. Remove bearing cone (40).  
**N.B.:** Where shimming was needed between the cones, take off the shims [47].
17. Remove cone (39).
18. Take off shims [38].  
**N.B.:** In all versions, the Hi-Lo range synchroniser was replaced by a coupler as from serial number V252037. For tractors with earlier numbers, see Workshop Manual 1646640M1.
19. Slide the Hi-Lo coupler (31) (Fig. 7) onto the Lo gear (36).
20. Pull shaft (44) towards the rear.
21. Remove spring ring (34) with tool MF460 and discard it (Figs.7 and 8).
22. Remove the shaft.
23. Through the opening in the selector cover take out: hub (33) and its coupler, gear (29), synchroniser brake (25), the two thrust washers (32), (27) and the Lo gear (36).  
**N.B.:** Keep the synchromesh brake (25) paired with gear (29) if they are to be re-used.
24. Remove cup (37).




Fig. 5




Fig. 6




Fig. 7



# Gearbox - Output shaft





- 25. Remove circlip (49).
- 26. Remove circlip (19), washer (22) and needle-roller bearing (24).

## D. Refitting and shimming output shaft

- 27. Clean and check the parts and replace any which are faulty.
- 28. Fit circlip (49) and cup (37).  
**N.B.:** The Hi-Lo range synchroniser was replaced by a coupler as from serial number V252037.  
**For tractors with earlier numbers, see Workshop Manual 1646640M1.**
- 29. On shaft (44) refit needle-roller bearing (24), washer (22) and circlip (19). Engage the shaft in the housing without gears.
- 30. Slide cones (39) and (40) onto the shaft.

### Setting J3

- 31. The purpose of this procedure is to prepare for the making of setting J3 (Fig.9). Hold cones (39) and (40) hard against the shoulder on shaft (44) by applying manual pressure to them. Fill the gap between the rear face of cone (40) and the groove for circlip (45) with shims [42] and packing shim /43. Select a new circlip such that it will be a slightly tight fit in the groove (Fig. 10).
- 32. Make the setting (Fig. 11) with shims to give :  
**J3 = -0.05 to +0.05 mm**  
The setting consists in taking up the clearance between cone (39), (40) and cups (37), (48) while observing the tolerance given above.





5101.6

**Gearbox - Output shaft****33. Fit circlip (45)**

**N.B.:** Fit the packing shim on the same side as the circlip.

**34. Fit cup (48) and retainer ring (46).****35. Tighten bolts (41) to a torque of 27 - 32 Nm.****36. Set up a dial gauge against the end-face of shaft (44) (Fig. 12).**

**N.B.:** In the case of gearboxes fitted with creeper gears, use the gearbox ring (Fig. 13) rather than the retainer ring. Tighten the bolts to a torque of 34 - 52 Nm.

**37. Push on the shaft while turning it alternately clockwise and anticlockwise to seat the cones properly in the cups.****38. Zero the dial gauge.****39. Repeat procedure 37 pulling on the shaft.****40. If the end float measured is greater than 0.05 mm, select shim(s) X [47] to give:**

$$J3 = -0,05 \text{ à } + 0,05$$

**Important:** The shim or shims X [47] selected for J3 must be in place between the cones for the following settings.

**Setting J4****41. Remove circlip (45).****42. Take out packing shim /43\ and adjusting shims [42].****43. Measure the total thickness Y of shims [42] and /43\ (this measurement will be helpful for setting J5).****44. Remove bolts (41) and retainer ring (46).****45. Take out cup (48), cones (40), (39) and shaft (44).****46. Fit together in the housing the following : Lo gear (36), coupler (31), hub (33), thrust washer (32), gear (29) (4th speed in 4 x 4 gearbox, 3rd in 4 x 2 gearbox), together with its combination needle-roller bearings (30) and (28), thrust washer (27), and synchro brake (25).**

**N.B.:** If bush (35) is showing signs of wear, replace the gear complete (the bush is reamed after fitting).

If the combination bearings (30) and (28) are worn, replace the gear complete (bearings are fitted in the factory).


**47. Insert output shaft (44) while holding the gear assembly in position (Fig. 14).****48. Pull the shaft back slightly to expose the groove for the spring ring (34)**

Fig. 12




Fig. 13




Fig. 14



## Gearbox - Output shaft

5101.7

49. Fit spring ring (34) with tool MF 459 (Fig.15).  
**N.B.:** Check that the spring ring is properly seated.
50. Slide the following onto the shaft: cone (39), the shim or shims X [47] selected in procedure 40, cone (40) and cup (48).
51. Fit retainer ring (46) and tighten bolts (41) to a torque of 27 - 32 Nm.
52. Make setting J4 (Fig.16) to give :  
**J4 = +0.2 to +0.4 mm**  
This setting consists in providing end float for gear (29) (Hi 4th speed in 4 x 4 gearbox . Hi 3rd gear in 4 x 2 gearbox).
53. Carry out procedures 36 to 39.
54. As dictated by the reading taken from the dial gauge, find the thickness required for shim(s) Z [38] to give J4.
55. Remove bolts (41) and retainer ring (46).
56. Remove cup (48).
57. Withdraw cones (40) and (39), and shim(s) X [47].
58. Slide the following onto the shaft: shim(s) Z [38], cone (39), shim(s) X [47] and cone (40).

**Setting J5.**

59. Make setting J5 (Fig. 17) to give :  
**J5 = No end float**  
This setting consists in taking up the end float which cones (40) and (39) have on shaft (44).
60. From the thickness measured for shim(s) Y [42]/43\ in procedure 43 find the thickness required for shim(s) Z [38] and X [47] to give **J5 = Y - (Z+X)**
61. Carry out procedures 34 and 35.
62. Slide the shims of the thickness selected in procedure 60 onto the shaft.
63. Fit circlip (45).  
**N.B.:** Position packing shim /43\ on the same side as the circlip.  
The circlip should be a slightly tight fit in its groove. Check that it is properly seated.  
**N.B.:** Refit the creeper gearbox (if fitted). See Section 5 A02.N.
64. Check by hand that the shaft and its gears turn freely.
65. Check that the 3rd/4th speed synchroniser and the Hi-Lo coupler are operating normally.





Fig. 16




Fig. 17



5101.8



## Gearbox - Output shaft

### E. Refitting guide rail and selector forks (Fig.18)

66. Check that the hydraulic ports in the Hi-Lo cylinder (10) are not blocked.
67. Fit O-ring (11) to cylinder (10) and insert cylinder in gearbox housing.
68. Fit Hi-Lo fork (20) to the coupling ring.
69. Fit O-rings (12), (14) to piston (13) and then slide the piston into the bore in the cylinder.  
**N.B.: Line up the seatings for the adjusting screws with the tapped holes in the fork. Hold the piston in position with an adjusting screw (19).**

70. Clean and put together mechanical locking gate (22), taper bearing (23), cone (24) and lock ring (21).
71. Fit the 3rd/4th speed fork (6), the 1st/2nd speed fork (5) and the locking gate assembly (25).
72. Insert the guide rail (7) from the rear of the housing and slide it through the piston, locking gate assembly and forks.  
**N.B.: In the case of 4 x 4 gearboxes, do not forget the A/B fork (4).**
73. Fit bearing (15) and tighten bolts (16) to a torque of 27-32 Nm.
74. Clean set screw (8) with a solvent, apply Loctite 542 to it and tighten it to a torque of 28-43 Nm.




Fig. 18



## Gearbox - Output shaft

75. Fit locking plungers (3) and springs (2) and tighten plugs (1) to a torque of 50-70 Nm.

**N.B.:** Gearboxes fitted with creeper gears (Fig.19).

Fit sleeve (5), fork (4) and pin (1).

Position the fork so that locking screw (3) is over the flat on guide rail (6) (between the two locking recesses).

Tighten the screw fully in so that the ball is compressed.

Unscrew the screw one quarter turn.

Apply Loctite 241 to nut (2) after cleaning it with solvent.

Tighten the nut to a torque of 15-20 Nm.

Check that the fork locks correctly.




Fig. 19

76. Adjusting the Hi-Lo fork.

General principle :

The fork (20) is positioned by means of the difference in the spacing **Y** between the tapped holes and the spacing **Z** of the spot-facings in piston (13).

The fork can be adjusted to move to different points by acting on either the front or rear screw depending on what adjustment is required (Fig.20).

77. Set control piston (13) and coupling ring (31) to the Hi range.
78. Hold the coupling ring pressed against the Hi range gear (29) (Fig.21) (3rd speed in 4 x 2 gearbox, 4th in 4 x 4 gearbox).




Fig. 20




Fig. 21



5101.10



# Gearbox - Output shaft

79. Having cleaned the two adjusting screws (19) with a solvent and coated them lightly with Loctite 221, use them to adjust the position of fork (20) to set a clearance of  $J1 = 0.3 \text{ mm}$  between the rear face of the pad and the coupling ring (Figs.21 and 22).

**N.B.:** For making the adjustment use the locally fabricated tool mentioned in sub-section U of 5 A02.

80. Set control piston (13) and coupling ring (31) to the Lo (Tortoise) range.

81. Check that there is a clearance of  $J2 = \text{min. of } 0.3 \text{ mm}$  (dimension determined by setting  $J1$ ) between pad and coupling ring with the latter hard against Lo range gear (36) (Fig.23). Tighten the screws to a torque of 35 Nm without disturbing the adjustment.

**N.B.:** In the Lo (Tortoise) position, if face X of the pad on fork (20) is in contact with the coupling ring (Fig.23), increase clearance  $J1$ .

82. Set the fork to the Lo position.

83. Unscrew lock ring (21) slightly. Apply Loctite 270 sparingly to the thread on cone (24).

84. Set the forks to the neutral position.

85. Set clearances  $J3$  and  $J4$  to be of equal size (min. = 0.3 mm) so that the mechanical locking gate (22) can operate freely (Figs.24 and 25)




Fig. 22




Fig. 23




Fig. 24




Fig. 25



## Gearbox - Output shaft

86. Tighten lock ring (21) to 50 Nm with spanner 3615334 M01 and a spring balance (Fig.26).
87. Apply Loctite 648 to the clamping face of slider (18) and Loctite 648 to bolt (17). Fit the bolt and washer.
88. Adjust the clearances J5 and J6 (min. of 0.3 mm) between the slider and the locking gate to be equal in the Hi and Lo positions (Figs.21, 23, 27 and 28).
89. Tighten the bolt to a torque of 27-32 Nm.
90. Check the operation of the Hi-Lo (Hare/Tortoise) range and the locking gate.
91. Check the changing of the gears and of the A/B range.




Fig. 26

### F. Refitting selector cover

#### 4 x 2 gearbox (Fig.30)

92. Clean the mating face of the cover (56).
93. Set the reverse selector to the neutral position.
94. Engage 1st gear.
95. Apply a gasketing compound (Loctite Master joint 510 or equivalent) to the mating face of the gearbox housing.  
**N.B.: Do not forget to fit bolt (1) to the housing (Fig.29).**
96. Position the two levers on the cover to the left and parallel to one another.




Fig. 27




Fig. 28




Fig. 29





5101.12



## Gearbox - Output shaft

97. Fit the cover to the gearbox, making sure that the levers are correctly engaged in the selector forks (Fig.30).
98. Refit the bolts which hold the selector cover in place and tighten them to a torque of 50-70 Nm. Refit the support for the creeper gear cable (if fitted).
99. Check :
  - the -changes to all the gears and the change between the Hi-Lo positions.
  - the operation of the reversing mechanism.

### 4 x 4 gearbox

100. Clean the mating face of the cover (57).

#### In the gearbox :

101. Check that the reverse selector is in the neutral position and that the A/B fork is in the B position (the forward position).
102. Engage 1st gear.

#### At the cover :

103. Take out pressure valve (58) and remove plunger (59) (Fig.31).
104. Clamp actuating shaft (53) in the B position with tool 3615053 M01 (Fig.31). Tighten down moderately hard.
105. Set the finger /61\ for actuating the A/B fork to the B position (the forward position) (Fig.32).
106. Move the gear lever to the left (into 1st gear).
107. Apply a gasketing compound (Loctite Master joint 510 or equivalent) to the mating face of the gearbox housing.

**N.B.:** Do not forget to fit bolt (1) to the housing (Fig.29).




Fig. 30




Fig. 31




Fig. 32



## Gearbox - Output shaft

108. Offer up the cover to the gearbox, engaging fingers (54), (66) in the reverse selector fork and finger /61\ in the A/B fork, and then engage actuating finger (36) in the 1st/2nd gear fork and the mechanical locking gate (Fig.33).
109. Seat the cover down.
110. Fit the bolts and tighten them to a torque of 50 - 70 Nm.  
Remove tool 3615053 M01.  
**N.B.:** In the case of a gearbox fitted with a creeper gearbox, fit cable support (1) (Fig.34). To ensure the cover is correctly located, first tighten bolt /3\ (Fig.34). With the help of the levers, check by hand that the actuating fingers are correctly engaged in the selector forks.
111. Fit plunger /59\ and screw in pressure valve (58) and tighten it to a torque of 18-20 Nm. Refit the A/B supply pipe.
112. Reconnect the tractor between gearbox and rear axle. Section 3 B02.
113. Check
  - that none of the circuits leak
  - that the electrical circuits are working.
114. Carry out a road test on the controls.
115. Check that there are no leaks at the joints between selector cover and gearbox and between gearbox and rear axle




Fig. 33




Fig. 34



*5 J01 Creeper gears*

CONTENTS

- General	2
- Operation	2
A. Removing creeper gearbox and ring gear	4
B. Disassembling planetary carrier	4
C. Reassembling planetary carrier	5
D. Refitting creeper gearbox and ring gear	5
E. Adjusting control mechanism	5
F. Circuit diagram	6



5J01.2

## 3000/3100 SERIES TRACTORS



# Gearbox - Creeper gears

### General

The creeper gear reduction gearbox consists of an epicyclic gear train comprising a planetary carrier and ring gear assembly mounted at the rear of the main gearbox. It is operated from a lever situated on the console in the cab, the lever being connected by a cable to an arm fitted on the right at the front of the centre housing. The arm shifts the fork which controls the coupling sleeve.

#### 1st generation 3000 tractors (serial numbers prior to P107048)

When the creeper gear control is engaged, the «Auto-tronic» system automatically permits a changeover to the Lo range.

#### New generation 3000 tractors and 3100 tractors

A system for locking the Hi-Lo (Hare/Tortoise) ranges was introduced as from serial number P107048.

The creeper gears should only be selected if the main gearbox is in the Lo range.

### Operation

Coupling sleeve (8) is splined to connecting shaft (21). If lever A is moved towards the creeper gear position (Figs. 1 and 2), this shifts coupling sleeve (8) towards the rear and engages its external teeth with planetary carrier (1). The speed of connecting shaft (21) is then 1/4 of the speed of the output shaft.



In the normal gears, coupling sleeve (8) is moved forward to connect the output shaft of the gearbox to the connecting shaft (21), thus providing direct transmission.

#### Special points : New generation 3000 tractors and 3100 tractors

If the creeper speed range is selected and the Hi (hare) light flashes, this indicates to the operator that he is in the Hi position and that it is essential for him to change to the Lo position.

The electrical signal indicating that the creeper speed range has been selected is transmitted from switch C. Switch C is mounted on the control box in the manner shown in Fig. 1 in the case of tractors without an «Auto-tronic» or «E» and in the manner shown in Fig 2 in the case of tractors with an «Autotronic».


Tractors without an «Autotronic» have a button on the dashboard which permits a changeover to the Lo range.





**Gearbox - Creeper gears**

General arrangement drawing (Fig.3)



**List of parts**

- |                             |                                 |
|-----------------------------|---------------------------------|
| (1) Planetary carrier       | (11) Spacer                     |
| (2) Thrust washer           | (12) Pin                        |
| (3) Front disc              | (13) Sector plate               |
| (4) Spring washer           | (14) Sector plate               |
| (5) Bolt                    | (15) Backing disc               |
| (6) Spring ring             | (16) Circlip                    |
| (7) Internally toothed bush | (17) Planetary carrier assembly |
| (8) Coupling sleeve         | (18) Thrust washer              |
| (9) Planetary gears         | (19) Ring gear                  |
| (10) Needle rollers         | (20) Locating pin               |
|                             | (21) Connecting shaft           |




5J01.4



**Gearbox - Creeper gears**

Exploded view (Fig.4)



**A. Removing the creeper gearbox and ring gear**

1. Take off the RH hydraulic cover.  
Carry out procedures 1 to 14, Section 8 I01.

**Removing support for top link - driving gear - intermediate shaft - PTO clutch**

2. Two-speed PTO :  
- carry out procedures 1 to 7, Section 6 D01.  
- carry out procedure 3, Section 6 G01.

**Four-speed (economy PTO) :**

- carry out procedures 60 to 76, Section 6 D01.
- carry out procedure 14, Section 6 G01.

**Removing sleeve/connecting shaft/coupling sleeve assembly and fork**

3. Carry out procedures 3 to 16, Section 5 D01.A.

**Removing creeper gearbox and ring gear**

4. Take out bolts (5) and spring washers (4).
5. Take off front disc (3).

6. Withdraw planetary carrier assembly (17) and thrust washers (2) and (18)

7. Remove ring gear (19).

**N.B. Locating pins (20) should be left in the ring gear.**

8. Remove backing disc (15).

**N.B. Be careful not to apply any traction to the output shaft.**

**B. Disassembling planetary carrier**

9. Remove circlip (16)

10. Drive out pins (12).

11. Take out sector plates (13) and (14).

12. Take out planetary gears (9)

**N.B.: There are 54 needle-rollers (10) per planetary gear (two rows of 27 needle-rollers separated by a spacer (11)). Replace the planetary carrier (1) if there is any damage to internally toothed bush (7).**



## Gearbox - Creeper gears

### C. Reassembling planetary carrier

13. Check and clean the parts and replace any which are faulty.
14. Refit planetary gears (9). Use a miscible grease («Amber Technical» or equivalent) to fit needle-rollers (10).
15. Refit sector plates (13) and (14).
16. Refit pins (12), making sure they are the correct way round to allow circlip (16) to be fitted.
17. Fit circlip (16).  
Check the end float of each planetary gear and that it turns freely by hand.

### D. Refitting creeper gearbox and ring gear

18. Carry out procedures 177 to 181, Section 5 A02.N  
**Refitting fork and sleeve/connecting shaft/coupling sleeve assembly**

19. Carry out procedures 22 to 31, Section 5 D01.A

**Refitting PTO clutch, intermediate shaft, driving gear and support for top link.**

20. **Two-speed PTO**

- carry out procedures 5 to 7, Section 6 G01
- carry out procedures 8 to 18, Section 6 D01.

**Four-speed PTO**

- carry out procedures 16 to 18, Section 6 G01
- carry out procedures 79 to 88, Section 6 D01.

**Refitting RH hydraulic cover**

21. Carry out procedures 15 to 33, Section 8 I01

22. Carry out road test on creeper gears.
23. Test the operation of the PTO and its brake

### E. Adjusting control mechanism (Fig.5 and 6)

**N.B.: Procedures 25 to 28 should be carried out when replacing the control cable.**

24. Move control lever A to the «Creeper» position.
25. Screw clevis (1) right to the end of the threaded part of cable (6).
26. Attach clevis (1) to lever A with pin (7) and tighten up nut (2).
27. Adjust cable ferrule (5) to bring nut (3) flush with the end of its threaded portion.
28. Tighten up nut (4).

**N.B. Check that the cable is not under any stress.**

29. Move arm B to the «Creeper gear» position (Fig.6) (external teeth on coupling sleeve (8) engaged in rearwards direction (Fig.3)) - fork locked.
  30. Screw clevis (9) right to the end of the threaded portion of cable (6) (Fig.6).
  31. Attach clevis (9) to arm B with pin (10) and tighten nut (11) (Fig.6).
  32. Adjust ferrule (12) with nut (13), while making sure that arm B remains properly locked.
  33. Tighten up nut (14).
- N.B. After tightening the nut, check that the cable is not under stress.**
34. Check that the control mechanism locks in the «direct transmission» position




Fig. 5




Fig. 6




5J01.6



**Gearbox - Creeper gears**

**F. Circuit diagram**



**Key**

- 12. Creeper gear indicating switch
- 16. Hi indicator light
- 17. Lo indicator light
- 59. Relay

**Colour codes**

- B. White
- BLC. Light blue
- G. Grey
- M. Light brown
- N. Black
- R. Red
- V. Green
- VF. Dark green





***Gearbox - Super creeper speeds***

5J02.1

*5 J02 Super creeper speeds*

CONTENTS

- General _____	2
- Operation _____	2
A. Removing the accumulator _____	2
B. Refitting the accumulator _____	2
C. Electrical diagrams _____	4-5



5J02.2

## 3000/3100 SERIES TRACTORS



# Gearbox - Super creeper speeds

### General

The tractors fitted with super creeper speeds use the same mechanical reduction assembly as the standard «creeper gear» version. This reduction gear is fitted behind the main box, on the output shaft (see chapter 5 J01).

They also use the reduction function of the hydro-mechanical device included in the input housing. In this configuration, the following modifications have been made (Fig. 1):

- planet wheels / sun wheels reduction ratio increased.
- special hydraulic cover (25), with a larger clutch piston.

In addition, a hydraulic accumulator is fitted to the right-hand side of the box.

### Operation

Moving lever A to the snail position (Fig. 2) causes, at the same time, engagement of the two reduction devices.

The switch (1) closes the solenoid valve which controls the hydro-mechanical reduction device (input housing) putting the forward reduction device into the Tortoise range.

At the same time, the rear mechanical reduction gear goes into the slow position (see chapter 5 J01).

The movement of the two reduction devices into the Tortoise range drives the rear axle connecting shaft at a speed of 1 revolution per 7.8 revolutions of the box input shaft. When lever A is moved back to the Hare position, the transmission of movement is direct (ratio of 1:1). From serial number P333039, tractors having the «super creeper speeds» version are fitted with an accumulator (Fig. 3) connected to the pipe (2) coming from the 17 bar valve. The purpose of this is to reduce the pressure drop when the super creeper range is engaged. This device is held by a bracket fixed to the selection cover.

### A. Removing the accumulator

1. Remove bolt (3)
2. Disconnect union (4)
3. Remove accumulator (5)
4. Remove fixing bracket (6)

### B. Refitting the accumulator

1. Reverse operations 1 to 4.

**Note: Apply a sealant between the union and accumulator (Loctite 542 or equivalent).**

**For correct operation, maintain nitrogen inflation pressure of 8 bar, using the valve (7) (Fig. 3). Pressure to be checked once a year.**



# Gearbox - Super creeper speeds




Fig. 1




Fig. 2




Fig. 3




5J02.4

# Gearbox - Super creeper speeds

## C. Electrical diagram

### 1. With «Autotronic»



#### Key

- 1 - «Autotronic» box
- 7 - Hi-Lo (Hare/Tortoise) switch
- 21 - Starting switch
- 60 - Super creeper speed solenoid valve
- 61 - Low-pressure pressure-sensitive switch
- 62 - Super creeper speed switch

#### Colour codes

- B. - White
- J. - Yellow
- N. - Black
- R. - Red
- Ro. - Pink
- V. - Green

#### Abbreviations


- +AC = + After contact
- +P = Permanent +
- C = Connection
- C = Connection



# Gearbox - Super creeper speeds

5J02.5

## 2. Without «Autotronic»



### Key

- 7. Hi-Lo (Hare/Tortoise) switch
- 11. Low-pressure pressure-sensitive switch
- 21. Starting switch
- 60. Super creeper speed solenoid valve
- 61. Low-pressure pressure-sensitive switch
- 62. Super creeper speed switch
- 63. Telebreaker

### Colour codes

- B. White
- G. Grey
- J. Yellow
- N. Black
- R. Red
- Ro. Pink
- VF. Dark green

### Abbreviations

- +AC = + After contact
- P - Permanent +



**Gearbox - Selector cover 16 speed**

5 K01.1

*5 K01 Selector cover (4 x 4) 16 Speed*

CONTENTS

- General	2
- Operation	2
A. Removal	8
B. Disassembly	9
C. Reassembly	10
D. Refitment	11
E. Adjustment of sleeves on levers	11
- List of parts	12



5 K01.2

## 3000/3100 SERIES TRACTORS



# Gearbox - Selector cover 16 speed

### General

The selector cover fitted on the RH side of the gearbox housing has two separate levers which each perform two different functions:

- Front lever: this lever controls the A/B ranges and the reversing mechanism.
- Rear lever: this lever selects the four basic gears and the Hi-Lo speeds.

### Operation

#### 1. A/B range and reverse lever (Fig.1)

##### A/B range function

The A/B ranges are hydro-mechanically controlled. The range and reversing lever (23) selects one of the two ranges when it is either pushed (A range) or pulled (B range).

Supply chamber (F), ducts (a) and (d), and chamber (H) are under constant pressure from the 17 bar LP circuit.

##### A range

Lever (23) is pushed. Plunger /59\ moves to the lowered position in the waist on shaft (53) and there is no supply to ducts (b) and (c). The pressure prevailing in chamber (F) is transmitted to chamber (H) and acts on the annular face of piston (72). The piston moves forward and pivots lever /61\, which moves fork (T) to the A position. The hydraulic oil contained in chamber (G) is returned to the housing via ducts (c) and (b) and pressure valve (58).

##### B range

Lever (23) is pulled. Plunger /59\ then moves into contact with the larger-diameter circumference of spindle (53) and assumes its raised position. It allows hydraulic oil to flow from duct (a) to ducts (b) and (c) and then to chamber (G). Since the force acting on the larger face of piston (72) is greater than that applied to its annular face, the piston moves back. Lever /61\ moves with the piston and shifts fork (T) to the B position.

The hydraulic oil contained in chamber (H) is returned to the 17 bar circuit via ducts (d) and (a).

### Reversing function

The reversing function is obtained when lever (23) is moved either forward (reverse gears) or back (forward gears). It can be obtained in both the A range and the B range.

### A range

Moving lever (23) either forward or back causes shaft (53), which is secured to U-arm (54), to turn. The front pad on U-arm (54) moves selector (S) and the selector, as it moves, takes with it upper finger (66), which is engaged in the selector (S).

**N.B.:** In the A range, upper finger (66) remains passive and is simply carried along by selector (S) in its movement.

### B range

In this position, when lever (23) is pulled, moving the lever either forward or back causes U-arm (54) to pivot. The rear pad on U-arm (54) moves upper finger (66) which in turn moves selector (S). The front pad on U-arm (54) is then disengaged from selector (S).







5 K01.4

## Gearbox - Selector cover 16 speed

### Mechanical locking of A/B ranges

Two ramps machined into the A/B range fork (T) allow it to be locked by the end of shaft (53).

- In the A range, fork (T) is in the position shown in Fig. 2 and prevents an accidental change to the B range.
- In the B range, fork (T) is in the position shown in Fig. 3 and prevents an accidental change to the A range.

**N.B.:** The lever in the cab moves in the opposite direction to the lever on the selector cover; when it is in the forward position, the forward gears are engaged.

### 2. Gear lever

#### Selecting 1st/2nd gears

To select these gears, the gear lever (12) is set to its intermediate position. Arm (36), which is linked to lever (12) engages in the 1st/2nd speed fork (P) and lock (V) prevents any movement by the 3rd/4th speed fork (Q) (Fig. 4). 1st gear is obtained by moving lever (12) back and 2nd by moving it forward.

#### Selecting 3rd/4th gears

If gear lever (12) is pushed, arm (36) engages in the 3rd/4th speed fork (Q) and moves with it lock (V), which then prevents movement by the 1st/2nd speed fork (P) (Fig. 5). 3rd gear is obtained by moving lever (12) back and 4th by moving it forward.

#### Hi-Lo (Hare-Tortoise) function

The Hi-Lo function is obtained in the neutral position by pulling lever (12). Arm (36) linked to the lever moves lock (V), which applies pressure to switch (1). Switch (1) operates the Hi-Lo solenoid valve via the Autotronic (if fitted) or via a system of relays (tractors without Autotronic or «E»).




Fig. 2




Fig. 3




Fig. 4




Fig. 5



## Gearbox - Selector cover 16 speed

5 K01.5

### Hare position

Solenoid valve E, which is mounted at the bottom of the RH cover (Fig. 6), opens and feeds hydraulic oil to chamber (a) situated at the rear of piston (13) (Fig. 9). The piston moves forward and applies pressure to fork (20).

The oil contained in chamber (b) is forced into the Hare duct and returns to the 17 bar circuit.

### Tortoise position

Switch (1) is again actuated via the gear lever and this causes the solenoid valve to close and the pressure in chamber (a) to drop. Piston (13) moves back under the prompting of the 17 bar pressure applied to its annular face.

The oil contained in chamber (a) is returned to the housing via the Hare duct and solenoid valve E.

### Hare/Tortoise locking

Slider (18) secured to fork (20) is facing lock (22), which prevents any accidental movement of fork (20) both in the Hare position (Fig. 7) and in the Tortoise position (Fig. 8).

The configuration of lock (22) is such that the slider and fork assembly is only released if the gear lever is pulled to select either the Hare position or the Tortoise position.




Fig.6




Fig.7

Fig.8




Fig.9




5 K01.6

3000/3100 SERIES TRACTORS

**Gearbox - Selector cover 16 speed**



Gear-change system (Fig.10)






# Gearbox - Selector cover 16 speed

5 K01.7

Range-change and reversing system (Fig.11)





5 K01.8



## Gearbox - Selector cover 16 speed

### A. Removal

1. Immobilise the tractor. Fit wedge blocks under the LH rear wheel.
  2. Apply the handbrake.
  3. Fit chock between frame and front axle.
  4. Drain the gearbox (only) of oil.
  5. Raise the rear RH side of the tractor with a jack.
  6. Place an axle stand in position.
  7. Take off the wheel.
  8. Take off the RH step.
  9. Take out cotter pins (18) and (25) and remove washers (17) and (26). Remove pins (11) and (20).
  10. Lift dust-covers (49) and (51), and (9) and (16). Take out range lever (23) and gear lever (12) and mark which fits where. Take off pipe (2) (Fig. 12).
  11. Disconnect the Hi-Lo wiring from switch (1) (Fig. 12).
  12. On gearboxes fitted with creeper speeds, disconnect the control linkage.  
On gearboxes fitted with a speed limiter, disconnect the wiring to switch (1) (Fig. 13).
  13. Remove bolts (33).
- N.B.: Mark the positions of locating bolt (3) and earth wire lug (24).**  
**On gearboxes fitted with creeper gears, take off the control cable support (1) (Fig. 14).**
14. Remove cover (57).




Fig.12




Fig.13




Fig.14



## Gearbox - Selector cover 16 speed

### B. Disassembly

15. Clamp cover (57) in a vice (Fig. 15).
16. Unscrew pressure valve (58) and plunger (59).
17. Unscrew bolts (29) and (30), and (4) and (5), and take off supports (6) and (31).  
**N.B.: On gearboxes fitted with a speed limiter, take off support (1) (Fig. 16).**
18. Unscrew setscrews (15) and (52) and remove arms (10) and (32).
19. Unscrew setscrew (55), withdraw shaft (53) and take off the reverse- controlling U-arm (54).
20. Withdraw cotter pin (62), washer (64), spring washer (65) and pin (63) and take off finger (66).
21. Unscrew shoulder screw (60), mark which way round A/B control finger (61) fits, and remove the finger (Fig. 17).
22. Unscrew A range plug (77), take off O-ring (76) and unscrew nut (75).
23. Withdraw washer (74), piston (72), adjusting shims [71] O-ring (73), piston rod (68) and O-ring (69).
24. Unscrew bolts (44), (45) and (47).
25. Take off support (46).
26. Withdraw dowel pins (43) and (48) from the cover.
27. Unscrew bolt (34) and withdraw the selecting arm assembly.
28. Remove cup seals (38) (40) and spring (39).
29. Withdraw arm (36) from mounting block (35) and remove cup seal (41) and spring (42) from the arm (36).
30. Unscrew Hi-Lo switch (1), remove O-ring (2), plug (19) and union (67).
31. Remove seals (37) and (50).




Fig.15




Fig.16




Fig.17



5 K01.10

## 3000/3100 SERIES TRACTORS



# Gearbox - Selector cover 16 speed

### C. Reassembly

32. With a jet of compressed air, check that the **A** and **B** passages are not blocked (Fig. 18 and 19).
33. Clean the mating face of cover (57).
34. Apply a light coating of Loctite 542 to the outer circumference of seals /37\ and /50\ and press them fully home in the cover.
35. Carry out procedures 28 to 30 in reverse.
36. Refit the selecting arm assembly and bolt (34).  
**N.B.: Be careful not to damage the lip of seal /37\ when refitting the assembly. Clean the bolt and coat it with Loctite 270 and tighten it to a torque of 25 - 25 Nm.**
37. Carry out procedures 25 and 26 in reverse.
38. Refit bolts (44), (45) and (47) and tighten them to a torque of 25 to 35 Nm
39. Replace O-ring (69) on piston rod (68). Lubricate the combination and insert it in the bore in the cover.  
**N.B. The notch in the rod must face down (Fig. 20).**
40. Carry out procedure 21 in reverse.  
**N.B.: Clean the tapped thread and coat it with Loctite 270 (do not coat the thread on the screw). Tighten the screw to a torque of 50 to 70 Nm. Check that the finger will pivot freely.**
41. Carry out procedure 20 in reverse.
42. Carry out procedure 19 in reverse.  
**N.B.: Fit shaft (53) from the inside of the cover (Fig. 21). Be careful not to damage the lip of seal /50\. Tighten the setscrew to a torque of 28 to 43 Nm.**
43. Carry out procedures 17 and 18 in reverse.
44. Take the cover out of the vice.




Fig.18




Fig.19




Fig.20





Fig.21



## Gearbox - Selector cover 16 speed

### D. Refitment

45. Carry out procedures 247 and 248, 250 to 255 from Section 5 A02.S.
46. Fit the earth wire lug (24).
47. Carry out procedures 256 and 257, Section 5 A02.S.  
**N.B.:** *If nothing has been done to the A/B control mechanism, fit the cover without making the adjustments. Otherwise adjust the A/B selector mechanism as described in Section 5 K03.*
48. Carry out procedures 11 and 12 in reverse.
49. Carry out procedure 10.  
**N.B.:** *Grease ball-joints (8) (14) and (21) (27) (Loctite Anti Seize grease or equivalent).*
50. On gearboxes fitted with creeper gears, adjust the control (see Section 5 J01).  
On gearboxes fitted with a speed limiter, fit switch (1) (Fig. 13) (see Section 5 M01).
51. Carry out procedures 8 and 9 in reverse.
52. Refit the wheel.
53. Remove the axle stand and jack. Tighten the wheel nuts to a torque of 400 - 450 Nm.
54. Carry out procedures 1 to 4 in reverse.
55. **Carry out road test on the controls for :**  
A/B and reverse, gears, Hi-Lo, creeper gears (if fitted).
56. Check that there are no leaks at the cover joint or at the hydraulic unions.



### E. Adjustment of sleeves on levers

**Note :** *If an adjustment or a replacement becomes necessary slightly coat the inside of every sleeve with "Anti-Seize" grease or equivalent.*

The setting dimension of the sleeve of the A/B range - reverse shuttle lever according to the shoulder of the selector cover lever which was previously 58 mm, becomes the same as for the gear lever : 40 mm. Refer to Service Bulletin 89/009, issue 1.

#### Adjustment (Fig. 22)

Place the A/B range-reverse shuttle lever in position A (reverse shuttle non engaged) and the gear lever to neutral.

Unscrew nuts (1). Set sleeves (2) to obtain 40 mm from the end of the sleeve to the shoulder "E" on every lever. Tighten the nuts to the torque of 50 Nm and fit the bellow (3).






5 K01.12

# Gearbox - Selector cover 16 speed

## List of parts

- (1) Switch
- (2) Seal
- (3) Locating bolt.
- (4) Bolt
- (5) Bolt
- (6) Support
- (7) Dowel pin
- (8) Ball
- (9) Dust-cap
- (10) Arm
- (11) Pin
- (12) Gear lever
- (13) Dowel pin
- (14) Ball
- (15) Setscrew
- (16) Dust cap
- (17) Washer
- (18) Cotter pin
- (19) Plug
- (20) Pin
- (21) Ball
- (22) Dowel pin
- (23) A/B range and reversing lever
- (24) Lug
- (25) Cotter pin
- (26) Washer
- (27) Ball
- (28) Dowel pin
- (29) Bolt
- (30) Bolt
- (31) Support
- (32) Arm
- (33) Bolt
- (34) Bolt
- (35) Mounting block
- (36) Arm
- (37) Seal
- (38) Cup seal
- (39) Spring
- (40) Cup seal
- (41) Cup seal
- (42) Spring
- (43) Spring dowel
- (44) Bolt
- (45) Bolt
- (46) Support
- (47) Bolt
- (48) Spring dowel
- (49) Dust cover
- (50) Seal
- (51) Dust cover
- (52) Setscrew
- (53) Shaft
- (54) U-arm
- (55) Setscrew
- (57) 4 x 4 cover
- (58) Pressure valve
- (59) Plunger
- (60) Shoulder screw
- (61) Finger
- (62) Cotter pin
- (63) Pin
- (64) Washer
- (65) Spring washer
- (66) Upper finger
- (67) Union
- (68) Piston rod
- (69) O-ring
- (70) Threaded rod
- [71] Adjusting shim
- (72) Piston
- (73) O-ring
- (74) Washer
- (75) Nut
- (76) O-ring
- (77) Plug









3000/3100 SERIES TRACTORS

### Gearbox - Selector cover 16 speed



5 K01.13





***Gearbox - Selector cover 8 speed***

5 K02.1

***5 K02 Selector cover (4x2)***

CONTENTS

General	2
Operation	2
A. Removal	2
B. Disassembly	2
C. Reassembly	2
D. Refitment	2
E. Adjustment of sleeves on levers	2



5 K02.2

## Gearbox - Selector cover 8 speed

### General

The selector cover fitted on the RH side of the gearbox housing has two separate levers which control the following functions:

- Front lever: controls the reverse shuttle,
- Rear lever: selects the four basic speeds and the Hare/Tortoise range.

### Operation

#### Reverse shuttle lever

The reverse shuttle operates when the lever (23) is moved either forwards (for reverse) or backwards (for forward travel).

Moving the lever (23) causes shaft (53) to rotate ; this is integral with lever (54) which moves the selector (S).

#### Gear lever

1st, 2nd, 3rd, 4th and Hare/Tortoise range are selected in the same way as for the 4x4 gearbox (See 5 K01).

**Note: In the 4x2 version 3rd and 4th positions are the reverse of those in the 4x4 gearbox.**

### A. Removal

1. Carry out procedures 1 to 13 (Section 5 K01).
2. Remove the cover (56).

### B. Disassembly

3. Place the cover (56) in a vice.
4. Carry out procedures 17 to 19 (Section 5 K01).
5. Carry out procedures 24 to 31 (Section 5 K01).

### C. Reassembly

6. Clean the gasket face of the cover (56). Coat the outer diameter of the seals /37\ and /50\ with Loctite 542 and press them fully home into the cover.
7. Press the pins (43) and (48) into the cover. Fit the support (46).  
Refit the bolts (44), (45) and (47) and tighten them to a torque of 25-35 Nm.  
Refit the lever (54), refit the shaft (53) inside the cover. Take care not to damage the lip of the seal /50\  
Fit the bolt (55) and tighten to a torque of 28-43 Nm.

8. Reverse procedures 28 and 29 (Section 5 K01).  
Refit the gear control assembly and the bolt (34) after coating it with Loctite 270.  
Tighten to a torque of 25-35 Nm.  
**Note: Take care not to damage the lip of the seal /37\.**
9. Refit the plug (19), the Hare/Tortoise switch (1) and its seal (2).
10. Reverse procedures 17 and 18 (Section 5 K01).
11. Remove the cover from the vice.

### D. Refitment

12. Carry out procedures 238 to 243 in Section 5 A02.  
**The following procedures not described must be carried out in Section 5 K01.**
13. Reverse procedure 13.  
Tighten the bolts to a torque of 50-70 Nm.
14. Reverse procedures 11 and 12.
15. Reverse procedure 10.  
**Note: Grease the balls (8) (14) and (21) (27) (use Loctite Anti-seize or equivalent grease).**
16. Procedure 50.
17. Reverse procedures 8 and 9.
18. Refit the wheel.
19. Remove the stand and the trolley jack. Tighten the wheel nuts to a torque of 400-450 Nm.
20. Reverse procedures 1 to 4.
21. Road test the following controls :
  - . A/B reverse shuttle, gears, Hare/Tortoise range, creeper gears (if fitted).
  - . Check the cover gasket face and the hydraulic unions for leaks.


### E. Adjustment of sleeves on levers

Carry out procedure from section 5K01 page 11.



# Gearbox - Selector cover 8 speed

5 K02.3





5 K02.4

## 3000/3100 SERIES TRACTORS



### Gearbox - Selector cover 8 speed

#### Key to Figure

- |                     |                        |
|---------------------|------------------------|
| (1) Switch          | (29) Bolt              |
| (2) Seal            | (30) Bolt              |
| (3) Centring screw  | (31) Support bracket   |
| (4) Bolt            | (32) Link              |
| (5) Bolt            | (33) Bolt              |
| (6) Support bracket | (34) Bolt              |
| (7) Pin             | (35) Rack              |
| (8) Ball            | (36) Lever             |
| (9) Dust cap        | (37) Seal              |
| (10) Link           | (38) Cup               |
| (11) Pin            | (39) Spring            |
| (12) Gear lever     | (40) Cup               |
| (13) Pin            | (41) Cup               |
| (14) Ball           | (42) Spring            |
| (15) Setscrew       | (43) Tubular split pin |
| (16) Dust cap       | (44) Bolt              |
| (17) Washer         | (45) Bolt              |
| (18) Pin            | (46) Bracket           |
| (19) Plug           | (47) Bolt              |
| (20) Pin            | (48) Tubular split pin |
| (21) Ball           | (49) Dust cap          |
| (22) Pin            | (50) Seal              |
| (23) Shuttle lever  | (51) Dust cap          |
| (24) Bracket        | (52) Setscrew          |
| (25) Pin            | (53) Pin               |
| (26) Washer         | (54) Lever             |
| (27) Ball           | (55) Setscrew          |
| (28) Pin            | (56) 4x2 cover         |







3000/3100 SERIES TRACTORS

**Gearbox - Selector cover 8 speed**



5 K02.5





***Gearbox - Adjusting selector cover***

*5 K03 Adjusting selector cover*

CONTENTS

-	General	2
A.	Preparing for adjustment	3
B.	B range adjustment	4
C.	A range adjustment	5





5K03.2

## 3000/3100 SERIES TRACTORS



# Gearbox - Adjusting selector cover

### General

To ensure that the A/B range will operate correctly, two adjustments need to be made. They consist of adjusting the position of the control piston so that there is a clearance of 0.2 to 0.3 mm between the pads on the A/B fork and the slider of the synchroniser in both the A and B positions.

**N.B.:** To rationalise the design of the hydraulic control mechanism for the A/B range, the system for reducing and regulating the pressure applied to the piston was modified mechanically and the modification was introduced:

- as from serial number N257024 in MF 3050, 3060, 3070 and 3090 tractors
- as from serial number N258024 in MF 3080 tractors, and
- as from serial number N265031 in MF 3065 tractors.


### Modification by service kit

A service kit to reduce and even up the pressure applied to the A/B control piston was introduced:

- in 40 km/h 3000 tractors: as from serial number N161041
- in 30 km/h 3000 tractors: as from serial number N173012.

30 km/h tractors produced with serial numbers between N161044 and N173011 were fitted with an intermediate set-up.

For the make-up of the kit and the fitting and adjustment procedures, see Service Bulletin 88/029, issue 2, July 1988.





## Gearbox - Adjusting selector cover

### A. Preparing for adjustment

1. Unscrew plug (77).
2. Remove and discard O-ring (76) (Fig.1).  
**N.B.:** In the rod of the A/B piston, the socket screw was replaced first by an M8 x 40 screw as from serial number P193024 and then by a threaded rod as from serial number R016007. For tractors with serial numbers prior to P193024, see Workshop Manual 1646640M1.
3. Unscrew nut (75) (Fig.2).  
**N.B.** If it proves necessary for the threaded rod (70) to be removed, clean it and refit it to the rod of the piston with Loctite 270, observing the dimension of 16 mm (Fig.3).
4. Withdraw flat washer (74) and piston (72) with a pair of external circlip pliers (Fig.4).
5. Keep the adjusting shims [71] (Fig.4).
6. Remove O-ring (73) from the piston and discard it.
7. Clean the parts and replace any which are faulty.




Fig. 1




Fig. 2




Fig. 3




Fig. 4



5K03.4



## Gearbox - Adjusting selector cover

### B. B range adjustment

8. Hold the control lever in the B position (Fig. 5).
9. Push rod (68) fully in to set it to the B position (Fig. 6)  
**N.B. : Make sure that the rod is well inserted.**
10. Insert tool 3583544M1 into the bore in the cover.
11. Make sure that the outer tube of the tool is in contact with the shoulder in the cover and that its inner tube is bearing against rod (68) (Fig.7).
12. Tighten the screw in the tool and withdraw the tool from the cover.
13. With a depth gauge, measure the dimension X shown by the service tool (Fig.8).




Fig. 5




Fig. 6




Fig. 7




Fig. 8







## Gearbox - Adjusting selector cover

14. Determine the shim thickness **E** required to give a clearance:  $J1 = +0.2$  to  $+0.3$  mm (Fig.9).
15. Lubricate O-ring (**73**) and fit it to the piston.
16. Fit shim(s) **E** [71] of the thickness selected in procedure 14 and then piston (**72**).
17. Slide on flat washer (**74**), apply a light coat of Loctite 241 to nut (**75**), fit the nut and tighten it to a torque of 25 - 35 Nm (Fig.10).

### C. A range adjustment

**N.B.:** Clean the thread on plug (**77**) and the tapping to receive it. For a correct adjustment to be made, it must be possible for the plug to be screwed in by hand for the full length of its thread without any resistance.

18. Connect a compressed air supply, a pressure gauge and a valve to union (**67**) (Fig.11).
19. Adjust the valve to give a pressure of not more than 3 bars on the pressure gauge.
20. Set control lever (**23**) to the A range position (Fig.12).
21. Screw in the A range plug (**77**) until it is in contact with the piston.





5K03.6



## Gearbox - Adjusting selector cover

22. Mark plug (77) and cover (57) with a straight line (Fig. 13).
23. Screw the plug out, counting the number of turns.
24. Lubricate O-ring (76) and fit it.
25. Apply Loctite 242E to the first turns of the thread on the plug.
26. Screw the plug in for the number of turns counted in procedure 23.
27. When the mark on plug (77) is opposite the mark on cover (57), screw the plug in by 1/6 of a turn (60°) (Fig. 14) to give a clearance (Fig. 15):  
**J2 = +0.2 to +0.3 mm.**
28. Check the operation of the A and B ranges and of the reversing gearbox.
29. Disconnect the pressure gauge and fit the supply pipe (1) for the A/B ranges (Fig. 16)




Fig. 13




Fig. 14




Fig. 15




Fig. 16



***Gearbox - Spacer***

5L01.1

*5 L01 Spacer*

CONTENTS

A. Spacer - 3000 Tractor with 6 cylinder engine	2
B. 3100 Spacer	3



5L01.2

## Gearbox - Spacer


### A. Spacer - 3000 Tractor with 6 cylinder engine

#### Disassembly

1. Split the tractor between the engine and the gear box (section 3 A01).
2. Remove the toolbox.
3. Remove two spacer attaching bolts on the gear-box.
4. Screw two guide pins in their place (use two bolts).
5. Remove the other thirteen bolts and the spacer.
6. Remove the locating dowels.

#### Reassembly

7. Clean the spacer and gearbox mating surfaces.
8. Refit the locating dowels.
9. Carry out procedure 4 and reverse procedure 5.
10. Remove both guide pins. Fit and tighten the fifteen bolts to a torque of 100 - 130 Nm.
11. Carry out procedures 1 and 2 in reverse.





## Gearbox - Spacer

### B. 3100 Spacer


#### Disassembly

1. Split the tractor between the engine and the gearbox (section 3 A02).
2. Remove the toolbox.
3. Remove two spacer attaching bolts on the gearbox.
4. Screw two guide pins in their place (use two bolts).
5. Remove the other thirteen bolts and the spacer.
6. Remove the locating dowels.

#### Reassembly

7. Clean the spacer and gearbox mating surfaces.
  8. Refit the locating dowels.
  9. Carry out procedure 4 and reverse procedure 5.
  10. Remove both guide pins. Fit and tighten the fifteen bolts to a torque of 100 - 130 Nm. \*
- NOTE : Make sure that the countersunk head screw /13\ is in the correct hole.**
11. Carry out procedures 1 and 2 in reverse.

\* After coating them, except screw /13\, with LOCTITE 270 (From S/N S255027)







**Gearbox - Dynashift**

*5 L02 Spacer*

CONTENTS

A. <b>Spacer (4 Cyl. engine - 1004)</b>	_____	<b>2</b>
B. <b>Spacer (6 Cyl. engine - 1006)</b>	_____	<b>3</b>



5L02.2



# Gearbox - Dynashift

## A. Spacer (4 cyl. engine - 1004)

A spacer is fitted between the gearbox and the engine on tractors of the MF 3075 Dynashift type (1004 engine). Internally, the spacer is attached by means of studs of different lengths which are screwed into the gearbox housing (Fig. 1).

### Disassembly


1. Split the tractor between the engine and the gearbox (see Section 3 A03).
2. Remove the spacer.
3. If necessary, extract the studs from the gearbox.

### Reassembly

4. Cleaning the mating faces on the spacer and gearbox.
5. If they were removed, coat the studs with Loctite 270. Screw and lock into their correct locations according to their lengths, as shown in Fig. 1.
6. Recouple the tractor between the engine and the gearbox (see Section 3 A03).

### Tightening torque

(1) to (15) = 100 - 130 Nm



### Length of studs

- (3) = 145
- (5) (8) = 155
- (6) (7) = 130

Fig. 1



## Gearbox - Dynashift

5L02.3

### B. Spacer (6 cyl. engine - 1006)

#### Disassembly

1. Split the tractor between the engine and the gearbox (see Section 3 A03 or 3 A04 according to the type).
2. Remove the tool box.
3. Remove two spacer attaching bolts on the gearbox.
4. Screw two guide studs in their place (locally manufactured).
5. Remove the 13 bolts and the spacer.
6. Remove the locating pins.

#### Reassembly

7. Cleaning the mating faces on the spacer and gearbox.
8. Reinstall the locating pins.
9. Repeat procedure 4 and carry out procedure in reverse order.
10. Remove the guide studs. Fit and tighten the 15 bolts to a torque of 100 - 130 Nm.  
**Note: Make sure that the countersunk head screw /13/ is positioned in the correct hole (Fig. 2).**
11. Carry out procedures 1 and 2 in reverse order.




Fig. 2



**Gearbox - 16th gear lockout**

5M01.1

*5 M01 16th gear lockout*

CONTENTS

- General	2
- Operation	2
A. Fitting	2
B. Circuit diagram	3



5M01.2



## Gearbox - 16th gear lockout

### General

The arrangement for locking out the 16th gear is fitted to 3100 series tractors which are equipped with a 40 km/h version speedshift.

It applies only to countries where the maximum speed is limited to 30 km/h.

The system is formed by a switch which bears against the gear lever (Fig.1) and by two relays mounted behind the instrument panel (Fig.2).

Moving the gear lever into 4th automatically causes the solenoid valve controlling the speedshift to open and a change to be made to the Tortoise range.




Fig. 1

### Operation

The system requires three items of information which are provided by the two relays :

- a) a supply in the Hare range coming from the Hare/Tortoise range solenoid valve
- b) a signal that switch (1) is in a position indicating that 4th gear has been engaged
- c) a signal controlled by the clutch pedal which indicates the clutch engagement phase.

In combination, these three items of information control the speedshift solenoid valve in the 4th Hare speed alone, without pressing the button on the console in the cab.

**N.B. In all the other gear ratios, the speedshift can be controlled from the button on the console.**




Fig. 2

### A. Fitting

With bolts (4) and nut (2), position switch (1) so that it rests hard against gear lever (3) in the 4th gear position (Fig. 1)



# Gearbox - 16th gear lockout


5M01.3

## B. Circuit diagram

To pin 10  
Connector C  
Autotronic unit

To terminal 56a  
of remote-control switch 63  
(tractors without Autotronic)

Terminal S1  
Speedshift switch



### Key

- 6. Hare/Tortoise solenoid valve
- 21. Starter switch
- 64. Speedshift solenoid valve
- 65. Relay
- 66. Switch

### Colour codes

- G. Grey
- N. Black
- O. Orange
- R. Red
- V. Green



**Gearbox - Dynashift**

5N01.1

*5 N01 Dynashift transmission assembly*

CONTENTS

A. Description	2
B. Gearbox assembly	2



5N01.2

## Gearbox - Dynashift

### A. Description

The general configuration of the Dynashift transmission is similar to the Speedshift transmission (see Section 5 A01) except for:

- **Input unit:** This features the Dynashift function and the reversing gear function.

The **Dynashift** system replaces the Speedshift and provides four gearbox input ratios in place of the two for Speedshift.

The **reverse shuttle** is located in the rear enclosure of the gearbox. Its design is identical to that of the Speedshift version except that it is installed on two taper roller bearings instead of on two ball bearings.

- **Clutch:** This is identical to the clutch for the Speedshift version but its control is different and ensured by a slave cylinder with two pistons.

The control system is pushed for the 3000 models and pulled for the 3100 models in the same way as in the Speedshift version.

### B. Gearbox assembly

#### Main gearbox

The main gearbox has eight basic speeds. It consists of a train of four gears to which a set of two gears is added so that a slow (Tortoise) range and a fast (Hare) range can be obtained. All the gears are in constant mesh and the speeds are selected by synchromesh units. These eight speeds can be selected with a single lever.

#### Reverse gear assembly

This consists of an assembly of two gears placed in front of the main gearbox, fitted on a hollow shaft, and a third gear fitted on the main gearbox mainshaft.

A compound gear cluster located between the hollow shaft and the mainshaft allows the direction of rotation of the mainshaft to be reversed.

#### Creeper gear unit

This is identical to that in the Speedshift version (see Section 5 A01).

#### Lubrication (Fig. 2)

Lubrication is ensured by means of the 1.5 bar valve located on the left-hand side of the gearbox. The oil flow circulates through the Dynashift assembly, the reverse shuttle and the layshaft bearings as well as in the gears, bearings and bushes of the mainshaft and output shaft.

The lubricating efficiency is improved by the fact that the end of the reverse shaft is engaged in the layshaft and the deflector (50) is installed.

The Dynashift planet gears are splash lubricated.

#### List of parts

(1) Bearing cone	(26) Circlip	(53) Bearing cone
(2) Bearing cup	(27) Thrust washer	(54) Layshaft
(3) Adjusting shims	(28) Combined bearing	(55) 3rd driven gear
(4) Thickness shim	(29) 3rd drive gear (Hare)	(56) 4th driven gear
(5) Circlip	(30) Combined bearing	(57) Spacer
(6) Washer	(31) Hare / Tortoise synchro	(58) Shims
(7) 1st drive gear	(32) Thrust washer	(59) 2nd driven gear
(8) Bush	(33) Tortoise synchro ring	(60) 1st driven gear
(9) 1st gear synchro cone	(34) Retaining ring	(61) Circlip
(10) 1st gear synchro ring	(35) Bush	(62) Needle roller bearing
(11) 1st and 2nd gear synchro	(36) Tortoise gear	(63) Bearing cone
(12) 2nd gear synchro ring	(37) Bearing cup	(64) Bearing cup
(13) 2nd gear synchro cone	(38) Adjusting shims	(65) Housing
(14) 2nd drive gear	(39) Bearing cone	(66) Reverse gear unit
(15) Circlip	(40) Bearing cone	(67) Input gear
(16) Bearing cup	(41) Bolt	(68) Nut
(17) Bearing cone	(42) Adjusting shims	(69) Mainshaft
(18) 4th drive gear	(43) Thickness shim	(70) Retaining ring
(19) Circlip	(44) Output shaft	(71) Oil feed pipe
(20) 4th gear synchro cone	(45) Circlip	(72) Spring
(21) 4th gear synchro ring	(46) Lock plate	(73) Tortoise synchro cone
(22) Washer	(47) Adjusting shims	(74) Hare synchro ring
(23) 3rd and 4th gear synchro	(48) Bearing cup	(75) Hare synchro cone
(24) Needle roller bearing	(49) Circlip	(76) 3rd gear synchro ring
(25) 3rd gear synchro ring	(50) Oil deflector	
	(51) Adjusting shims	










5N01.4

3000 / 3100 SERIES TRACTORS



# Gearbox - Dynashift



-  Pressure lubrication
-  Splash lubrication



## **Gearbox - Dynashift**

### *5 P01 Push-type clutch*

#### CONTENTS

-	<b>General</b> _____	<b>2</b>
A.	<b>Operation</b> _____	<b>2</b>
B.	<b>Engine flywheel</b> _____	<b>5</b>
C.	<b>Replacing the flywheel ring gear</b> _____	<b>5</b>
D.	<b>Removing and refitting the release bearing</b> _____	<b>6</b>
E.	<b>Replacing the slave cylinder seals</b> _____	<b>7</b>
F.	<b>Adjusting the clutch pedal</b> _____	<b>8</b>
G.	<b>Service tool</b> _____	<b>8</b>



5P01.2

3000 / 3100 SERIES TRACTORS



## Gearbox - Dynashift

### General

#### Description

This is a diaphragm push-type clutch. The master cylinder, which is of identical design to that on the 3600 tractor, is supplied and kept at a constant level by the low-pressure hydraulic system. Drive is obtained via the disc (6) which engages with the splined gearbox input shaft in rotation.

#### Construction

The clutch control system on tractors equipped with a Dynashift gearbox consists of:

- a slave cylinder (24) centred by spacer (9)
- two pistons /23\ housed in the slave cylinder
- a release bearing carrier (26) centred in the slave cylinder
- a release bearing assembly (25) which snaps into place on the bearing carrier.

Each piston /23\ is supported by two guide rings /28\ and tight sealing is provided by a bush /29\ and O-ring /29A\ and a scraper ring /27\.

### Operation

The force exerted on the pedal and transmitted by the control rod acts on the master cylinder. The quantity of oil displaced by the master cylinder piston enters via the upper hole (large diameter) in the slave cylinder (24) and causes the release bearing carrier (26) and the release bearing (25) to move forwards. The release bearing compresses the diaphragm of the clutch cover plate (7), and this releases the pressure on the clutch cover plate and frees the disc (6).

#### Clutch engagement

When the clutch pedal is released, the pressure drops in the slave cylinder. The diaphragm pushes the release bearing carrier back and the pressure plate is moved forwards. The disc (6) is then locked between the pressure plate and the engine flywheel and drives the gearbox input shaft.

#### Specifications

Clutch control	: push-type
Plate load	: 1,100 kg
Number of vanes	: 6
Type of vane	: non-progressive
Disc diameter	: 330 mm
Friction linings	: cerametallic


### List of parts

- |  |                                    |
|--|------------------------------------|
| (1) Engine flywheel                    | (17) Grommet                       |
| (2) Flywheel ring gear                 | (18) 90° union                     |
| (3) PTO shaft drive hub                | /19\ Slave cylinder attaching bolt |
| (4) Engine flywheel attaching bolts    | (20) Slave cylinder attaching bolt |
| (5) Dowel pins                         | (21) Pin                           |
| (6) Disc                               | (22) Spring washer                 |
| (7) Clutch cover plate                 | /23\ Pistons                       |
| (8) Clutch cover plate attaching bolts | (24) Slave cylinder                |
| (9) Spacer                             | (25) Clutch release bearing        |
| (10) Bleed point                       | (26) Release bearing carrier       |
| (11) Grommet                           | /27\ Scraper ring                  |
| (12) 90° union                         | /28\ Guide rings                   |
| (13) Bleed pipe                        | /29\ Sealing bush                  |
| (14) Straight union                    | /29A\ O-ring                       |
| (15) Straight union                    | /30\ Guide rings                   |
| (16) Supply pipe                       | (31) Flexible retainer             |



# Gearbox - Dynashift

5P01.3





5P01.4

3000 / 3100 SERIES TRACTORS



# Gearbox - Dynashift




Fig. 2



## Gearbox - Dynashift

5P01.5

### A. Clutch cover plate

#### Disassembly

1. Split the tractor between the engine and the gearbox (see Section 3 A03).
2. Position the centring tool MF 457 (Fig. 3) to retain the cover plate and disc assembly.
3. Gradually loosen the bolts (8) attaching the cover plate (7) to the engine flywheel (1).
4. Remove the cover plate and the disc (6).
5. Remove the two dowel pins (5) from the flywheel.

#### Reassembly

6. Remove dust and clean the engine flywheel with a solvent.
7. Check the flywheel friction surface.  
**Note: If the friction surface of the engine flywheel (1) is scored, it can be skimmed (see part B, operation 6).**
8. Lightly grease the splines on the power take-off shaft hub in the engine flywheel (GN + Molykote type grease).
9. Reinstall the two dowel pins (5).
10. Using the centring tool MF 457, centre the clutch disc (6) on the engine flywheel. The longest section of the hub must be facing the diaphragm.
11. Refit the clutch cover plate.
12. Gradually tighten the attaching bolts (8) to a torque of 50 - 70 Nm.
13. Remove the centring tool MF 457.
14. Recouple the tractor between the engine and the gearbox (see Section 3 A03).




Fig. 3

#### Reassembly

6. If the friction surface on the engine flywheel is scored it can be skimmed.  
Skimming of the friction surface should be performed as required (removal : 1.5 mm max. - surface condition : 2.5 micrometres max.).



**Important: On the flywheel, the clutch cover plate attaching face must be reduced by the same value, as well as the length of the dowel pins (if incorrect).**

**Check that the tapped holes for the bolts (8) attaching the mechanism onto the flywheel are deep enough. If they are not, they must be tapped.**

**After reworking, grease the flywheel.**

**Do not install a progressive clutch disc.**

**If skimming is performed, place two spacers (9) between the seal holders and the slave cylinder (24).**

**Replace bolts /19\ and (20) with bolts that are 35 mm and 55 mm long, 8 dia. pitch 125, grade 10-9.**

7. Screw the two dowel pins into the flywheel attaching holes.
8. Refit the engine flywheel and the hub (3).
9. Coat the bolts (4) with Loctite 241.
10. Reinstall the six bolts (4) and tighten them to a torque of 110 - 140 Nm. Free the engine flywheel.
11. Refit the engine clutch, carrying out procedures 6 to 13 (in part A).
12. Recouple the tractor between the engine and the gearbox (see Section 3 A03).

### B. Engine flywheel

#### Disassembly

1. Split the tractor between the engine and the gearbox (see Section 3 A03).
2. Remove the engine clutch. Carry out procedures 2 to 5, in part A.
3. Immobilise the engine flywheel (1).
4. Take out the six bolts (4) attaching the engine flywheel to the crankshaft.
5. Remove the engine flywheel and the PTO shaft hub (3).



5P01.6

3000 / 3100 SERIES TRACTORS



## Gearbox - Dynashift

### C . Replacing the flywheel ring gear

#### Disassembly

1. Remove the engine flywheel (part B, procedures 1 to 5).
2. Use a 5 mm dia. drill bit to drill a hole 16 mm deep between the inside diameter of the ring gear (2) and the bottom of a tooth (Fig. 4).
3. Crack the ring gear with a chisel positioned above the hole under the bottom of the tooth.

**Important: Wear protective equipment when breaking the ring gear to avoid possible injury by flying metal particles.**

#### Reassembly

4. Heat a new ring gear to 245°C in an oven only. Do not use a blow torch or any other naked flame.
5. Fit the ring gear (2) onto the flywheel (1) with the chamfered lead on the teeth pointing towards the engine side, and push the ring gear quickly into position. Allow the ring gear to cool slowly.
6. Refit the engine flywheel (carry out procedures 6 to 12 in part B).




Fig. 4

### D . Removing and refitting the release bearing

#### Preliminary operation

Split the tractor between the engine and the gearbox (see Section 3 A03).

#### Removal

1. Separate the release bearing carrier (26) from the slave cylinder (24).  
**Note: Do not press the clutch pedal, in order to avoid extending the slave cylinder pistons.**
2. Using a screwdriver, press on the lugs (1) (Fig. 5) of the flexible retainer and remove it along with the spring washer and the release bearing.

#### Refitting

3. Clean the release bearing carrier and carry out procedure 2 in reverse.
4. Check the rotation and radial movement of the release bearing.
5. Check that the guide rings /30\ inside the slave cylinder are not damaged (Fig. 5).
6. Carry out procedure 1 in reverse.




Fig. 5





## Gearbox - Dynashift

5P01.7

### E. Replacing the slave cylinder seals

1. Disconnect the bleed pipe (13) and the supply pipe (16).
2. Carry out procedure 1 (in part D) and remove the following (as per Fig. 6):
  - pin (21) (if necessary)
  - bolts /19\ and (20)
  - the slave cylinder (24).
3. Remove the unions (15), (if necessary) (Fig. 6).

#### Disassembly (Fig. 7)

4. Withdraw the piston /23\ by knocking the slave cylinder on a wooden block.
5. Remove the guide rings /30\ and drive out the scraper rings /27\.
6. Remove :
  - the guide rings /28\.
  - the sealing bushes /29\ and the O-rings /29A\.

#### Reassembly

7. Clean the slave cylinder (24) (Fig. 6) and the seal grooves.  
Check that :
  - the bleed and supply pipes are not blocked,
  - there is no scoring in the bores and on the pistons,
8. Shape the guide rings /28\ so as to decrease their diameter by approximately one third. Using pliers and wearing protective equipment, install the rings in their grooves (Fig. 7), with the knurled face in contact with the piston /23\.
9. Lubricate and fit the O-rings /29A\ in their groove without twisting them.
10. Shape the sealing bushes /29\ as per Fig. 8.  
**Note: The sealing bushes must be positioned with their lips facing the pressure side (Fig. 7).**
11. Position the sealing bushes in the grooves, gradually fitting them on the O-rings /29A\.
12. Lubricate the sealing bushes, the guide rings /28\ and the cylinder bores.
13. Check that there are no burrs on the pistons /23\ . Fit the pistons, with the "C" chamfers facing the inside of the cylinders (Fig. 7).




Fig. 6




Fig. 7




Fig. 8



5P01.8




## Gearbox - Dynashift

14. Using a suitable fixture, fit the scraper rings /27\ fully home on their shoulder (Fig. 7).
15. Check that the pistons move freely in their bores.
16. If they were dismantled, screw the unions (15) and pin (21) into place (Fig. 6), after coating them with Loctite 241 and tighten them to a torque of 25 - 35 Nm.
17. Shape the guide rings /30\ so as to decrease their diameter by approximately one third. Place the rings in their grooves, with their knurled faces in contact with the release bearing carrier (26) (see Fig. 5).
18. Lubricate the guide rings and the bore in the slave cylinder.
19. Fit the slave cylinder on the Dynashift cover, inserting spacer (9) between them. Coat the bolts /19\ and (20) with Loctite 241 and tighten them to a torque of 25 - 35 Nm (Fig. 6).
20. Fill the piston chambers with transmission oil via the supply port in the slave cylinder.
21. Reconnect the pipes (13) and (16).
22. Check that the guide rings /30\ have not been displaced (Fig. 5).  
Assemble the release bearing carrier (26) with the slave cylinder (24), positioning the pin (21) in its recess (Fig. 6).
23. Clean the clutch housing with a solvent.
24. Recouple the tractor between the engine and the gearbox (see Section 3 A03).
25. Bleed the brake and clutch systems. See Section 6 K01, parts C and D, and Section 5 Q01, part H.
26. Carry out a road test on the clutch control.
27. Check the unions for leaks.

### G . Service tool available from the MF network

Clutch disc centring tool, reference MF 457



### F . Adjusting the clutch pedal

See Section 5 Q01, part I.



*5 Q01 Pull-type clutch*

CONTENTS

-	<b>General</b> _____	<b>2</b>
-	<b>Operation</b> _____	<b>2</b>
A.	<b>Clutch cover plate</b> _____	<b>5</b>
B.	<b>Engine flywheel</b> _____	<b>5</b>
C.	<b>Replacing the flywheel ring gear</b> _____	<b>6</b>
D.	<b>Clutch release bearing assembly</b> _____	<b>6</b>
E.	<b>Clutch hydraulic slave cylinder assembly</b> _____	<b>6</b>
F.	<b>Replacing the slave cylinder seals</b> _____	<b>6</b>
G.	<b>Replacing the release bearing carrier guide rings</b> _____	<b>7</b>
H.	<b>Bleeding the system</b> _____	<b>8</b>
I.	<b>Adjusting the clutch pedal</b> _____	<b>8</b>
J.	<b>Service tools</b> _____	<b>9</b>



5Q01.2

3000 / 3100 SERIES TRACTORS



## Gearbox - Dynashift

### General

#### Description

This is a diaphragm pull-type clutch. The master cylinder, which is of identical design to that on the 3600 tractor, is supplied and kept at a constant level by the low-pressure hydraulic system. Drive is obtained via the disc (6) which engages with the splined gearbox input shaft in rotation.

#### Construction

The clutch control system on tractors equipped with a Dynashift gearbox consists of:

- a slave cylinder (24)
- two pistons /23\ housed in the slave cylinders
- a release bearing carrier (26) sliding on the guide cylinder (25)
- a guide cylinder (25) screwed onto the input gearbox seal holder
- a release bearing assembly (33) held in place by spring clip (31)

Each piston /23\ is supported by two guide rings /28\ and tight sealing is provided by a bush /29\ and O-ring /29A\, and a scraper ring /27\.

The clutch cover plate (7) is connected to the release bearing by a retaining ring fitted on the cover plate and which fits into the groove in the release bearing (33).

Warning: Any operation which requires the splitting of the tractor between the engine and the gearbox requires the removal of the spring clip (31) (see Section 3 A04).

### Operation

#### Clutch disengagement

The force exerted on the pedal and transmitted by the control rod acts on the master cylinder. The quantity of oil displaced by the master cylinder piston enters via the upper holes (large diameter) in the slave cylinder (24), acts on the pistons /23\ and causes the release bearing carrier (26) and the release bearing (33) to move rearwards. The release bearing pulls on the diaphragm of the clutch cover plate and this releases the pressure on the clutch cover plate and frees the disc (6).

#### Clutch engagement

When the clutch pedal is released, the oil escapes into the slave cylinder pressure chamber and the clutch release bearing returns. The diaphragm is compressed and the disc (6) is held against the engine flywheel by the friction plate in the cover plate (7).

#### Specifications

Clutch control	: pull-type
Plate load	: 1,300 kg
Number of vanes	: 7
Type of vane	: progressive
Type of pressure plate	: ventilated
Disc diameter	: 330 mm
Friction linings	: cerametallic

#### Service tools


See part J.

### List of parts

- |  |   |
|--|---|
| (1) Engine flywheel                    | (19) Supply pipe  |
| (2) Flywheel ring gear                 | (20) Bolts (location of slave cylinders for push-type clutch) |
| (3) PTO shaft drive hub                | (21) Tee union  |
| (4) Engine flywheel attaching bolts    | (22) Tee union  |
| (5) Dowel pins                         | /23\ Pistons  |
| (6) Disc                               | (24) Slave cylinders  |
| (7) Clutch cover plate                 | (25) Guide bearing  |
| (8) Clutch cover plate attaching bolts | (26) Release bearing carrier                                  |
| (9) Slave cylinder attaching bolts     | /27\ Scraper rings  |
| (10) Bleed point                       | /28\ Guide rings  |
| (11) Grommet                           | /29\ Sealing bush   |
| (12) 90° union                         | /29A\ O-ring  |
| (13) Bleed pipe                        | /30\ Guide rings  |
| (14) 90° union                         | (31) Spring clip  |
| (15) 90° union                         | (32) Locking screw  |
| (16) Connecting pipe                   | (33) Clutch release bearing                                   |
| (17) Grommet                           | (34) Cover  |
| (18) 90° union                         | (35) Spring washer  |



# Gearbox - Dynashift






5Q01.4

3000 / 3100 SERIES TRACTORS



# Gearbox - Dynashift





## Gearbox - Dynashift

### A. Clutch cover plate

#### Disassembly

1. Split the tractor between the engine and the gearbox (see Section 3 A04).
2. Separate the release bearing assembly from the cover plate.
3. Position the centring tool MF 457 to retain the cover plate and disc assembly (Fig. 3).
4. Gradually loosen the bolts (8) attaching the cover plate (7) to the engine flywheel (1) (Fig. 4).
5. Remove the cover plate (7) and the disc (6).
6. Remove the three dowel pins (5) from the flywheel (1) (Fig. 4).



#### Reassembly

7. Remove dust and clean the engine flywheel (1) with a solvent.
8. Check the flywheel friction surface.  
**Note: If the friction surface of the engine flywheel is scored, it can be skimmed (see part B, operation 6).**
9. Lightly grease the splines on the power take-off shaft hub (3) (Fig. 4) with a molybdenum grease. Reinstall the three dowel pins (5) on the flywheel (1).
10. Using the centring tool MF 457, centre the clutch disc (6) on the engine flywheel (Fig. 3). The longest section of the hub must be facing the diaphragm.
11. Refit the clutch cover plate.
12. Gradually tighten the attaching bolts (8) to a torque of 25 - 30 Nm.
13. Remove the centring tool MF 457.
14. Recouple the tractor between the engine and the gearbox (see Section 3 A04).

### B. Engine flywheel

#### Disassembly (Fig.4)

1. Split the tractor between the engine and the gearbox (see Section 3 A04).
2. Remove the engine clutch (see part A).
3. Immobilise the engine flywheel (1).
4. Take out the six bolts (4).
5. Remove the engine flywheel (1) and the hub (3).





5Q01.6



## Gearbox - Dynashift

### Reassembly

6. If the friction surface on the engine flywheel (1) is scored it can be skimmed.  
Skimming of the friction surface should be performed as required (removal : 1.5 mm max. - surface condition : 2.5 micrometres max.).  
Reduce the length of the three dowel pins (5) by the same amount.  
**Note: Check that the tapped holes for the bolts (8) attaching the mechanism onto the flywheel are deep enough. If they are not, they must be tapped. After reworking, grease the flywheel.**
7. Fit two dowel pins into the flywheel attaching holes.
8. Refit the hub (3) and the flywheel (1).
9. Clean the bolts (4) and coat them with Loctite 241.
10. Reinstall the six bolts (4) and tighten them to a torque of 110 - 140 Nm.
11. Carry out procedures 1 and 2 in reverse.

### C . Replacing the flywheel ring gear

#### Disassembly

1. Remove the engine flywheel (see part B).
2. Carry out procedures 1 and 2, in part C of Section 5 P01.

#### Reassembly

3. Carry out procedures 4 and 5, in part C of Section 5 P01.
4. Refit the engine flywheel (see part B).

### D . Clutch release bearing assembly

#### Preliminary operation

Split the tractor between the engine and the gearbox (see Section 3 A04).

**Note: Do not press the clutch pedal.**

#### Disassembly

1. Separate the release bearing assembly (33) from the clutch cover plate (33).
2. Remove the cover (34), the clutch release bearing (33) and the spring washer (35).

#### Reassembly

3. Carry out procedures 15 to 17, in Section 3 A04.
4. Recouple the tractor between the engine and the gearbox. Carry out procedures 18 to 33, in Section 3 A04.

### E . Hydraulic slave cylinder assembly

#### Preliminary operation

Split the tractor between the engine and the gearbox, as per Section 3 A04.

#### Removal

1. Disconnect:
  - the supply pipes,
  - the bleed pipes.
2. Take out bolts (9). Remove the slave cylinders.

#### Refitting

3. Position the slave cylinders on the Dynashift cover.
4. Fit the bolts (9) and tighten them to a torque of 25 - 35 Nm.
5. Reconnect the pipes.
6. Clean the clutch housing with a solvent.
7. Recouple the tractor between the engine and the gearbox, as per Section 3 A04.
8. Bleed the clutch system (see part H).

### F . Replacing the slave cylinder seals

#### Preliminary operation

Split the tractor between the engine and the gearbox, as per Section 3 A04.

#### Disassembly

1. Remove the slave cylinders (see part E).
2. Withdraw the piston /23\ by knocking the slave cylinder on a wooden block.
3. Drive out the scraper rings /27\ and their O-rings /29A\.
4. Remove :
  - the guide rings /28\,
  - the sealing bushes /29\ and the O-rings /29A\.





## Gearbox - Dynashift

### Reassembly

5. Clean the slave cylinder (24) (Fig. 5) and the seal grooves.  
Check that :
  - the bleed and supply pipes are not blocked,
  - there is no scoring in the bores and on the pistons
6. Shape the guide rings /28\ so as to decrease their diameter by approximately one third. Using pliers and wearing protective equipment, install the rings in their grooves (Fig. 5), with the knurled face in contact with the piston /23\.
7. Lubricate and fit the O-rings /29A\ in their groove without twisting them.
8. Shape the sealing bushes /29\ as per Fig. 6.  
**Note : The sealing bushes must be positioned with their lips facing the pressure side (Fig. 5).**
9. Position the sealing bushes in the grooves, gradually fitting them on the O-rings /29A\.
10. Lubricate the sealing bushes, the guide rings /28\ and the cylinder bores.
11. Check that there are no burrs on the pistons /23\ . Fit the pistons, with the "C" chamfers facing the inside of the cylinders (Fig. 5).
12. Position the O-rings and scraper rings /23\ in their corresponding grooves.
13. Fit the pistons and check that they move normally in their bores.
14. If they were removed, fit unions (14) and (15).
15. Reinstall the hydraulic slave cylinders (see part E). Reconnect the pipes.
16. Clean the clutch housing with a solvent.
17. Recouple the tractor between the engine and the gearbox (see Section 3 A04).
18. Bleed the brake and clutch systems. See part H and parts C and D in Section 6 K01.
19. Carry out a road test on the clutch control.
20. Check the unions for leaks.

## G. Replacing the clutch release bearing guide rings

### Preliminary operation

Split the tractor between the engine and the gearbox, as per Section 3 A04.




Fig. 5




Fig. 6

### Disassembly

1. Remove the hydraulic slave cylinders (see part E).
2. Withdraw the release bearing carrier (26). Remove the guide rings /30\ .  
**Note: If necessary, remove the guide cylinder (25) using socket 3376936 M1 (see part J).**

### Reassembly

**Note: If it was removed, apply Loctite 542 on the thread on the guide cylinder (25). Tighten to a torque of 40 - 50 Nm.**

3. Shape the guide rings /30\ so as to decrease their diameter by approximately one third.  
Install the rings in their grooves, with the knurled face in contact with the release bearing carrier (26).



5Q01.8

## Gearbox - Dynashift

4. Lubricate the guide rings and the bore in the release bearing carrier.
5. Check that the rings are correctly positioned. Assemble the *release bearing carrier (26)* on the guide cylinder (25). Check that the notches **E** on the rear face of the release bearing carrier are lined up with bolts (20) (Fig. 1). Check that the release bearing carrier slides freely.
6. Reinstall the hydraulic slave cylinders (see part E).
7. Recouple the tractor between the engine and the gearbox (see Section 3 A04).




Fig. 7

### H. Bleeding the system

1. Run the engine at approximately 1,200 rpm and restrict the return hose (1) (see Fig. 7) with suitably protected pliers or clamp.
2. Connect the union 3582045 M1 (1) together with its hose (Fig. 8) onto the bleed point (on the right-hand side of the gearbox).
3. Immerse the end of the hose in a receptacle partly filled with transmission oil.
4. Operate the clutch pedal. Repeat the action several times, until oil free of bubbles comes out of the hose.
5. Remove the union and release the hose.

**Note:** *On this type of clutch, pedal travel is taken up automatically. If, however, the clutch does not operate correctly, repeat the air bleed procedure.*




Fig. 8

### I. Adjusting the clutch pedal

Before installing, coat the pins (3) and (4) with molybdenum disulphide grease.

Apply Loctite 542 on the threads of rod (1) (Fig. 9). Adjust the rod to obtain a pedal travel of 200 mm between the disengaged position (pedal against the stop (2)) and the engaged position.





Fig. 9




# Gearbox - Dynashift

## J. Service tools available from the MF network


**MF 457**  
Clutch disc centring tool



**3582045 M1**  
Hydraulic quick coupler (union)



**3376936 M1**  
Socket for release bearing carrier guide





**Gearbox - Dynashift**

5R01.1

*5 R01 Input unit*

CONTENTS

-	<b>General</b> _____	<b>2</b>
A.	<b>Removal</b> _____	<b>2</b>
B.	<b>Refitting and adjusting the reverse gear selector</b> _____	<b>3</b>
C	<b>Service tool</b> _____	<b>4</b>



5R01.2



## Gearbox - Dynashift

### General

The input gearbox is in the form of an interchangeable module fitted at the input end of the gearbox. It is made of two quite separate parts. The Dynashift unit and the reverse shuttle.

**The Dynashift:** This is an independent device which allows four ratios to be selected while running, without declutching; using a lever located under the steering wheel. The Dynashift assembly is secured to the front of the input unit. It is a hydraulically controlled gear change device providing for ratios on input to the gearbox.

This function is ensured by two epicyclic gear trains associated with two hydraulic clutches.

For its operation, see Section 5 R02.

**The reverse shuttle:** This is housed in the enclosure to the rear of the input gearbox and consists of a set of two gears operated via a synchromesh mechanism. A pair of idler gears allows the direction of rotation to be reversed. For its operation, see Section 5 R03.

### A. Removal

When the input gearbox is replaced, the layshaft shimming must be adjusted. To allow the bearings to be shimmed correctly, the gearbox must be removed from the tractor.

#### 3000-3100 tractors

1. Split the tractor between the gearbox and the rear axle (Section 3 B02).
2. Remove the selector cover and carry out procedure 11 and 12 in Section 5 X01.

#### 3000 tractors

3. Separate the gearbox from the engine. Carry out procedures 9 and 11 to 12 in Section 3 A03. Remove the PTO shaft.

#### 3100 tractors

4. Separate the gearbox from the engine. Carry out procedures 3 and 4, and 12 to 14 in Section 3 A04. Remove the PTO shaft.




Fig. 1




Fig. 2

#### 3000 - 3100 tractors

5. To facilitate the removal of the input unit, remove the bolts (34). Remove the selector (33) (Fig. 1).
6. Remove the clutch slave cylinder or cylinders (depending on the type) and install the sling 3376883M1 (see part J of Section 5 R02), using bolts of the correct length (Fig. 2).
7. Remove the eight bolts (30) (Fig. 2).  
**Note: Do not remove the three bolts (66), dimensioned across flats 13 (Fig. 2).**



## Gearbox - Dynashift

8. Detach and remove the input unit, pulling it forwards.
9. Discard the O-rings (2) and (3). Recover the cup (64) and the locating pin (4) (Fig. 3 and 4).

### B. Refitting and adjusting the reverse gear selector

#### Refitting

10. On the input unit, check that the cup (64) O-ring (2) are in position (Fig. 3).
11. On the housing, position the new O-rings (3) and the locating pin (4) (Fig. 4).
12. On the gearbox, screw in two locating studs "G", as per Fig. 4. Offer up the gearbox in the housing, using the sling.
13. At a first stage, with the help of an operator, slightly lift the layshaft through the opening of the selector cover in order to engage the cone of the shaft in the cup (64).
14. Position the housing with respect to the locating pin. Tighten the bolts to a torque of 45 - 60 Nm.
15. Remove the sling.
16. Refit the clutch slave cylinder or cylinders, depending on the type (see Section 5 P01 or 5 Q01, part G, procedure 5). Fit the bolts:
  - 3000 series: First coat them with Loctite 542 and tighten to a torque of 36 - 46 Nm,
  - 3100 series: Tighten to a torque of 25 - 35 Nm.
17. Shim the layshaft. Carry out procedures 25 to 35, in Section 5 T01.

#### 3000 tractors

18. Recouple the gearbox to the engine. Carry out procedures 13 to 16, in Section 3 A03.
19. Carry out procedures 17 and 18, in Section 3 A03.




#### 3100 tractors

20. Recouple the gearbox to the engine. Carry out procedures 15 to 23, in Section 3 A04.

#### 3000/3100 tractors

##### Adjusting the reverse gear selector

21. Position the selector (33) to the neutral position. Fit and tighten tool 3582434 M1 (see Part C) with two bolts (Fig. 5).
22. Coat the adjusting bolts with Loctite 221.
23. Position face F of the reverse gear selector in contact with the tool using bolts (34) (Fig. 5).





5R01.4

# Gearbox - Dynashift

## Principle of adjustment

The selector (33) is positioned on the basis of the difference in the spacing **Y** of the holes and the spacing **Z** of the spot-faced depressions in the guide rail (31). The selector can be adjusted to move to different points by acting either on the front or the rear screw (32) depending on the adjustment required (Fig. 6).

- 24. Refit the selector cover. Carry out procedures 33 to 38, in Section 5 X01.
- 25. Recouple the tractor between the gearbox and the rear axle (Section 3 B02).
- 26. Carry out road test on ratios A, B, C and D of the Dynashift, reverse shuttle and gears.
- 27. Check the mating faces on the selector cover as well as the gearbox on the rear axle for leaks.

## C. Service tools

### 1. Tool available through MF network




Fig. 6

3583434 M1 - Reverse shuttle setting gauge




Fig. 7

3376883 M1 - Lifting bracket





Fig. 8

### 2. Tool to be made locally

Handling bar



5 holes, 7 mm dia.



*5 R02 Dynashift input unit*

CONTENTS

-	<b>General description</b> _____	<b>2</b>
-	<b>Operation</b> _____	<b>2</b>
A.	<b>Preliminary operations</b> _____	<b>8</b>
B.	<b>Disassembling the cover, housing, front clutch and brake</b> _____	<b>9</b>
C.	<b>Removing and separating the planetary carrier</b> _____	<b>10</b>
D.	<b>Disassembling the rear clutch and brake</b> _____	<b>10</b>
E.	<b>Assembling the planetary carriers</b> _____	<b>10</b>
F.	<b>Reassembling the rear clutch and brake</b> _____	<b>11</b>
G.	<b>Reassembling the cover, front clutch, brake and spacer housing</b> _____	<b>12</b>
H.	<b>Shimming the planetary carriers</b> _____	<b>14</b>
I.	<b>Reinstall primary shaft, cover and housing assembly</b> _____	<b>15</b>
J.	<b>Service tools</b> _____	<b>16</b>





5 R02.2

## Gearbox - Dynashift

### General

#### Description

The general conception of the Dynashift input unit 3000/3100 is the same as the tractor 3600.

But it's important to note that the spacer (21) is fixed on the gearbox housing instead of being mounted on the reverse shuttle housing.

Only a Belleville spring /52\ operates on the brake and the rear clutch

#### Particularities 3100

The front of the support hub (11) is threaded and supports the guide of the release bearing carrier.

Sealing with the primary shaft is obtained by a wide seal (77) only.

The Dynashift assembly is fitted at the front of the input unit. It is a hydraulically controlled gearchange device which provides four input ratios to the main gearbox. It does this by means of two epicyclic gear trains connected to two hydraulic clutches.

The Dynashift design allows four ratios to be selected on the move, without declutching, using a control located under the steering wheel.

The Dynashift unit is controlled by two solenoid valves fitted in the low flow hydraulic circuit.

The two solenoid valves are themselves controlled by an electronic control unit located under the instrument panel and connected to the tractor's Autotronic unit.

### Operation

The dynashift input unit includes two epicyclic gear trains :

- The primary epicyclic unit is the major component of the input unit and is used to transmitting engine motion to the gearbox.
- The secondary epicyclic unit controls the speed of the primary sun gear.

#### Primary epicyclic gear train

Motion enters via the primary ring gear (31) which is splined onto the primary shaft (7). It turns at engine speed.

The motion is transmitted via the planetary carrier (28) which is splined onto the secondary shaft (53). The primary sun gear (64) is driven by the secondary epicyclic gear train. The speed of this sun gear determines the unit reduction ratio.

#### Secondary epicyclic gear train

This epicyclic gear train is controlled by hydraulic clutches and brakes.

The secondary ring gear (34) is :

- either locked onto the primary shaft (7) by the three clutch discs (3) and the Belleville spring /4\ located in the front part of the unit.
- or immobilized in relation to the housing by three brake discs (15) and one piston (22).

With no pressure, the piston (22) is pushed to the rear by the twelve springs (20) and the Belleville spring /4\ via the brake plate (16).

When pressure from the 17 bar circuit acts on piston (22), it moves forward, locks the brake discs (15) and pushes plate (16), which compresses the Belleville spring /4\.

The secondary ring gear speed is established as follows :

- speed equal to engine speed when the front piston is not under pressure.
- speed zero when the front piston is under pressure.

The sun gear (61) is either :

- locked on the secondary shaft by means of the four clutch discs (50) and one Belleville spring /52\ located at the rear part of the unit.
- or immobilized in relation to the housing by means of the three brake discs (41) and one piston (37).

With no pressure, piston (37) is pushed towards the front by the Belleville spring and the six springs (65).

Under 17 bar pressure, piston (37) moves towards the rear and locks the brake discs (41). It compresses the Belleville spring /52\ via the brake plate (45), which frees up the secondary shaft clutch discs.

When the secondary ring gear (34) or the sun gear (61) is immobilized, the speed of the secondary planetary carrier (39) changes. The secondary planetary carrier drives the primary sun gear (64) and produces the unit reduction ratio.

### Service tools

#### Tools available for MF dealers (See section J)

- Lifting bracket for front cover unit, No. 3376883 M1
- Centering tool, No. 3376887 M1
- Secondary ring gear retaining tool, No. 3376888 M1
- Sling for shaft and cover assembly, No. 3376889 M1
- Planetary carrier compression tool, No. 3376920 M1
- Calibrated pins, No. 3376925 M1

#### Tool to be made up locally

- Adaptor bar




# Gearbox - Dynashift

5 R02.3

### Key (Fig. 1)

- (1) Secondary ring gear carrier
- (2) Clutch driven plates
- (3) Clutch driving plates
- /4\ Belleville spring
- (5) Splined hub
- (6) Needle bearing
- (7) Primary shaft
- /8\ Wide seal
- /9\ Narrow seal
- (10) Thrust washer
- (11) Support hub
- (12) Bolt
- (13) Front cover
- (14) Clutch housing
- (15) Front brake discs
- (16) Brake plate
- (17) Pressure plate
- (18) Bolt
- (19) O-ring
- (20) Springs
- (21) Spacer (piston housing)
- (22) Front piston
- (23) Blanking plug
- (24) O-ring
- (25) Bolt
- (26) O-ring
- (27) Ball bearing
- (28) Primary planetary carrier
- (29) Blanking plug
- (30) Screw
- (31) Primary ring gear
- (32) O-ring
- (33) Bolt
- (34) Secondary ring gear
- (35) O-ring
- (36) O-ring
- (37) Rear piston
- (38) Pressure plate
- (39) Secondary planetary carrier
- (40) Reverse shuttle housing
- (41) RH Brake disc
- /42\ Secondary brake housing
- (43) Bolt
- (44) Pressure plate
- (45) Brake plate
- (46) Bolt
- (47) Cover
- (48) Driven plate
- (49) Retaining ring
- (50) Rear clutch driving plate

- (51) Thrust washer
- /52\ Belleville spring
- (53) Secondary shaft
- (54) Splined hub
- (55) Circlip
- (56) Spacer
- (57) Ball bearing
- (58) Ball bearing
- (59) Rear clutch housing
- (60) Retaining ring
- (61) Secondary sun gear
- (62) Retaining ring
- (63) Locating needles
- (64) Primary sun gear
- (65) Springs
- (66) Bolt
- (67) O-ring
- (68) O-ring
- (69) Circlip
- (70) Thrust plate
- (71) Shim(s)
- (72) Retaining ring
- (73) O-ring
- (74) Plug
- (75) Oil deflector
- (76) Ball
- (77) Wide seal (serie 3100)






5 R02.4

3000 / 3100 SERIES TRACTORS



# Gearbox - Dynashift



### Explanation of ratios

#### Ratio A = 1:1.620 reduction (Fig. 3)

The two pistons (22) and (37) are simultaneously under pressure from the 17 bar circuit.

The secondary ring gear (34) is locked onto the housing by means of the front brake.

The secondary sun gear (61) is locked onto the housing by means of the rear brake.

As a result, the secondary epicyclic gear train is locked. The primary sun gear (64) is locked.

The reduction ratio is fixed only by the primary epicyclic gear train. It uses traditional gearing: motion enters via the ring gear and leaves via the planetary carrier, while the sun gear remains immobile.

#### Ratio B = 1:1.386 reduction (Fig. 4)

The front piston (22) is under pressure.

The secondary ring gear (34) is locked onto the housing by means of the front brake.

The rear piston (37) is not under pressure.

The secondary sun gear (61) turns with the secondary shaft (53) (the clutch is engaged).

The secondary planetary carrier (39) turns at slow speed, driving the primary sun gear (64).

This causes the reduction ratio to be less.



# Gearbox - Dynashift




Fig. 3




Fig. 4



5 R02.6

## **Gearbox - Dynashift**

### **Ratio C = 1:1. 1704 reduction (Fig.5)**

The rear piston **(37)** is under pressure.

The secondary sun gear **(61)** is locked onto the housing by the rear brake.

The front piston **(22)** is not under pressure.

The secondary ring gear **(34)** turns with the primary shaft **(7)**, thus imparting a higher speed to the secondary planetary carrier **(39)**.

The primary sun gear **(64)** is driven by the secondary planetary carrier **(39)** at a higher speed than in ratio B. This therefore gives less reduction.

### **Ratio D = 1:1. reduction (Fig.6)**

Neither of the two pistons is under pressure. The two clutches are therefore engaged.

The secondary ring gear **(34)** turns with the primary shaft **(7)**

The secondary sun gear **(61)** is locked onto the secondary shaft **(53)** thus mechanically locking the entire system.

The ratio is therefore 1:1 (direct drive).



# Gearbox - Dynashift




Fig. 5




Fig. 6



## Gearbox - Dynashift

### A. Preliminary operations

1. Split the tractor between the engine and the gearbox :
  - see section 3 A03 (3000)
  - see section 3 A04 (3100)
2. Drain only the gearbox.
3. At the left hand front of the gearbox, disconnect the clutch slave cylinder(s) supply hose (tractors 3000 or 3100).
4. Inside the clutch housing, disconnect :
  - pipes **(13)** and **(16)**, the union **(12)** (Fig. 7 and 8) (tractors 3000 and 3100)
  - the tube **(1)**.Remove the union **(10)** (Fig. 7 and 8) (tractors 3000 and 3100).  
Disassemble the grommets **(2)**, **(11)** and **(17)** (Fig. 7 and 8) (tractors 3000 and 3100).
5. Remove the PTO shaft.
6. Remove the clutch slave cylinder(s). Fit the lifting bracket 3376883 M1, using bolts of the correct length (Fig.9).  
Immobilize the reverse shuttle lever in forward position so as to retain the reverse shuttle housing (Fig.10).




Fig. 7




Fig. 8




Fig. 9




Fig. 10






## Gearbox - Dynashift

7. Remove two screws (30) diametrically opposed and screw two guide studs "G" (Fig.11). Remove the other six screws.
8. Unscrew the three bolts (66) gradually and alternately (Fig. 11) (flat to flat dimension 13 mm) fixing the housing (21) on the reverse shuttle housing (40).

### B. Disassembling the cover, the housing, front clutch and brake

9. Remove the primary shaft assembly (7), cover (13) and housing (21). Discard the O'rings (32), (67) and (68).
10. Remove the lifting bracket.
11. Turn the front cover/housing assembly over onto a suitable support (Fig.12).
12. Retain the thrust washer (70) and the shims (71).
13. Remove the circlip (69), take out the primary shaft (7) downwards, taking care not to damage :
  - the seals /8\ and /9\ (tractor 3000)
  - the seal /77\ (tractor 3100)
14. Take the piston (37) out the housing (21). Remove the seals (35), (36) and discard them.
15. Turn the ring gear (31) so as to have access to the bolts (25).
16. Using tool 3376888 M1, immobilize the ring gear (34). Remove the bolts (25) (Fig.13).
17. Take out the ring gear assembly (34), its carrier (1), ring gear (31), bearing (27).
18. If necessary, remove the bolts (33), to separate the ring gear (34) from its carrier (1). Remove the bearing (27) from the ring gear (31).
19. Unscrew the bolts (18) gradually and alternately, remove the housing (21). Discard the seal (19).
20. If necessary, take the piston (22) out of the housing, discard the seals (24) and (26).
21. Remove the discs (3), the driven plates (2) and the splined hub (5).
22. Remove the springs (20), the discs (15) separated by the brake plate (16) and the pressure plate (17).
23. Take out the Belleville spring /4\, the clutch housing (14), and its the thrust washer (10).
24. If necessary, take the seals /8\ and /9\ out (tractor 3000), the seal /77\ (tractor 3100) and the needle bearing (6). Discard the parts. Remove screws (12), separate the support hub (11) from the cover (13) (hit the back of the support, using a plastic hammer).







5 R02.10



## Gearbox - Dynashift

### C. Removing and separating the planetary carrier assembly

25. Compress the planetary carrier assembly using special tool 3376920 M1 (Fig.14).
26. Remove the retaining ring (72). Lift off the primary planetary carrier assembly.
27. Remove the secondary sun gear (61) and the retaining ring (49) (if necessary).
28. Remove the circlip (55). Remove the planetary carrier bearing (57) and the spacer (56).
29. Separate the secondary planetary carrier (39) from the primary planetary carrier (28).
30. Remove the retaining ring (60) and the bearing (58).
31. Place the secondary carrier in vertical position. Tapping lightly on a wooden block, remove the needles (63) (Fig.15). Separate the planetary carrier from the primary sun gear (64), with the ring (62) and the deflector (75).




Fig. 14

### D. Disassembling the rear clutch and brake

32. Remove the pressure plate (38), the pressure plate springs (65), the brake discs (41), separated from the pressure plate (44).
33. Remove the clutch housing assembly (59), incorporating brake plate (45) and the last disc (41). Remove the thrust washer (51).
34. Remove the clutch cover screws (46). Remove the cover (47) and the Belleville spring (52). Separate the brake/clutch plate (45), the clutch discs (50) and the driven plates (48). Remove the hub (54).
35. Remove the screws (43). Separate and remove the secondary brake housing (42). Mark its position.




Fig. 15

### E. Assembling the planetary carriers

36. Clean and inspect the parts. Replace any which are defective.
37. Make sure that the secondary shaft lubrication holes are not obstructed.
38. Check axial play and rotation of each planetary manually.
39. Onto the secondary planetary carrier (39), fit the primary sun gear (64) along with its bearing retaining ring (62) and the deflector (75).



## Gearbox - Dynashift

40. Slide the three needles (63) into each hole of the primary sun gear. They must be fully home to the bottom of the groove in the secondary planetary carrier.
41. Fit the ball bearing (58) and the retaining ring (60).
42. Assemble the secondary planetary carrier on the primary planetary carrier (28). To facilitate the entry of the gear teeth, turn the planetary gears.
43. Fit the spacer (56) and the ball bearing (57). Install the circlip (55).
44. Check the backlash between the primary planetary gears manually.
45. Fit the ring (49) (if it was removed) into the secondary sun gear (61).




Fig. 16

### F. Reassembling the rear clutch and brake

46. Clean and inspect the parts, replace any which are defective.
47. Direct a jet of compressed air into the reverse idler gear port to ensure that it is not obstructed.
48. Coat the seal mating surface of the brake housing (42) with a sealing compound in the area of the lubrication passage (Fig.16).
49. Fit the input unit like it was during the dismantling. Coat the screws (43) with Loctite 241 and tighten them to a torque of 29 - 37 Nm.
50. To gain access to the bolts (46), turn over the planetary carriers. Place the secondary planetary (61), the housing (59) and the splined hub (54) with the internal splines facing downwards (Fig.17). Install the rear discs (50), the driven plates (48) and the pressure plate (45), the Belleville spring (52) as Fig.1, then the cover (47).
51. Centre the clutch housing assembly (59) using tool 3376887 M1 (Fig.18). Coat the bolts (46) with loctite 241 and torque them to 12 - 16 Nm. Remove the tool. Separate the housing assembly from the planetary carriers.
52. Coat the washer (51) with miscible grease and place it on the cover (47).
53. Fit a disc (41) in the brake housing (42).




Fig. 17





Fig. 18





5 R02.12

**Gearbox - Dynashift**

54. Fit the clutch housing assembly (59) and the washer (51) on the shaft (53). Fit the splined hub (54), with its internal splines pointing upwards (Fig.19).
55. Fit the two other brake discs (41), separated by the pressure plate (44). Position the sun gear (61) together with the ring (49), on the clutch housing (59).

**G. Reassembling the cover, front clutch, brake and spacer housing**

56. Clean the seal mating surface and the cover (13). Check that the plug (74) is fitted. Make sure that the lubrication passage is not obstructed.
57. Clean the support hub (11). Check that the lubrication holes are not obstructed.
58. If necessary, fit and then position :
- Tractor 3000** (Fig. 20)
- The needle bearing (6) at 0 - 0,3 from face H
  - The narrow seal /9\ pressing on shoulder E
  - The wide seal /8\ at 0,2 - 0,6 from face G
- Tractor 3100** (Fig. 21)
- The needle bearing (6) at 0 - 0,3 from face H
  - the seal /77\ pressing on shoulder E.
- Note : Use a press and a suitable assembly device to fit the bearing and the seals correctly.**
59. After fitting the seals /8\ and /9\, make sure that orifices O are not obstructed (Fig. 20).
60. Coat the surface of the cover which contacts the support (11) with sealing compound.
61. Screw in two guide studs G. Position the support (Fig. 22) making sure that lubrication hole meets up with the corresponding passage in the cover (Fig. 22).
62. Fit the support into the cover (Fig. 22).
63. Remove the guide studs. Coat the screws (12) with Loctite 542, fit and torque to 14 - 20Nm.
64. Place the cover on a suitable support (Fig. 23).
65. Make sure that lubrication holes of the primary shaft (7) are not obstructed. Protect the splines to avoid damage to the seals /8\ and /9\ or /77\ (following type). Lubricate the shaft and slide it into the support from below. Retain the shaft in position using the locally made tool (Fig. 23).





## Gearbox - Dynashift

66. Remove the spline protection.
67. Coat the thrust washer (10) with miscible grease and place it on the housing (14).
68. Place the housing with the thrust washer on the support (11).
69. Fit the Belleville spring (4) the correct way round (Fig. 1), a brake disc (15) and a brake plate (16).
70. On the primary shaft (7) fit the splined hub (5) with its internal splines pointing upwards (Fig. 24). Fit the discs (3) and the driven plates (2).
71. Fit the two other brake discs (15), separated by the pressure plate (17).
72. Reinstall the springs (20). Fit the O-rings (19) and (73).
73. Check that the blanking plugs (23) and (29) are in place. Make sure that the supply holes to the front and rear piston chambers in the spacer housing (21) are not obstructed.
74. Lubricate O-rings (24) and (26) and fit them respectively in the front piston (22) and in the spacer housing (21).
75. Position the front piston in the spacer housing and drive in it using a plastic hammer, tapping gradually and alternately around its circumference.
76. Screw two diametrically opposed guide studs into the spacer housing (21) and position it on the front cover (13), making sure that the spacer housing lubrication hole meets up with the corresponding passage in the cover.
77. Remove the guide studs. Fit and tighten the bolts (18) to a torque of 29 - 37 Nm. Connect a pressure gauge fitted with a shut-off valve to the front piston orifice. Connect a 0,3 bar compressed air line to the circuit. Close the shut-off valve and check that no pressure drop occurs within 1 minute.
78. If it was removed, reinstall the bearing (27) on the primary ring gear (31). Place the secondary ring gear (34) on the secondary ring gear carrier (1). Coat the bolts (33) with Loctite 241, fit and tighten to a torque of 12 - 16 Nm.
79. Screw two guide studs into the clutch housing (14). Fit the secondary ring gear (34), carrier (1), primary ring gear (31) and bearing (27) assembly onto the primary shaft (7). Remove the guide studs. Fit the bolts (25). Immobilize the secondary ring gear (34) as Fig. 13. Coat the bolts (25) with Loctite 241 and tighten to a torque of 29 - 37 Nm.
80. Fit the circlip (69).
81. Lubricate, then fit seals (35) and (36) on the rear piston (37).
82. Position the piston in the housing and drive it home using a plastic mallet, tapping gradually around its circumference. Maintain the rear piston in place by means of a suitable device. Check that the seals are leakproof using operation 77 above.




Fig. 22




Fig. 23




Fig. 24



5 R02.14

3000 / 3100 SERIES TRACTORS



## Gearbox - Dynashift

### H. Shimming the planetary carriers

This operation consists of obtaining a play **J1** from **0,50 to 0,70** between the stop (70) and the front face of the primary planetary carrier (28) (Fig. 25).

This shimming must be carried out if any operation is performed on the following parts :

- housing (21),
- cover (13),
- support (11),
- washer (10),
- housing (14),
- ring gear carrier (1),
- bearing (27),
- ring gear (31),
- circlip (69),
- stop (70),
- planetary carrier (28),
- bearing (58),
- spacer (56),
- bearing (57),
- ring (49),
- housing (59),
- cover (47),
- washer (51).

To do this shimming correctly, the springs (65), the pressure plate (38) and the shims [71] must not be fitted.

**Note :** If shimming is not necessary, continue operations as from 89 to 104.

83. Fit stop (70) on the primary shaft (7).



On the spacer housing (21)

84. Using calibrated pins 'P' 3376925 M1 and a depth gauge with an engineer straight edge, measure dimension X (Fig. 26) at two opposing points. Calculate the mean of the two measurements.

**Note :** Subtract the thickness of the straight edge.

On the reverse shuttle housing (40)

85. Remove the guide studs. Retain the housing using two bolts (30) diametrically opposed (Fig. 14).





## Gearbox - Dynashift

86. Slide the planetary carrier assembly on the shaft and place it fully home, using a compression tool 3376920 M1 (Fig. 27).
87. Screw the pins **P** (Fig. 27) in contact with the housing. Using depth gauge with an engineer straight edge, measure dimension **Y** (Fig. 27).  
**Note : Subtract the thickness of the straight edge.**
88. Calculate the play to obtain :  
**J1 = 0,50 to 0,70**  
Find the initial play from the formula :  
**J1 = (X+Y) - 220**  
where 220 = 2a  
a = length of calibrated pins  
Depending of the initial play, select the thickness of shims needed **[71]** to obtain **J1** at the tolerance shown.
89. Place the shim pack **[71]** between circlip **(69)** and stop **(70)** coated with miscible grease (Amber Technical or equivalent).
90. Remove the compression tool and the planetary carriers (if shimming). Coat the springs **(65)** with miscible grease and reinstall them. Position the pressure plate **(38)**, making sure that the notches line up with the lugs on the brake housing **/42**. Place the planetary carriers on the shaft **(53)** and compress them using tool 3376920 M1 (Fig. 14).
91. Fit the retaining ring **(72)**. Remove the tool. Check manually the play between the secondary planetary gears backlash.

### I. Reinstall primary shaft , cover and housing assembly

92. Place new O'rings **(32)**, **(67)**, **(68)** coated with grease, on the reverse shuttle housing. Remove the two bolts **(30)** retaining the reverse shuttle housing. Screw two guide studs in diametrically opposed.
93. Fix the lifting bracket 3376883 M1 on the cover **(13)**. Reinstall the primary shaft assembly **(7)**, cover and housing **(21)** (Fig. 11) lining up the lubrication holes and the circuit 17 bar.
94. Turn the shaft so as to engage the planetary gears in the ring gears.
95. Fix two screws **(30)**. Remove the guide studs. Fit six other bolts (Fig. 11). Fit screws and tighten to a torque of 45 - 60 Nm.
96. Fit three screws **(66)** and tighten to a torque of 25 - 35 Nm (Fig. 11).
97. Remove the lifting bracket. Reinstall the clutch slave cylinder(s) (for different type, see section 5P01 or 5Q01). Coat only the bolts 3000 with Loctite 542 and tighten to a torque of :
  - 36 - 46 Nm (3000)
  - 25 - 35 Nm (3100)
98. Reverse operations 3 and 4.
99. Clean the clutch housing with a solvent.
100. Replace the sealing of the input shaft
  - **3000 serie tractors** : see operation 14, section 3A03.
  - **3100 serie tractors** : see operation 19, section 3A04.
101. Couple the tractor together at the engine and the gearbox (section 3A03 - 3000 serie tractor, section 3A04 - 3100 serie tractor).
102. Fill the rear axle with oil to the correct level.
103. Road test all controls and Dynashift A, B, C and D ratios.
104. Check the sealing of the unions.




Fig. 27




## Gearbox - Dynashift


### J . Service tools

- Lifting bracket for input unit No 3376883 M1
- Centering tool No 3376887 M1
- Secondary ring gear retaining tool No 3376888 M1
- Planetary carriers compression tool No 3376920 M1
- Calibrated pins No 3376925 M1.


3376883 M1




3376887 M1




3376888 M1



3376920 M1



3376925 M1






# Gearbox - Dynashift

Tool to be made up locally

- Adaptor bar



5 holes Ø 7 mm





**Gearbox - Dynashift**

5 R03.1

*5 R03 Reverse shuttle*

CONTENTS

-	<b>General</b> _____	<b>2</b>
-	<b>Operation</b> _____	<b>2</b>
A.	<b>Input unit removal</b> _____	<b>5</b>
B.	<b>Dynashift dismantling</b> _____	<b>6</b>
C.	<b>Reverse shuttle dismantling and reassembly</b> _____	<b>6</b>
D.	<b>Dynashift reassembly</b> _____	<b>8</b>
E.	<b>Input unit assembly and refitting</b> _____	<b>8</b>
F.	<b>Service tool</b> _____	<b>9</b>



5 R03.2

## Gearbox - Dynashift

### General

The reverse shuttle transmits drive from the dynashift to the mainshaft located at the front of the main gearbox.

The reverse shuttle assembly is located at the rear of the input unit behind the Dynashift. It comprises :

- two helical gears (5) and (23) running on two needle roller bearings (6) and (20).
- a synchronmesh assembly which the hub (2) is splined onto the secondary shaft (19).
- a synchronmesh selector rail and fork assembly
- a secondary shaft (19) mounted on taper roller bearings (24) (37) and (9) (38) supported at both ends in the reverse shuttle housing.
- a compound gear (15) in constant mesh with the gear (23) and the gearbox input gear (67).

### Operation

#### Forward drive

When moved rearwards the synchronmesh coupler connects gear (5) with shaft (19) and gear (67) with shaft (69). Gear (5) transmits drive to main shaft (69) via gear (67) in constant mesh with gear (5).

#### Reverse drive

When moved forward the synchronmesh coupler connects gear (23) with shaft (19). The drive is transmitted to main shaft (69) via gear (23), the teeth of gear (15) and gear (67).

#### Service tool

Lifting bracket for input unit, No 3376889 M1 (see paragraph F).


### Key

- |                                 |                            |
|---------------------------------|----------------------------|
| (1) Shims                       | (20) Needle roller bearing |
| (2) Synchronmesh hub            | (21) Synchronmesh ring     |
| (3) Synchronmesh ring           | (22) Synchronmesh cone     |
| (4) Synchronmesh cone           | (23) Gear                  |
| (5) Gear                        | (24) Front bearing cone    |
| (6) Needle roller bearing       | (25) Retaining plate       |
| (7) Bush                        | (26) Housing               |
| (8) Thrust washer               | (27) Locking pin           |
| (9) Rear bearing cone           | (28) Spring                |
| (10) Screw                      | (29) Plug                  |
| (11) Spacer                     | (30) Fork                  |
| (12) Thrust washer              | (31) Selector rail         |
| (13) Reverse gear pin           | (32) Adjusting screw       |
| (14) Needle roller bearing      | (33) Selector              |
| (15) Compound gear              | (34) Adjusting screw       |
| (16) Needle roller bearing      | (35) Thrust washer         |
| (17) Thrust washer              | (36) Screw                 |
| (18) Synchronmesh/gear assembly | (37) Front bearing cup     |
| (19) Secondary shaft            | (38) Rear bearing cup      |
|                                 | (39) Ball                  |



# Gearbox - Dynashift


5 R03.3





5 R03.4

# Gearbox - Dynashift





## Gearbox - Dynashift

5 R03.5

### A. Input unit removal

#### Version with shimming of layshaft

**Example :** Replacement of reverse shuttle housing (26). To obtain a correct shimming of the layshaft bearings, the gearbox removal is necessary.

#### 3000/3100 series tractors

1. Split the tractor between the gearbox and the rear axle (section 3B02).
2. Remove the selector cover, carry out operations 11 and 12, section 5X01.

#### 3000 series tractors

3. Disconnect the gearbox from the engine, carry out operations 9 and 11-12, section 3A03. Remove the PTO shaft.
4. Remove the pipes and the clutch slave cylinder.

#### 3100 series tractors

5. Disconnect the gearbox from the engine, carry out operations 3, 4 and 12 to 14, section 3A04. Remove the PTO shaft.
6. Remove the pipes and the clutch slave cylinders.

#### Version without shimming of layshaft

#### 3000 series tractors

7. Split the tractor between the engine and the gearbox (section 3A03). Remove the PTO shaft.
8. Remove the pipes and the clutch slave cylinder.
9. Drain the gearbox only.
10. Remove the selector cover, carry out operations 7 to 12, section 5X01.

#### 3100 series tractors

11. Split the tractor between the engine and the gearbox, section 3A04. Remove the PTO shaft.
12. Remove the pipes and the clutch slave cylinders.
13. Drain the gearbox only.
14. Remove the selector cover, carry out operations 7 to 12, section 5X01.

#### Version with or without layshaft shimming 3000/3100 series tractors

15. Remove the input unit, carry out operations 5 and 7 to 9, section 5R01.
16. Remove the plug (29), the spring (28) and the locking pin (27). Remove the screws (32). Remove selector rail (31) and the fork (30).  
**Note : The locking pin (27) can not be replaced by those of 1st/2nd and 3rd/4th of the gearbox.**
17. Place the input unit in vertical position.



5 R03.6

## Gearbox - Dynashift

### B. Dynashift dismantling

18. Unscrew the three bolts (66) (Fig. 3) gradually and alternately.
19. Using the lifting bracket 3376889 M1, remove the primary shaft assembly (7), cover (13), housing (21) (Fig. 3). Discard O-rings (32), (67) and (68) (Fig. 4).
20. Remove the planetary carrier assembly, carry out operations 25 and 26, section 5R02.
21. Remove the rear clutch and brake, carry out operations 32 - 33 and 35, section 5R02.




Fig. 3

### C. Reverse shuttle, dismantling and reassembly

#### Dismantling

22. Remove the screws (10). Take out pin (13). Remove the compound gear, the washers (12), (17), the needle roller bearings (14) (16) and the spacer (11).
23. Remove the bolts (36). Remove the retaining plate (25), the shims [1] and the cup (37).
24. Take out the secondary shaft (19) (Fig. 5).
25. Remove gear/synchro assembly (18) (Fig. 5) and the washer /8\.
26. Remove the cone (9) and the cup (38).
27. On the gears/synchro assembly, separate: the gear (5), the bush /7\, the needle roller bearing (6), the cone (4), the ring (3), the synchromesh (2), the ring (21), the cone (22), the gear (23), the needle roller bearing (20).
28. If necessary, take out the cone (24) from the shaft and remove the washer /35\.

#### Refitting

29. Clean and check the parts, replace any parts which are defective.
30. Check the parts and oilways on secondary shaft (19), pin (13) and housing (26) are all clear. Check ball (39) is present.
31. Lubricate the shaft, the cones and the bearing cups.
32. Check for the end float between the synchromesh rings and the cones (section 5A01, p 9).




Fig. 4




Fig. 5



## Gearbox - Dynashift

5 R03.7

33. If removed, place the washer /35\ pointing the grooves towards the gear (27). Using a press and an appropriate device, fit the cone (24) fully home on the washer.
34. Fit gear (5) and bush /7\ . Fit the needle roller bearing (6) the cone (4), the ring (3), the synchromesh, the ring (21), the cone (22), the gear (23), the needle roller bearing (20).
35. Reverse operations 25 and 26.  
**Note : Place the washer /8\ pointing the lubrication grooves towards the gear (5) (Fig. 6).**
36. Centre the washer /8\ . By the front bore of the unit, fit the secondary shaft (19) in synchromesh/gear assembly (18). Place recess "E" fully home on the synchromesh (2) (Fig. 7).
37. Position the cup (37) and the retaining plate (25) without the shims [1].
38. Fit and tighten screws (36) to a torque of 36 - 46 Nm.
39. Position the unit in a vice.
40. Shim (Fig. 8) to obtain a preload :  
**P1 = 0,05 to 0,15**




Fig. 6




Fig. 7





Fig. 8



5 R03.8

## Gearbox - Dynashift

41. Place the tip of the dial gauge at the end of shaft (19) (Fig. 9).
42. Pull on the shaft while turning it alternately from right to left to seat the cones correctly in the cups.
43. Set the dial gauge to zero.
44. Repeat operation 42 while pushing.  
**Note:** To get the correct preload, reduce the end float to obtain a value between 0,10 and 0,15.
45. Depending of the end float noted, select shims thickness (1) to obtain P1.
46. Place the unit in vertical position. Remove the screws (36). Remove the retaining plate (25).
47. Place shims selected during operation 45, making sure that they are correctly centered on the cup (37).
48. Refit retaining plate (25). Fit and tighten bolts (36) coated with loctite 241 to a torque of 36 - 46 Nm.
49. Check the end float and the gears (5) and (23) running. Manually, check the free running of shaft (19).
50. Refit compound gear (15). Reverse operation 22.
51. Coat the screw (10) with Loctite 241 and tighten to a torque of 28 - 43 Nm.
52. Check manually the end float and the backlash of the compound gear.




### D. Dynashift reassembly

53. Refit rear clutch and brake, carry out operations 46, 48, 49 and 52 to 55, section 5R02.  
**Note:** The planetary carrier shimming is required in case of intervention on the housing (26) and the retaining plate (25).  
If shimming is necessary (see paragraph H, section 5R02). With or without shimming, carry out operations 89 to 91, section 5R02.

### E. Input unit assembly and refitting

54. Place new O-rings (32) (68) and (67) respectively on the reverse shuttle housing (26) and the housing (21) (Fig. 4).
55. Using the lifting bracket 3376889 M1, refit primary shaft assembly (7), cover (13) and housing (21) (Fig. 3) lining up the galleries of the lubrication circuit and the low pressure circuit 17 bar.
56. Turn the shaft so as to engage the planetaries in the ring gears.



57. Fit bolts (66) (Fig. 3) and tighten gradually to a torque of 25 - 35 Nm.
58. Manually check that shaft rotates correctly.
59. Clean the fork threaded holes.
60. Fit and adjust the fork.

#### Principle :

The fork (30) is positioned by means of the difference in the spacing Y to the tapped holes and the spacing Z of the spot facings in the guide rail (31).  
The fork can be adjusted to move to different points by acting on either the front or rear screws (32) depending on what adjustment required (Fig. 10).





## Gearbox - Dynashift

61. Fit the fork (30), the locking plugger (27), the spring (28) and the plug (29). Tighten the plug to a torque of 50 - 70 Nm. Fit the screws (32) coated with Loctite 221.
62. Select forward gear. Hold the sliding coupler to the gear.
63. Check that a clearance exists between the sliding coupler and the fork pads. If there is no clearance adjust via screws (32).
64. Repeat operations 62 and 63 but in this time select reverse gear. Adjust as required.
65. Tighten the screws to a torque of 35 Nm without changing the setting.
66. Refit the input unit, carry out operations 10 to 15, section 5R01.
67. Refit the clutch slave cylinder(s) (different types, see section 5P01 or 5Q01, paragraph G, operation 5). Fit the screws.
  - 3000 series tractors : coat with Loctite 542 and tighten to a torque of 36 - 46 Nm.
  - 3100 series tractors : tighten to a torque of 25 - 35.Reconnect the pipes.

### Version with shimming of layshaft


68. Shim the layshaft carry out operations 25 to 35, section 5T01.
  69. Adjust reverse shuttle selector, carry out operations 21 to 23, section 5R01.
  70. Remove the selector cover, carry out operations 33 to 38, section 5X01.
- 3000 series tractors**
71. Connect gearbox to engine, carry out operations 13 to 16, section 3A03.
  72. Carry out operations 17 and 18, section 3A03.
- 3100 series tractors**
73. Connect, gearbox to engine, carry out operations 15 to 23, section 3A04.
- 3000/3100 series tractors**
74. Connect the tractor between the gearbox and the rear axle, section 3B02.

### Version without shimming of layshaft

75. Adjust reverse shuttle selector, carry out operations 21 to 23, section 5R01.
  76. Refit the selector cover, carry our operations 33 to 43, section 5X01.
- 3000 series tractors**
77. Connect the tractor between the engine and the gearbox, section 3A03.
- 3100 series tractors**
78. Connect the tractor between the engine and the gearbox, section 3A04.
- 3000/3100 series tractors**
79. Top up the oil in the rear axle housing. Bleed the clutch circuit, section 5Q01, paragraph H.
  80. Road test all the controls.
  81. Check for leaks at the selector cover seal mating surface.

## F. Service tool

- Lifting bracket, No 3376889 M1





## 5S01 Mainshaft

### CONTENTS

-	<b>General</b>	_____	2
A.	<b>Preliminary operations</b>	_____	2
B.	<b>Disassembling and reassembling the mainshaft</b>	_____	4
C.	<b>Final operations</b>	_____	6
D.	<b>Service tools</b>	_____	7



5S01.2

## 3000 / 3100 SERIES TRACTORS

**Gearbox - Dynashift****General**

The mainshaft (69) is fitted on the two taper roller bearings (1) (2) and (16) (17) which are supported by the two lower bearings of the main gearbox. The front end houses the input gear (67).

Between the two lower bearings, it supports the 1st (7) and 2nd (14) driving gears which run free and the 1st and 2nd gear synchromesh assembly (11) whose hub is splined onto it.

At the rear end, it supports the 3rd and 4th gear synchromesh assembly (23).

The bore in the rear end carries a needle-roller bearing which supports the front end of the output shaft. The moving parts are lubricated by a central oilway and radially-drilled holes. The taper roller bearings are preloaded by means of a shim (4) and shim adjusters (3) located behind the bearing cup (2).

**Service tools**

See part D.

**A. Preliminary operations**

The gearbox must be removed in order to dismantle the mainshaft.

**3000 - 3100 tractors**

1. Split the tractor between the gearbox and the rear axle, as per Section 3 B02.

**3000 tractor**

2. Separate the gearbox from the engine, as per Section 3 A03.


Support the gearbox with a sling and carry out procedures 9 and 11 to 12. Remove the power take-off shaft.

Remove the grommets and the clutch slave cylinder pipes at the front end of the gearbox.

**3100 tractor**

3. Separate the gearbox from the engine. Support the gearbox with a sling and carry out procedures 3, 4 and 12 to 14 (as per Section 3 A04). Remove the PTO shaft.

Remove the grommets and the clutch slave cylinder pipes at the front end of the gearbox.





# Gearbox - Dynashift

5S01.3




Fig. 2



5S01.4

## 3000 / 3100 SERIES TRACTORS



# Gearbox - Dynashift

### 3000 - 3100 tractors

4. Remove the selector cover. Carry out procedures 11 and 12, in Section 5 X01.  
Remove the bolts (1) (Fig. 5) as per Section 5 X01.
5. Remove the guide rail and the forks. Carry out the procedures in part C, Section 5 V01.
6. Remove the input gearbox assembly. Carry out procedures 5 to 9, in Section 5 R01.
7. Remove the layshaft. Carry out procedure 8, in Section 5 T01.
8. Remove the output shaft. Carry out procedures 11 to 23, in Section 5 V01.




Fig. 3

## B. Disassembling and reassembling the mainshaft

### Disassembly

9. Remove the circlip (26).
10. Remove the 3rd and 4th gear synchromesh (23). Mark the direction of fitting.
11. Remove the synchromesh ring (21).
12. Remove the synchromesh cone (20) and the gear (18).  
**Note: Keep the synchromesh ring and cone as a pair for possible re-use.**
13. Position the retaining tool MF 458 (Fig. 3) and the locally manufactured holding sleeve for the mainshaft (69) (Fig. 4). (See part D).
14. Remove the oil feed pipe (71) and spring (72).
15. Unlock the nut (68) and loosen it using socket 3376805 M1 (Fig. 5).
16. Remove the input gear (67) and cone (1).
17. Remove the washer (6).
18. Remove tool MF 458 and the sleeve (Fig. 3 and 4).
19. Withdraw the shaft rearwards from the housing, holding the 1st and 2nd gear train in place.
20. From inside the housing and in the following order, remove: the 2nd gear (14) with bush (8), cone (13), 2nd gear synchromesh ring (12), 1st and 2nd synchromesh (11), cone (9), 1st gear synchromesh ring (10) and the 1st gear (7).
21. Withdraw the cups (16) and (2).  
**Note: Keep the cups and cones in pairs for possible re-use.**




Fig. 4




Fig. 5






## Gearbox - Dynashift

22. Remove the adjusting shims [3], the shim /4\ and circlips (15) and (5).  
**Note: Measure the thickness of the adjusting shims for use on the mainshaft during reassembly operations.**
23. Remove the cone (17) and retaining ring (70).

### Reassembly

24. Clean the housing and the mating faces.
25. Using a jet of compressed air, check that all the oilways in the gearbox and the shaft are free of obstructions. Clean and check the parts, and replace any that are faulty.
26. Lubricate the cones, the cups, the bearing bores and the bush.
27. Using a press, fit the bearing cone (17) onto the shaft (69).
28. Fit the retaining ring (70). Fit the circlips (5) and (15).
29. Position the shim /4\ against circlip (5) (Fig. 6).
30. Reduce the thickness of the shims [3] whose measurements were noted during disassembly by approximately 0.3 mm so as to obtain an end play of between 0.10 and 0.15 maximum so as to obtain an exact fit.
31. Install the shims [3] and the cups (2) and (16).
32. In the housing and in the following order, assemble the 1st gear (7), cone (9), the 1st gear synchromesh ring (10), the 1st and 2nd speed synchromesh (11), the 2nd gear synchromesh ring (12), cone (13) and the 2nd gear (14) with bush (8).
33. Insert the shaft through the rear of the housing, while supporting the synchromesh gear assembly (Fig. 7).  
**Note: Check that the bush (8) is correctly positioned in the gear (14).**
34. Fit the retaining tool MF 458 and the locally made holding sleeve (Fig. 3 and 4).
35. Fit the washer (6).
36. Fit the cone (1) onto the gear (67).
37. Fit the gear (67) onto the shaft (69).
38. Fit the nut (68) using the special socket 3376805 M1. Tighten to a torque of 80 - 100 Nm (Fig. 8).
39. Shim the shaft. Remove tool MF 458 and the sleeve (Fig. 3 and 4).





5S01.6

## 3000 / 3100 SERIES TRACTORS



## Gearbox - Dynashift

40. Position the pointer of a dial gauge at the end of the shaft (Fig. 9).
41. From the front of the housing, pull on the shaft and turn it 1st to the right and then to the left, so that the cones are properly seated in the cups.
42. Set the dial gauge to zero.
43. Repeat procedure 41, while pushing on the shaft.
44. According to the play measured, select the shim thickness required to obtain a preload of:

**P1 = 0.14 to 0.20**

45. Fit the retaining tool MF 458 and the locally manufactured holding sleeve (Fig. 3 and 4).
46. Unlock nut (68). Remove the gear (67).
47. Take out the cup (2).
48. Fit the adjusting shims [3] selected during procedure 44.

**Note: The shim /4\ must be positioned on the same side as the circlip (5) (Fig. 6).**

49. Reinstall the cup and the gear.
50. Degrease the thread on the shaft with a solvent.
51. Lightly coat the nut (68) with Loctite 270 and then tighten to a torque of 80 - 100 Nm.
52. Lock the nut, bending the collar into the groove with a suitable drift punch.
53. Insert the spring (72) and the oil feed pipe (71) into the shaft.
54. Remove tool MF 458 and the holding sleeve.
55. Fit the gear (18) and the synchromesh cone (20), as well as the ring (21) and the 3rd and 4th synchromesh (23).
56. Fit the circlip (26).  
**Note: Check that the synchromesh is facing the right way.**
57. Check the following by hand:
  - a) the end play on gears,
  - b) the rotation of the shaft and gear train.
58. Check that the 1st and 2nd gear synchromesh functions correctly.

### C. Final operations

59. Refit and shim the output shaft. Carry out procedures 25 to 63, in Section 5 V01.
60. Refit the layshaft. Carry out procedure 23, in Section 5 T01.
61. Refit the input gearbox assembly. Carry out procedures 10 to 16, in Section 5 R01.
62. Shim the layshaft. Carry out procedures 25 to 35, in Section 5 T01.
63. Reassemble the forks and the guide rail. Repeat the operations in part F, Section 5 V01.




Fig. 9

64. Adjust the reversing selector. Carry out procedures 21 to 23, in Section 5 R01.
65. Refit the selector cover. Carry out procedures 33 to 38 in Section 5 X01.

**Note: Do not forget to install the bolt (1) on the housing (see Fig. 5, Section 5 X01).**

#### 3000 tractors

66. Recouple the gearbox with the engine. Carry out operations 13 to 16, Section 3 A03.
67. Carry out procedures 17 and 18 (after supporting the gearbox in a sling, as per Section 3 A03).

#### 3100 tractors

68. Recouple the gearbox with the engine. Carry out procedures 15 to 23 (after supporting the gearbox in a sling) as per Section 3 A04.

#### 3000 - 3100 tractors



69. Reconnect the gearbox and the rear axle (Section 3 B02).
70. Check the operation of the electrical circuits.
71. Carry out a road test on the controls.
72. Check the unions and mating faces for leaks (selector cover, and gearbox on rear axle).




# Gearbox - Dynashift

## D. Service tools

### 1. Tools available from the MF network



### 2. Locally manufactured tool







5 T01 Layshaft

CONTENTS

-	<b>General</b> _____	2
A.	<b>Preliminary operations</b> _____	3
B.	<b>Disassembly</b> _____	3
C.	<b>Reassembly</b> _____	3
D.	<b>Refitting the input gearbox and shimming the layshaft</b> ____	4
E.	<b>Service tool</b> _____	5



5T01.2




# Gearbox - Dynashift

## General

The layshaft and its gears make up the upper drive line of the gearbox. The shaft (54) carries the driven gears for 1st speed (60), 2nd speed (59) 3rd speed (55) and 4th speed (56). The rear set of teeth is constantly meshed with the Tortoise (Lo) gear.

The front of the shaft is carried by the taper roller bearing (63) (64) in the rear of the input gearbox and by a bearing (52) (53) mounted in the bearing at the rear of the gearbox.

The gears (56) and (60) are held in position by spacer (57). End play on the gears is obtained by mounting shims (58) between the gears (59) and (60).





## Gearbox - Dynashift

5T01.3

### A. Preliminary operations

To allow the bearings to be correctly shimmed when replacing the laysaft the gearbox must be removed.

#### 3000-3100 tractors

1. Split the tractor between the gearbox and the rear axle (see Section 3 B02).

#### 3000 tractors

2. Separate the gearbox from the engine. Carry out procedures 9 and 11 to 12, in Section 3 A03 (having suspended the gearbox in slings). Remove the PTO shaft.
3. Remove the pipes and the clutch slave cylinder.

#### 3100 tractors

4. Separate the gearbox from the engine. Carry out procedures 3 to 4 and 12 to 14, in Section 3 A04 (having suspended the gearbox in slings). Remove the PTO shaft.
5. Remove the pipes and the clutch slave cylinders.

#### 3000-3100 tractors


6. Remove the selector cover. Carry out procedures 11 and 12, in Section 5 X01).
7. Remove the input gearbox. Carry out procedures 5 to 9, in Section 5 R01).

### B. Disassembly

8. Remove the deflector (50), the shims (51) and the cup (52). Withdraw the shaft assembly (Fig. 3).
9. Extract the bearing cones (53) and (63).  
**Note: Keep the cones and cups in pairs if they are to be re-used.**
10. Remove the circlip (61).
11. Remove the 2nd gear (59), the shims (58), the 1st gear (60) and the spacer (57).
12. Remove the 4th gear (56) and the 3rd gear (55).
13. Drive out the needle-roller bearing (62) and discard it.

### C. Reassembly

14. Clean and check the parts, and replace any that are defective.
15. Fit the needle-roller bearing (62) fully home on the shoulder of the shaft (54), using a press.  
**Note: After this fitting operation, check that the needle-rollers turn normally in the cage.**
16. Reinstall the 3rd gear (55) and the 4th gear (56).
17. Slide the spacer (57) into position. Install the 1st gear (60) and the 2nd gear (59).
18. Fit the circlip (61).



19. Using a set of shims, measure the space between the 1st gear (60) and the 2nd gear (59). According to the measurement obtained, use the shim thickness required to obtain a play of:  
**J1 = 0 to 0.25 mm**
20. Remove the circlip (61) and the gear (59).
21. Slide the previously selected shims onto the shaft. Fit the pinion and the circlip.
22. Use the press and a suitable fixture to fit the cones (63) and (53).
23. Reinstall the assembled shaft and the cup (52).

**Note : When replacing the gears, it is not necessary to shim the bearings again. Disassembly of laysaft can be made without removing the gearbox according to the following method.**

#### Disassembly

- Remove the 1st, 2nd plunger and position the lock so as to free the fork.
- Refer to section 5 N01. Remove lubrication tube (71) and the spring. Loosen nut (68).
- In order to facilitate the disengagement of 1st gear (60) to remove the complete shaft, take out the input gear (67) to the front with its bearing, the 1st, 2nd gears (7) - (14) and the synchromesh.
- Remove the gears (see § B).

#### Reassembly

- Reverse the disassembly operations. Replace nut (68) as described section 5 S02 § B, op. 50 to 53.
- Tighten the plunger plug to a torque of 50 - 70 Nm.
- Check the axial play of the 1st - 2nd gears and the synchromesh operation.



5T01.4

## Gearbox - Dynashift

### D. Removing the input gearbox and shimming the layshaft

24. Remove the input gearbox. Carry out procedures 10 to 16, in Section 5 R01.
25. Shim the layshaft (see Fig. 4) to obtain a play of:  
**J2 = 0.04 to 0.12 mm** (Fig. 5)
26. Install the locally manufactured tool (see Section E) in the layshaft (Fig. 6).
27. Compress the spring moderately by tightening the nut on the tool in order to bed the cones correctly in the cups.
28. Rotate the shaft through a few turns.
29. Using a depth gauge, measure the dimension **X** between face **A** of the cup (52) and face **B** on the housing (see Fig. 5).
30. Measure the thickness **Y** of the deflector (50).
31. Calculate the difference between **X** and **Y**.
32. Determine the shim thickness required to obtain a play of between 0.04 and 0.12.
33. Remove the compression tool.
34. Position the shims [51] selected in procedure 32.
35. Fit the deflector in the housing.
36. Adjust the reversing selector. Carry out procedures 21 to 23, in Section 5 R01.  
Refit the selector cover. Carry out procedures 33 to 38 in Section 5 X01.  
**Note: Do not forget to fit the bolt (1) on the housing (Fig. 5), Section 5 X01.**

#### 3000 tractors

37. Recouple the gearbox with the engine. Carry out procedures 13 to 16, Section 3 A03.
38. Carry out procedures 17 and 18, in Section 3 A03.

#### 3100 tractors

39. Recouple the gearbox with the engine. Carry out procedures 15 to 23, in Section 3 A04.

#### 3000 - 3100 tractors

40. Recouple the tractor between the gearbox and the rear axle (Section 3 B02).
41. Check :
  - the systems for leaks
  - the operation of the electrical circuits.
42. Carry out a road test on all the controls.
43. Check the unions and mating faces for leaks (selection cover, and gearbox on rear axle).




Fig. 4




Fig. 5



# Gearbox - Dynashift

5T01.5




Fig. 6

## E. Service tool

Layshaft holding tool, to be manufactured locally.




Fig. 7



## **Gearbox - Dynashift**

### *5 V01 Output shaft*

#### CONTENTS

-	<b>General</b>	_____	<b>2</b>
A.	<b>Preliminary operations</b>	_____	<b>4</b>
B.	<b>Removing the selector cover</b>	_____	<b>4</b>
C.	<b>Disassembling the guide rails and selector forks</b>	_____	<b>4</b>
D.	<b>Disassembling the output shaft</b>	_____	<b>5</b>
E.	<b>Reassembling and shimming the output shaft</b>	_____	<b>6</b>
F.	<b>Reassembling the guide rail and selector forks</b>	_____	<b>9</b>
G.	<b>Refitting the selector cover</b>	_____	<b>11</b>
H.	<b>Final operations</b>	_____	<b>11</b>
I.	<b>Service tools</b>	_____	<b>12</b>



5V01.2



# Gearbox - Dynashift

## General

The output shaft transmits the drive provided by the various gear ratios to the rear axle transfer shaft. It is mounted on the lower transmission drive line at the rear of the gearbox.

At the front end, it is supported by a needle-roller bearing located in the bore in the mainshaft and, at the rear end, in two taper bearings fitted with their tapers in opposition.

The shaft (44) carries:

- the driving gear (29) which is mounted to rotate freely on combination bearings (28) and (30),
- the gear (36) and bush (35) assembly which are mounted to rotate freely,
- the Hare/Tortoise (Hi/Lo) coupler (31) and its hub which are splined to rotate together.

To ensure that the assembly will operate correctly under the forces applied to the transmission, several settings have to be made with shims:

- **Setting J3:** with shim or shims [47], this setting allows the clearance to be taken up between the cones (39) and (40) and their respective cups.
- **Setting J4:** shim or shims [38] placed between the shoulder on the shaft (44) and the cone (39) allow(s) end play on the gear (29).
- **Setting J5:** shim or shims [42] placed between the cone (40) and packing shim [43] take up the end play of cones (39) and (40) on the shaft (44).




Fig.



# Gearbox - Dynashift

Exploded view




Fig. 2





5V01.4




## Gearbox - Dynashift

### A. Preliminary operations

1. Split the tractor between the gearbox and the rear axle (Section 3 B02).

### B. Removing the selector cover



2. Carry out procedures 11 and 12, in Section 5 X01.
3. If necessary, remove the bolt (1) (see Fig. 13).



### C. Removing the guide rail and forks

**Note:** Gearbox equipped with creeper gears. Remove pin (1) locknut (2), adjustable locking screw (3), and fork (4) with sleeve (5) (see Fig. 3).

4. Remove the plugs (1), springs (2) and locking plungers (3) (See Fig. 5).
5. Slacken off the castellated nut (21) using spanner 3615334 M1 (see Fig. 4).
6. Engage 4th gear.





## Gearbox - Dynashift

7. Free the cone (24) on the guide rail (7) using a bronze drift (see Fig. 6).
8. Remove the set screw (8).
9. Remove the bearing (15), the guide rail (7) from the rear, the forks (5) and (6) and the locking assembly (25).
10. Dismantle the castellating nut (21), locking device (22), bearing (23) and cone (24).  
Remove the bolts (19), piston (13), the Hare/Tortoise (Hi-Lo) fork (20), the bolt and washer assembly (17) slider (18) and cylinder (10).  
**Note: Discard the seals (11), (12) and (14).**




Fig. 6

### D . Removing the output shaft

**Note: Remove the creeper gearbox if the tractor is fitted with one.**

11. Move the three screws (41).
12. Remove the locking ring (46).
13. Remove the bearing cup (48).  
**Note : Keep the cones and cups in pairs if they are to be re-used.**
14. Remove the circlip (45).
15. Remove the packing shim (43) and the adjusting shims (42).
16. Remove the bearing cone (40).  
**Note : If shimming was required between the cones, remove the shim or shims (47).**
17. Remove the cone (39).
18. Remove the adjusting shims (38).
19. Pull the shaft (44) towards the rear.
20. Remove the snap ring (34) using tool MF 460 and discard it (see Fig. 7).
21. Remove the shaft.
22. Through the opening in the selector cover, take out the synchromesh (31), the synchromesh rings (33) and (74), the gear (29) with cones (75) and (76), the ring (25), the two thrust washers (27) and (32) and the Tortoise gear (36).  
**Note: Keep the synchromesh rings (25) and (74) paired with the cones (75) and (76), and ring (33) with cone (73).**
23. Remove the cap (37) and circlip (49).
24. Remove circlip (19), washer (22) and the needle-roller bearing (24).




Fig. 7



5V01.6

**Gearbox - Dynashift****E. Reassembling and shimming the output shaft**

25. Check and clean the parts, and replace any that are faulty.
26. Fit the circlip (49) and cup (37).
27. Reinstall the needle-roller bearing (24), washer (22) and circlip (19) on the shaft (44). Engage the shaft in the housing without gears.
28. Slide the cones (39) and (40) onto the shaft.

**Setting J3**

29. The purpose of this operation is to prepare for setting **J3** (Fig. 8). Hold the cones (39) and (40) fully home against the shoulder of shaft (44) by pressing on them by hand.

Fill the gap **Y** between the rear of the cone (40) and the groove for circlip (45) with shims (42) and the packing shim (43). Choose a new circlip that provides a slightly tight fit in the groove (Fig. 10).

30. Perform the setting (Fig. 9) with shims in order to obtain :

**J3 = -0.05 to +0.05.**

This shimming operation consists in taking up the clearance between the cones (39) and (40) and the cups (37) and (48), while complying with the setting tolerance specified above.

31. Fit the circlip (45).

**Note : Position the packing shim on the circlip side.**

32. Fit the cup (48) and the locking ring (46).
33. Tighten the bolts (41) to a torque of 27 - 32 Nm.




Fig.




Fig.




Fig.



## Gearbox - Dynashift

34. Position a dial gauge on the end of the shaft (44) (Fig. 11).

**Note:** In the case of gearboxes equipped with creeper gears, use the gearbox locking ring (see Fig. 12) in place of the locking ring. Tighten the bolt to a torque of 34 - 52 Nm.

35. Push on the shaft while turning it alternately clockwise and then anticlockwise to seat the cones correctly in the cups.
36. Reset the dial gauge to zero.
37. Repeat procedure 35 while pulling on the shaft.
38. If the end play measured is greater than 0.05 mm select a thickness of shims X [47] to obtain :  
**J3 = -0.05 to +0.05**  
**Important:** The shim or shims X [47] selected for J3 must be installed between the cones for the following setting operations.




Fig. 11

### Setting J4

39. Remove the circlip (45).
40. Remove the packing shim /43\ and the adjusting shims [42].
41. Measure the thickness Y of the set of shims [42] and /43\ (This measurement will be useful for setting J5.)
42. Remove the bolts (41) and the locking ring (46).
43. Remove the cup (48), cones (40) and (39), and the shaft (44).
44. Fit the following in the housing: the Tortoise gear (36), the synchromesh and its rings (33) and (74), the thrust washer (32), the gear (29) with its needle-roller bearings (30) and (28) and its synchromesh cones (75) and (76), thrust washer (27) and synchromesh ring (25).
- Note:** If bush (35) shows signs of wear, replace the complete gear assembly. (The bush is reamed after fitting). If the combination bearings (30) and (28) are worn, replace the complete gear assembly. (Bearings are fitted in the factory).
45. Insert the output shaft (44) while holding the gear assembly in position (see Fig. 13).
46. Pull the shaft slightly back in order to expose the groove for the snap ring (34).




Fig. 12




Fig. 13



5V01.8

3000 / 3100 SERIES TRACTORS






## Gearbox - Dynashift

47. Fit the snap ring (34) with tool MF 459 (Fig. 14).  
**Note: Check that the snap ring is correctly installed.**
48. Slide the following components onto the shaft: cone (39), shim or shims X [47] selected in procedure 38, cone (40) and cup (48).
49. Fit the locking ring (46). Tighten the bolts (41) to a torque of 27 - 32 Nm.
50. Perform the setting (Fig. 15) to obtain a play of :  
 **$J_4 = 0.20$  to  $0.40$**   
 This setting operation consists in providing an end play on the gear (29).
51. Carry out procedures 34 to 37.
52. According to the measurement read on the dial gauge, determine the thickness of shims Z [38] to obtain play  $J_4$ .
53. Remove the bolts (41) and the locking ring (46).
54. Remove the cup (48).
55. Withdraw the cones (40) and (39), and the shim or shims X [47].
56. Slide the following components onto the shaft: the required thickness of shims Z [38], cone (39), shim or shims X [47], and cone (40).

### Setting J5

57. Perform the setting (Fig. 16) to obtain :  
 **$J_5 = \text{no end play}$**   
 This setting consists in taking up the end play of cones (40) and (39) on the shaft (44).
58. Use the thickness of shims Y [42] /43\, measured in procedure 41, to deduce the thickness of shims Z [38] and X [47] to obtain :  $J_5 = Y - (Z + X)$ .
59. Carry out procedures 32 and 33.
60. Slide the thickness of shims selected in procedure 58 onto the shaft.
61. Fit the circlip (45).  
**Note: Position the packing shim /43\ on the circlip side.**  
 The circlip must be a slightly tight fit in its groove. Check that it is correctly positioned.  
**Note: Refit the creeper gearbox (if fitted).**
62. Check by hand that the shaft and its gears turn freely.
63. Check that the 3rd and 4th gear and Hare/Tortoise synchromeshes operated normally.





## Gearbox - Dynashift

### F: Reassembling the guide rail and forks (Fig. 17)

64. Check that the ports in the Hare/Tortoise cylinder (10) are not blocked.
65. Fit the cylinder (10) equipped with O-ring (11) in the housing.
66. Install the Hare/Tortoise fork (20) in the synchro-mesh.
67. Fit seals (12) and (14) onto the piston (13) and then insert it into the bore in the cylinder.  
**Note : Line up the locations for the adjusting screws with the tapped holes in the fork. Immobilise the piston with a screw (19).**
68. Clean and then assemble the mechanical locking device (22), taper bearing (23), cone (24) and castellated nut (21).
69. Fit the 3rd and 4th speed fork (6) and the 1st and 2nd speed fork (5), and the locking assembly (25).
70. Insert the guide rail (7) from the rear of the housing and slide it through the piston, the locking assembly and the forks.

71. Fit the bearing (15) and tighten the bolts (16) to a torque of 27 - 32 Nm.
72. Clean the set screw (8) with a solvent. Coat it with Loctite 542 and tighten to a torque of 28 - 43 Nm.
73. Fit the locking plungers (3) and springs (2), and tighten the plugs (1) to a torque of 50 - 70 Nm.  
**Note : Gearboxes equipped with creeper gears (Fig. 3).**
  - Fit sleeve (5), fork (4) and pin (1).
  - Position the fork so that locking screw (3) is over the flat on the guide rail (6) (between the two locking recesses).
  - Tighten the screw fully in so that the ball is compressed.
  - Loosen the screw by one quarter turn.
  - Apply Loctite 241 to nut (2) after cleaning it with solvent.
  - Tighten to a torque of 15 - 20 Nm.
  - Check that the fork locks correctly.




Fig. 17



5V01.10

**Gearbox - Dynashift****74. Adjusting the Hare/Tortoise fork**

Principle: The fork (20) is positioned by means of the difference in the spacing between the tapped holes **Y** and the spacing **Z** of the spot-facing marks in the piston (13). The fork can be adjusted to move to different positions by acting on either the front or rear screw, depending on the adjustment required (Fig. 18). Set the control piston (13) and synchromesh (31) to the high range (Hare).

76. Hold the synchromesh against the high range gear (29). (See Fig. 19).

77. Adjust the position of the fork (20) by acting on the two adjusting screws (19) after cleaning them with solvent and coating them with Loctite 221, in order to obtain a play of  $J1 = 0.3$  mm between the rear face of the pad and the synchromesh slide rod (Figures 19 and 20).

**Note: Perform the setting using a locally manufactured tool.**

78. Set the control piston (13) and the synchromesh to the low range (Tortoise).

79. Check that there is a play of  $J2 = 0.3$  min. (value determined by setting  $J1$ ) between the pad and the synchromesh slide rod, with the slide rod resting against the low range gear (36) (Fig. 21). Tighten the screws to a torque of 35 Nm without modifying the setting.

**Note: In the Tortoise position, play  $J1$  must be increased if face X of the pad on fork (20) is bearing against the synchromesh slide rod (Fig. 21).**

80. Set the fork to the Tortoise position.

81. Slightly loosen the castellated nut (21). Apply a moderate coat of Loctite 270 on the thread of cone (24).

82. Place the forks in the neutral position.




Fig. 19




Fig. 20




Fig. 20





Fig. 21



## Gearbox - Dynashift

83. Adjust the plays J3 and J4 (min. = 0.3 mm) evenly so that the mechanical lock (22) operates freely (Figures 22 and 23).
84. Tighten the castellated nut (21) to a torque of 50 Nm using a spanner 3615334 M1 and a spring scale (Fig. 23).
85. Apply Loctite 648 on the tightening face of the slider (18) and Loctite 241 on bolt (17). Fit the washer and the bolt.
86. Adjust plays J5 and J6 (min. = 0.3 mm) evenly between the slider and the lock in the Hare and Tortoise positions (Figures 19 to 21 and 24).
87. Tighten the bolt to a torque 36 - 46 Nm.
88. Check the operation of the Hare/Tortoise range and the lock.
89. Check the changing of the gears.





### G. Refitting the selector cover

90. Fit the bolt (1) (Fig. 13), if fitted, and carry out procedures 33 to 38, in Section 5 X01.  
**Note:** If the setting of the sleeves on the levers is required, repeat part E, Section 5 X01.

### H. Final operations

91. Recouple the tractor between the gearbox and the rear axle, as per Section 3 B02.
92. Check :
  - the systems for leaks,
  - the operation of the electrical circuits.
93. Carry out a road test on the controls.
94. Check for leaks on the mating faces of the selector cover and of the gearbox on the rear axle.







5V01.12

3000 / 3100 SERIES TRACTORS




## Gearbox - Dynashift

### I. Service tools


#### a) Tools available from the MF network

Slotted nut wrench 3615334 M1



3376805 M1



Snap ring remover tool MF 460



MF 458

#### b) Tool to be manufactured locally

Snap ring replacer tool MF 459





5 X01 Selector cover

CONTENTS

-	<b>General</b> _____	<b>2</b>
-	<b>Operation</b> _____	<b>2</b>
A.	<b>Removal</b> _____	<b>5</b>
B.	<b>Disassembly</b> _____	<b>5</b>
C.	<b>Reassembly</b> _____	<b>5</b>
D.	<b>Refitting</b> _____	<b>6</b>
E.	<b>Adjustment of sleeves on levers</b> _____	<b>6</b>



5X01.2

## Gearbox - Dynashift

### General

The selector cover fitted on the right-hand side of the gearbox housing has two separate levers each of which performs one of two different functions :

- Front lever : This lever controls the reverse shuttle.
- Rear lever : This lever selects the four basic speeds and the two Hare/Tortoise (Hi-Lo) ratios.

### Operation

#### Reversing lever

The reverse shuttle is operated when the lever (23) is pushed forwards (reverse) or backwards (forward motion).

When the lever (23) is moved forwards or backwards, it causes the shaft (53) which is secured to the U-arm (54) to turn. The index on the U-arm moves the selector (S).

#### Gear lever

The arrangement of the 1st and 2nd speed gears is the reverse of the arrangement for the standard 8-speed gearbox (4 x 2).

### Operation

#### Selecting 1st/2nd gears

When the lever (12) is pushed, the arm (36) is engaged in the 1st and 2nd speed fork.

moving lock (V) which prevents any movement of the 3rd and 4th speed fork.

1st gear is then obtained by moving the lever forwards and 2nd is obtained by moving it back.

#### Selecting 3rd/4th gears

In this configuration, the gear lever (12) is in the intermediate position. The arm (36), which is secured to the lever (12), is engaged in the 3rd and 4th speed fork and lock (V) prevents any movement of the 1st and 2nd speed fork.

3rd gear is then obtained by moving the lever forwards and 4th is obtained by moving it back.

#### Hare/Tortoise function

The Hare/Tortoise position (Hi-Lo) is obtained in the neutral position by pulling the lever (12). The arm (36) moves the lock (V) which applies pressure on switch (1) controlling the Hare/Tortoise solenoid valve via the Autotronic system.

For the operation of the hydraulic system, see Section 5 K01, page 5.

### List of parts

(1) Switch	(20) Pin	(40) Cup
(2) Seal	(21) Ball	(41) Cup
(3) Temperature probe	(22) Pin	(42) Spring
(4) Bolt	(23) Reversing lever	(43) Dowel pin
(5) Bolt	(24) Lug	(44) Bolt
(6) Support bracket	(25) Cotter pin	(45) Bolt
(7) Pin	(26) Washer	(46) Bracket
(8) Ball	(27) Ball	(47) Bolt
(9) Dust cover	(28) Pin	(48) Dowel pin
(10) Link	(29) Bolt	(49) Dust cover
(11) Pin	(30) Bolt	(50) Seal
(12) Gear lever	(31) Support bracket	(51) Dust cover
(13) Pin	(32) Link	(52) Set screw
(14) Ball	(33) Bolt	(53) Shaft
(15) Set screw	(34) Bolt	(54) Arm
(16) Dust cover	(35) Rack	(55) Set screw
(17) Washer	(36) Arm	(56) Cover
(18) Cotter pin	(37) Seal	(57) Nut
(19) Elbow union	(38) Cup	
	(39) Spring	




3000 / 3100 SERIES TRACTORS

# Gearbox - Dynashift



5X01.3





5X01.4

3000 / 3100 SERIES TRACTORS



# Gearbox - Dynashift

Exploded view




Fig.



## Gearbox - Dynashift

### A . Removal

1. Immobilise the tractor. Fit wedging block under the left-hand rear wheel.
2. Apply the handbrake.
3. Fit chock between the frame and the front axle.
4. Drain the oil from the gearbox only.
5. Raise the rear right-hand side of the tractor with a trolley jack.
6. Install an axle stand and remove the wheel.
7. Remove the footstep (if necessary).
8. Take out the cotter pins (18) and (25), washers (17) and (26). Remove pins (11) and (20). Lift the dust covers (49) (51) and (9) (16). Remove the reversing lever (23) and gear lever (12) and mark their positions (Fig. 3).
9. Disconnect the wiring harnesses from the switch (1) and temperature probe (3) (Fig. 3).
10. Disconnect the control linkage on gearboxes equipped with creeper gears.
11. Remove the nut (57) and bolts (33) and mark the position of the earth wire lug (24). On creeper-type gearboxes, remove the control cable support bracket (1) (Fig. 4).
12. Remove the cover (56).




Fig. 3




Fig. 4

### B . Removal

13. Install the cover in a vice.
14. Take out bolts (29) (30) and (4) (5). remove the supports (6) and (31).
15. Remove set screws (15) and (52). Remove the links (10) and (32).
16. Remove bolt (55). Withdraw shaft (53) and remove the reversing control U-arm (54).
17. Remove bolts (44) (45) and (47).
18. Remove the bracket (46).
19. Extract the dowel pins (43) (48) from the cover.
20. Remove bolt (34). Remove the gear control assembly.
21. Remove the cups (38) and (40), and spring (39).
22. Separate the arm (36) from rack (35). Remove the cup (41) and spring (42) from the arm (36).
23. Remove the Hare/Tortoise switch (1), seal (2), union (19) and temperature probe (3).
24. Remove seals /37\ and /50\.

### C . Reassembly

25. Clean the mating face on the cover (56). Apply Loctite 542 on the outer circumference of seals /37\ and /50\ and fit them fully home in the shoulder of the cover.
26. Fit the dowel pins (43) and (58) in the cover. Install the bracket (46). Reinstall the bolts (44) (45) and (47), and tighten them to a torque of 25 - 35 Nm. Refit the U-arm (54) and refit the shaft (53) from the inside of the cover. Be careful not to damage the lip of seal /50\.
- Install the set screw (55) and tighten it to a torque of 28 - 43 Nm.
27. Refit the cup (41) and spring (42) on arm (36). Assemble the arm with the rack (35).



5X01.6

## Gearbox - Dynashift

28. Reinstall the spring (39) and cups (38) and (40).
29. Refit the gear control assembly and bolt (34) after coating it with Loctite 270. Tighten to a torque of 25 - 35 Nm.  
**Note : Be careful not to damage the lip of seal /37/.**
30. Reinstall the union (19), the temperature probe (3) fitted with its seal, the Hare/Tortoise switch (1) and its seal (2).
31. Refit links (10) and (32). Fit the set screws (15) and (52).
32. Refit the support brackets (6) and (31). Fit bolts (29) (30) and (4) (5).

### D . Refitting

33. Clean the mating face on the cover (56).
34. Set the reversing selector, and the 1st, 2nd, 3rd and 4th gear forks to the neutral position. Move the lock V towards the opening of the selector cover (see Fig. 5).
35. Apply a sealing compound on the mating face of the gearbox housing.
36. Position the gear lever pointing towards the right. Set the reversing lever to the neutral position.
37. Position the cover on the gearbox, making sure that the levers are correctly positioned in the selector mechanisms.
38. Fit the earth wire lug (24), bolts (33) and nut (57). Tighten to a torque of 50 - 70 Nm.  
**Note : For gearboxes equipped with creeper gears, fit the cable support (1) (Fig. 4).**
39. Connect up the control linkage on gearboxes equipped with creeper gears.
40. Reconnect the wiring harnesses to the Hare/Tortoise switch (1) and on the temperature probe (3).
41. Refit the reversing lever (23) and gear lever (12).
42. Reinstall pins (11) and (20). Reinstall the washers and pins. Position the dust covers (Fig. 3).
43. Refit the footstep (if it was removed).
44. Reinstall the wheel.
45. Remove the axle stand and the trolley jack. Tighten the wheel nuts to a torque of 400 - 450 Nm.
46. Carry out procedures 1 to 4 in reverse order.
47. Carry out a road test on the controls for :
  - the reverse shuttle, gears, Hare/Tortoise range, creeper gears (if fitted) and Dynashift speeds A, B, C, D.
  - Check the mating face on the cover and hydraulic unions for leaks.

### E : Adjusting the sleeves on levers

**Note: If an adjustment or replacement is necessary, lightly coat the inside of each sleeve with "Anti-Seize" grease or equivalent.**

48. Set the reversing and gear levers to the neutral position.
49. Unlock nuts (1). Adjust the sleeves (2) so as to obtain a dimension X between the base of the sleeve and shoulder "E" on each lever (see Fig. 6). Tighten the nuts to a torque of 50 Nm and position the dust cover (3).  
X = 40 mm for all types  
= 70 mm on the gear lever only for 3125 as from serial number B064014.




Fig. 5




Fig. 6







***Rear axle - Description***

***6 A01 Description of rear axle***

CONTENTS

- General	2
A. Centre housing assembly	2



6A01.2

## 3000 / 3100 SERIES TRACTORS



### Rear axle - Description

#### General

The rear axle comprises four main housings :

- The centre housing which houses the differential, the power take-off gear in all variants and the 4-wheel drive transmission, the handbrake and main brake control unit. It also supports the two axle housings (trumpets), the lift cover and the side covers (see chapters 8 I01-02).
- The right and left trumpets fixed to each side of the centre housing, serving as a rear wheel drive axle case (see chapters 6C01-02).
- The lift cover fitted to the top of the centre housing supporting the lift arms which are attached to the lower links (see chapter 6B01).

#### Power take-off drive

The rotation of the shaft passing through the gearbox, proportional to the engine speed, is transmitted to the hydraulic clutch situated at the front of the centre housing (see 6G01).

In the engaged position drive is transmitted by a countershaft and a set of driving and driven gears to the 540 or 1000 rpm power take-off shaft. Speeds are selected by a system of interchangeable shafts (see 6 E01) or by coupler (see 6 E02).

A hydraulic braking device stops the rotation of the power take-off shaft in the disengaged position.

Two additional options are offered :

- (economy) 4 speed power take-off (see 6 D01).
- power take-off proportional to forward speed (GSPTO) (see 6 F01).

#### Handbrake assembly

A brake assembly comprising two plates and an expander mechanism is mounted on the bevel drive pinion (see 6I01).

#### A. Centre housing assembly

##### Differential

The bevel gear is driven from the gearbox output shaft through a connecting shaft with splined couplers. The helical bevel crownwheel and pinion set transmits the drive through a differential to the final reduction units. A differential lock system actuated by hydraulic pressure is incorporated into the casing (see 6J01).

The differential lock is controlled by the Autotronic (if fitted).

##### 4-wheel drive clutch

A gear splined to the drive bevel gear shaft drives the 4 WD clutch assembly.

Motion is then transmitted via Belleville washers to the clutch output shaft (see 7A01).

It is hydraulically actuated to disengage the 4 WD. There is therefore no possibility of accidental disengagement of 4 WD in the event of hydraulic failure.

##### Main brakes

Two pistons mounted laterally in two cavities in the centre housing act on two discs splined onto the output shafts. The brake pistons are activated hydraulically (see 6 K01).




3000 / 3100 SERIES TRACTORS



6A01.3

## Rear axle - Description

Centre housing assembly  
(longitudinal cross-section)






3000 / 3100 SERIES TRACTORS



6A01.4

## Rear axle - Description

Rear transmission assembly  
(cross section)





**Rear Axle - Lift cover**

6B01.1

**6 B01 Lift cover**

**CONTENTS**

- General	2
A. Removal	5
B. Disassembly	6
C. Reassembly	7
D. Refitting	9



6B01.2

## Rear Axle - Lift cover

### General

The lift cover is mounted on the upper face of the rear axle housing. The shaft (4) which has the two lift arms (5) and (11) splined to it, is supported by bushes (8).

Cam (9) on the lift shaft (4) provides the means for sensor (26) to monitor position of lift arms. This information is transmitted to the Electronic Linkage Control (ELC) system.

To ensure correct play between the lift arms and the cover, shims [12] are fitted on the left hand end of the shaft.

The rear face of the lift cover supports the auxiliary spool valves. The vehicle speed sensor (15) is screwed in the front of the cover. The cover also supports lever (21) for economy ( 4 speed) PTO, if fitted.

### Parts list


- |                           |                                   |
|---------------------------|-----------------------------------|
| (1) Washer                | (17) Cup plug (2-speed PTO)       |
| (2) Bolt                  | (18) Screw (4-speed PTO)          |
| (3) Retainer              | (19) Control finger (4-speed PTO) |
| (4) Lift shaft            | (20) O-ring (4-speed PTO)         |
| (5) Right-hand lift arm   | (21) Lever (4-speed PTO)          |
| (6) Nylon ring (2)        | (22) Screw (4-speed PTO)          |
| (7) O-ring (2)            | (23) Elbow connector              |
| (8) Bush (2)              | (24) Bolt                         |
| (9) Cam                   | (25) Nut                          |
| (10) Lift cover           | (26) Position sensor              |
| (11) Left-hand lift arm   | (27) Cup plug                     |
| [12] Shim(s)              | (28) Threaded plug                |
| (13) Bush                 | (29) Seal                         |
| (14) Set screw (2)        | (30) Threaded plug                |
| (15) Vehicle speed sensor | (31) Seal                         |
| (16) Nut                  |                                   |



3000/3100 SERIES TRACTORS

Rear Axle - Lift cover

6B01.3






6B01.4

3000/3100 SERIES TRACTORS



Rear Axle - Lift cover

Exploded diagram







## Rear Axle - Lift cover

### A. Removal

1. Remove the sheetmetal.
2. Remove the rear fastening screws to the cab (remove only the central and lower screws to the guard plates to gain access to the cab fastening screws).
3. Raise the cab.  
**Note: Place a block between the cab and the trumpets (Fig. 1).**
4. Disconnect (Fig. 2):
  - . the supply hose (1) to the spool valve
  - . the supply hose (3) to the lift valve
  - . the return hose (2).
5. Remove the bolts (4) for the spool valve support (5) (Fig. 2).
6. Remove the support swinging the assembly out of the way, without disconnecting the controls (1) (Fig. 3).
7. Disconnect (Fig. 4):
  - . the vehicle sensor wire assembly (1) (Autotronic, Datatronic)
  - . the position sensor wire assembly (2)
  - . the differential lock pipe (3)
  - . the cable (4) (4-speed PTO, if fitted)
  - . the cable (5) (shiftable PTO, if fitted).




Fig. 1




Fig. 2




Fig. 3




Fig. 4



6B01.6

## Rear Axle - Lift cover

8. Unscrew the pipe (1) at both ends and remove the support (2) for the trailer brake connector if fitted (Fig. 5).
9. Remove the upper pins from the rams and lift rods.
10. Remove the fastening bolts (24) for the cover (10).  
**Note: The p.t.o. control cable supports (depending on the version) are fixed by the bolts for the cover.**
11. Lift the cover and remove it.




Fig. 5

### B. Disassembly

12. Place the cover on a work bench.
  13. Remove the elbow connector (23).
  14. Unscrew the nut (16) and remove the vehicle speed sensor (15).
  15. Unscrew the nut (25) and remove the position sensor (26).
- For tractors equipped with economy 4-speed, carry out operations 16 to 19 (Fig. 6).**
16. Undo the Allen screw (22) in the lever (21).
  17. Undo the screw (18).
  18. Remove the control finger (19).
  19. Remove the O-ring (20).
  20. Flatten tabs locking the bolts (2) retaining the lift arms..
  21. Undo the screws.
  22. Remove the washers (1).
  23. Remove the shim(s) [12].
  24. Remove the lift arms (5) and (11).
  25. Remove the nylon rings (6) and the O-rings (7).
  26. Remove the set screws (14) in the cam (9).
  27. Withdraw the lift shaft (4) from the cover.
  28. Remove the cam (9).
  29. Withdraw the bushes (8) (Fig. 7).
  30. Remove the cup plug (17) (2-speed PTO).




Fig. 6




Fig. 7



## Rear Axle - Lift cover

### C. Reassembly

**Note: The bushes (13) are mounted with Loctite 648 at a distance of 40.50 mm from the face A (Fig. 8).**

31. Clean and check the parts. Replace any which are defective.
32. Clean the joint faces of the lift cover and of the spool valve support.
33. Fit the bushes (8) in the cover.
34. Fit the cup plug (17) smeared with Loctite 542 flush with the cover (2- speed p.t.o.).
35. Mount the lift shaft (4) and the cam (9) in the cover (Fig. 9).

**Note: Ensure that the direction of the shaft and the position of the cam are correct.**

36. Tighten the set screws (14) smeared with Loctite 241 to a torque of 5 Nm (Fig. 9).

**Note: Apply this torque so as not to deform the cam.**

37. Position the O-rings (7) and the nylon rings (6).  
**Note: Protect the splines of the shaft. Lubricate the O-rings before mounting (Fig. 10).**
38. Grease the splines of the shaft (4) (Anti-Seize Grease or equivalent).
39. Fit the lift arm (5) (sensor side), the washer (1), the retainer (3) and the screw (2).  
**Note: Grease the face of the cover (Anti-Seize Grease or equivalent) before fitting the arms.**
40. Tighten the screw (2) so as to align two flat sides of the screw head with the two tabs of the retainer (3). Bend back the tabs.

**Note: If work has been done without the need to carry out shimming J1 (Fig. 12) (eg. replacement of seals) it is essential to place the shims [12] at the left end of the shaft (factory fitting) to preserve the correct positioning of the cam and avoid having to adjust the sensor (26).**




Fig. 8




Fig. 9




Fig. 10



6B01.8

## Rear Axle - Lift cover

41. Carry out shimming of the shaft (4) (Fig. 12) to obtain:

**J1 = +0.05 to +0.20 maximum.**

Mount the arm (11), the washer (1) and the bolt (2).

**Note: Grease the face of the cover (Anti-Seize Grease or equivalent) before mounting the arm.**

42. Tighten the bolt so as to position the lift arms (5) and (11) correctly on the shaft.

43. Remove the bolt (2) and the washer (1) at the left end of the shaft.

44. Measure the distance between face A of the shaft and face B of the arm using a depth gauge (Figs. 11 and 12).

45. By measuring dimension X, determine the thickness of spacers Y needed to obtain (Fig. 12):

**J1 = +0.05 to +0.20 maximum.**

**J1 = X + Y**

46. Mount the previously selected shims [12], the washer (1), the retainer (3) and the bolt (2).

47. Tighten the bolt (2) so as to align two flat sides of the screw head with the two tabs of the retainer (3). Bend back the tabs.

**For tractors equipped with economy 4-speed PTO, carry out operations 48 to 51.**

48. Refit the finger (19) (Fig. 13).

49. Mount the O-ring (20) from the exterior side of the cover (Fig. 13).

50. Smear the screws (18) and (22) with Loctite 241 and tighten.

51. Check that the control functions smoothly.

52. Fit the elbow connector (23).




Fig. 11




Fig. 12




Fig. 13



## Rear Axle - Lift cover

### D. Refitting

53. Clean the joint face of the cover on the rear axle housing.
54. Smear the joint face with a sealing compound (Master Joint 510 Loctite or equivalent).
55. Lift cover into position.

**Note:** When refitting the cover, ensure that the supply pipe of the differential lock and the control finger (4-speed economy PTO) engage properly in their respective positions (Fig. 14).

56. Mount the supports for the PTO control cables (depending on the version) and fit the bolts (24) of the cover (10). Tighten to the following torque :

- . 12mm diameter bolt = 72- 96 Nm
- . 16mm diameter bolt = 160-200 Nm

A heavy-duty cover and five new bolts (24) has been released on 3125 tractor from SN : S067011. The tightening torque of 16 mm diam bolts is 240 - 320 Nm instead of 160 - 200 Nm.

57. Refit the upper pins to the rams and lift rods. Refit the trailer brake valve support if fitted. Retighten the pipe at both ends.

58. Refit (Fig. 4) :

- . the differential lock supply pipe (3)
- . the cable (4) (4-speed PTO, if fitted)
- . the cable (5) (shiftable PTO, if fitted)

59. Fit the vehicle speed sensor (15) with "Loctite 577 Sensor Sealing" or equivalent (Autotronic, Datatronic tractors) (Fig. 15).

60. Screw in the speed sensor into contact with the crownwheel, without forcing it.

61. Unscrew the sensor 3/4 of a turn so as to obtain a clearance of approx. 1 mm between the sensor and the crownwheel (Fig. 15).

62. Tighten the nut (16) moderately (Fig. 15).

63. Connect the sensor.

64. Fix the harness assembly with a clip.

65. Clean the joint face of the spool valve support .

66. Coat the joint face of the spool valve support with a sealing compound (Master Joint 510 Loctite or equivalent).

67. Refit the support and spool valve assembly (1) (Fig. 16).




Fig. 14




Fig. 15




Fig. 16



6B01.10



# Rear Axle - Lift cover

- 68. Smear the thread of the two lower screws (4) with Loctite 510. Fit and tighten the bolts (4) in the spool valve support to a torque of 50-70 Nm (Fig. 17).
- 69. Reconnect (Fig. 17):
  - the supply hose (1) to the spool valve
  - the supply hose (3) to the lift valve
  - the return hose (2)
- 70. Adjust the p.t.o. control (4-speed) (chapter 6D01, operations 127 and 132 to 137) and the p.t.o. control (shiftable) (chapter 6E02, operations 47 and 52 to 58).
- 71. Remove the blocks between the cab supports and the trumpets. Position the cab.
- 72. Refit the rear fastening screws of the cab. Tighten the nuts to 27-35 Nm and the lock-nuts smeared with Loctite 270 to 13-20 Nm. Refasten the guard plates.
- 73. Fit and adjust the position sensor.
- 74. Smear the thread of the sensor (26) with a sealing compound (Hylomar or equivalent), then screw in the sensor a few turns and connect the harness.
- 75. Start the engine.
- 76. Using the external control, make sure that the lift arms are in the fully raised position (relief valve blowing).
- 77. Stop the engine, then make a mark on the cover and on one arm. Screw in the sensor (without forcing it) until it meets the cam (9) and unscrew by approximately one turn (ie. 1.5 mm).
- 78. Fix the harness.
- 79. Start the engine.
- 80. Using the internal control, lower and raise the lift arms.
- 81. Check the position of the moving mark on the arm. The difference between the two marks should be approx. 3 mm.
 

**Note:**

  - a) If the difference is greater than 3 mm, unscrew the sensor slightly.
  - b) If the difference is less than 3 mm, retighten the sensor slightly.
- 82. Tighten the nut (25) to a torque of 25 Nm using a suitable spanner (Fig. 18).
- 83. Check for leaks:
  - at the joint between the lift cover and the spool valve support
  - at the hydraulic connectors.
- 84. Refit the sheetmetal.

### Version without lift

- The holes of the shaft (4) are plugged with caps (27) sealed with Loctite 542.
- The position sensor (26) is replaced with a threaded plug (28) equipped with a seal (29).

### Version without Autotronic

- The vehicle speed sensor (15) is replaced with a threaded plug (30) equipped with a seal (31).




Fig .17




Fig .18



**Rear axle - 3000 Tractor trumpet**

**6 C01 3000 Tractor Trumpet housings**

**CONTENTS**

General	2
A. Trumpet housing assembly	5
B. Planetary carrier assembly	7
C. Bearings and seals	8
D. Axle shaft bearings preload	9
E. Wheel stud replacement	10



6C01.2

## 3000/3100 SERIES TRACTORS



# Rear axle - 3000 Tractor trumpet

### General

#### Description

The trumpet housings support the RH and LH axle shafts and house the final reduction units which transmit the drive from the differential assembly.

There are two versions of the rear axle, normal and heavy duty, depending on the size of tractor: normal for the 3050, 3060 and 3065 tractors and heavy duty for the 3070, 3080 and 3095 tractors.

The two trumpet housings are identical and are fitted on either side of the centre housing.

#### Construction

The half shaft (2) is supported by two taper roller bearings (5) and (8) fitted opposite each other. The unit is sealed on the outside by a triple lip seal (3) and on the inside by a single lip seal (7). The final reduction planetary carrier assembly (10) fitted with three pinions (14) is splined onto the half shaft (2).

The heavy duty planetary carrier assemblies comprise two rows of needle rollers (16) separated by a spacer (15). The normal duty planetary carrier assemblies have only one row of needle rollers (16). The recesses in carrier assemblies (10) are rough finished and as such planetary gears (14) end float is adjusted by fitting suitable thickness thrust washer (13).

Shims (26) located at the end of the axle shaft allow the taper roller bearing preload to be adjusted. The half shaft (2) and the planetary carrier assembly (10) are held by the washer (25) and the bolt (24). The ring gear (22) is a force fit in the trumpet housing and attached by three bolts (17). It comprises three locating dowels (21) which centre the brake plate (18).

Drive from the differential is transmitted to the final reduction planetary gears through a planetary shaft (23) on to which the brake disc (19) is splined.

### Key to illustrations


- |                                 |   |
|---------------------------------|---|
| (1) Wheel stud                  | (14) Planetary gear                                 |
| (2) Axle shaft                  | (15) Spacer (heavy duty planetary carrier assembly) |
| (3) Triple lip seals            | (16) Needle rollers                                 |
| (4) Seal housing                | (17) Bolt   |
| (5) Bearing cup                 | (18) Brake plate                                    |
| (5A) Bearing cone               | (19) Brake disc                                     |
| (6) Trumpet housing             | (20) Bolt   |
| (7) Seal                        | (21) Locating dowel                                 |
| (8) Bearing cup                 | (22) Ring gear                                      |
| (8A) Bearing cone               | (23) Planetary shaft                                |
| (9) Spur washer                 | (24) Bolt   |
| (10) Planetary carrier assembly | (25) Washer   |
| (11) Circlip                    | (26) Shim(s)  |
| (12) Planetary gear pin         | (27) Locating dowel                                 |
| (13) Thrust washer(s)           | (28) Plug   |





Rear axle - 3000 Tractor trumpet

6C01.3






6C01.4

3000/3100 SERIES TRACTORS



Rear axle - 3000 Tractor trumpet








## Rear axle - 3000 Tractor trumpet

6G01.5

### A. Trumpet housing assembly

#### Removal

1. Immobilize the tractor. Apply the handbrake. Fit chocks between the frame and the front axle (see 3 A01 Fig 1).
2. Drain the rear axle only.
3. Using a trolley jack, raise the side of the tractor involved.
4. Support the tractor with an axle stand.
5. Remove the wheel.
6. Remove the stabilizer bracket
7. Disconnect the draft control sensor harness.
8. On tractors fitted with **an automatic hitch**, the sensor is removed outwards (Fig. 1).
9. Remove the cab attaching bolts (**A**) (Low profile cab Fig.2) - (Hiline cab Fig.3).
10. Raise the cab sufficiently to prevent any fouling when the trumpet housing is removed (chock the cab).  
**Important : Check the clearance between the hood and the windscreen (if insufficient remove the sheet metal).**
11. Remove the spacer (**B**) (Fig.2 low profile cab).  
**Note: Only for trumpet housing replacement on hiline cab tractors, remove bolts (A) and (C) and the spacer B (Fig.3).**
12. Position a suitable support on a trolley jack under the trumpet housing.
13. For the LH trumpet housing disconnect the lift hydraulics valve supply hose (plug the ends).
14. Unscrew the attaching bolts (**20**).
15. Pull the trumpet housing away from the rear axle housing.





6C01.6



## Rear axle - 3000 Tractor trumpet

16. Remove :

- the brake disc (19)
- the planetary shaft (23)
- the locating dowel (27)

**Note :** To prevent the brake piston (C) from coming out of the housing, it is recommended that two wide washers and two bolts be fitted diametrically opposite each other to hold it in place. (Fig.4)

17. Remove the brake plate (18).

### Refitment

18. Clean the mating faces of the centre housing and the trumpet housing with a non-greasy solvent.

19. Apply a bead of oil resistant (Silicomet type) silicone to the inner edge of the centre housing (Fig.5).

**Note:** Do not block up the oil drain hole in the housing.

20. Check that the disk (19) slides freely on the planetary shaft (23) (Fig.6).

21. Refit the locating dowel (27), the planetary shaft (23) and the brake disc (19).

22. Screw two dowel pins into diametrically opposite positions on the centre housing.

23. Refit the brake plate (18) in the trumpet housing.  
**Note:** To retain the plate, apply three spots of "Amber Technical" grease or an equivalent product to the surface of the ring gear (22).

24. Fit the trumpet housing to the centre housing.  
**Note:** Turn the shaft (2) to engage the planetary shaft (23) in the planetary gears.

25. Clean the bolts (20) and coat them with Plastex, Hylomar or an equivalent gasket sealant.

26. Fit and tighten the bolts (20) to a torque of 170-210 Nm.

27. Carry out procedures 12 and 13 in reverse.

28. Carry out procedures 10 and 11 in reverse.

29. Refit the cab attaching bolts with the nuts and locknuts to a torque of :

Nut : 27-35 Nm

Locknut : 13-20 Nm (with Loctite 270)

30. Refit the draft control sensor.

**Note:** Lightly coat the draft control sensor with Loctite Anti-seize or equivalent grease.

31. Reconnect the draft control sensor harness and refit the stabilizer bracket.

32. Replenish transmission oil.

33. Refit the wheel. Tighten to a torque of 400-450 Nm.

34. Remove the axle stand.

35. Test the hydraulic lift and brake circuits.




Fig. 4




Fig. 5




Fig. 6



## Rear axle - 3000 Tractor trumpet

### 36. Check for leaks :

- between the trumpet housing and the rear axle housing
- from the lift system valve supply hose (LH trumpet housing)

## B. Planetary carrier assembly

### Disassembly

1. Remove the trumpet housing (see Section A).
2. Remove the bolt (24) (Fig. 7).
3. Remove the retaining washer (25) and the shim(s) [26] (Fig. 7).
4. Remove the planetary carrier assembly (10).
5. Open out the circlip (11) (Fig. 8).
6. Using a copper tipped mallet, tap lightly on the three pins (12) (Fig. 8).
7. Remove the three pins (12) and the circlip (11).
8. Remove the three planetary gears (14), the needle rollers (16), the spacers (15) (heavy duty planetary gear A) and the thrust washers [13].

### Reassembly

9. Clean the planetary carrier (10), the pins (12) and the planetary gears (14). Check the condition of the parts.
10. Coat the needle rollers (16) with "Amber Technical" or an equivalent grease. Into each planetary gear (14) insert :
  - Heavy duty planetary carrier (A) : two rows of needle rollers separated by a spacer (15) (Fig. 7).
  - Normal duty planetary carrier (B) : one row of needle rollers (Fig. 7).

**Note: Each heavy duty planetary gear (A) has 42 needle rollers.**

**Each normal duty planetary gear (B) has 21 needle rollers.**

11. Shim the planetary gears.

**Note: Three thicknesses of thrust washer [13] are available :**

- 3382026 M2 = 1.60 / 1.50
- 3382210 M1 = 2.37 / 2.27
- 3580962 M1 = 2.10 / 2.00

12. Position the planetary gears (14) and the medium thickness washers [13] on each side of the planetary gear.

13. Fit the three pins (12).




Fig. 7




Fig. 8



6C01.8

**Rear axle - 3000 Tractor trumpet**

14. Using a set of feeler gauges, determine the thickness of washers [13] to be fitted to obtain an end play of between 0.15 and 0.55 on each planetary gear (Fig.9).
15. Pull out the three pins slightly and fit the shims [13] selected in procedure 14 (Fig.10).
16. Push in the three pins and fit the circlip (11).
17. Open out the circlip (11) (Fig.8).
18. Tap lightly on the three pins to insert the circlip (11) into the groove in the planetary carrier (Fig.11).
19. Check that the spur washer (9) is fitted.
20. Refit the planetary carrier.
21. Fit shims to obtain the required preload (see Section D).
22. Refit the trumpet housing (see Section A).




Fig. 9

**C. Bearings and Seals****Disassembly**

1. Separate the trumpet housing from the centre housing (see Section A).
2. Remove the planetary carrier (see Section B).
3. Remove :
  - the spur washer (9) (Fig. 12)
  - the bearing cone (8A) (runs free on shaft)
4. Withdraw the shaft (2) from the trumpet housing.
5. Extract the cone (5A).
6. Drive out the triple lip seal /3\.
7. Using an extractor, remove:
  - the cup (5)
  - the housing (4) for seal /3\
  - the cup (8)
8. Drive out the seal /7\.




Fig. 10

**Reassembly**

**Note:** The planetary ring gear (22) is a tight fit in the trumpet housing (6) (page 3).

It is centred by the three locating dowels (21) (Loctite 638) and tightened by the three bolts (17) to a torque of 79-90 Nm (Loctite 242).

9. Clean the seal contact surfaces, the cup seats and the cones in the trumpet housing and on the shaft. The seal, cup and cone contact surfaces must be free from burrs and damage.
10. Coat the outside diameter of the seal /7\ with Loctite 542 (metal cage).

**Note:** Fit the seal the correct way round.





Fig. 11



## Rear axle - 3000 Tractor trumpet

### 11. Replacement of seal /7\ :

#### a) Without replacing the shaft (2)

So that the seal lip is not in the same place on the shaft, press on the seal until it is 4 mm from the shoulder of the cup (8) (Fig.12).

#### b) Replacing the shaft (2)

Position the seal 5 mm from the shoulder of the cup (8) (Fig.13).

12. Lubricate the cups (8) and (5) and press them fully on to the shoulder.

13. Press the housing (4) fully on to the shoulder (Fig.14).

14. Push the triple lip seal /3\ up against the shaft shoulder.

**Note : Ensure that the seal is fitted the correct way round (Fig.14).**

15. Lubricate the shaft (2) and press the cone (5A) against the shoulder.

16. Lightly grease the cone (5A) and the lips of seals /3\ and /7\ (use BP Agricharge or an equivalent-grease).

17. Protect the splines of the shaft (2) and insert it into the trumpet housing.

**Note: The lips of seal /3\ must face outwards.**

18. Remove the protection from the shaft and lightly lubricate the cone (8A).

19. Refit the cone (8A), the washer (9) and the planetary carrier (10).

20. Fit shims to obtain the required preload (see D).

21. Replace the plug (28) by a grease nipple. Partly fill the cavity at the end of the trumpet housing between the cone (5A) and the seal /3\ with BP Agricharge or an equivalent grease. Remove the grease nipple and refit the plug (Fig.14).

22. Refit the trumpet housing (see Section A).




Fig. 12




Fig. 13




Fig. 14

### D. Axle shaft bearings preload

1. Place the trumpet housing assembly in a vertical position.
2. Remove the bolt (24) and the washer (25).
3. Seat the cones (5A) and (8A) in their cups by turning the trumpet housing on its shaft.



6C01.10

## 3000/3100 SERIES TRACTORS



### Rear axle - 3000 Tractor trumpet

4. Fit shims [26] required to provide thickness greater than dimension **X** to obtain end play (Fig. 15).
5. Fit the washer (25) and the bolt (24) and tighten to a torque of 270-440 Nm.
6. Using a dial gauge, check the end play by moving the planetary carrier laterally (Fig. 16).
7. Remove the bolt (24) and the washer (25).  
On the basis of the reading obtained, remove the number of shims [26] required to obtain a preload of : **P1 = 0.025 to 0.125**
8. Clean the threads at the end of the shaft (2).
9. Refit the washer (25).
10. Clean the bolt (24) and coat it with Loctite 241. Tighten to a torque of 270-440 Nm.




Fig. 15

#### E. Rear wheel stud replacement

1. Drive out the damaged stud using a hammer and bronze drift.
2. Clean the marks left by the stud ridges with a paint brush dipped in solvent.
3. Dry with compressed air.
4. Apply a few drops of Loctite 270 to the new stud ridges.
5. Place the new stud in the ridge marks left by the old stud.
6. Make sure that the ridges are properly engaged and then knock the stud head up against the half shaft flange with a bronze mallet.




Fig. 16





**Rear axle - 3100 Tractor trumpet**

**6 C02 3100 Tractor Trumpet housings**

**CONTENTS**

General	2
A. Trumpet housing assembly	5
B. Planetary carrier assembly	6
C. Bearings and seals	8
D. Axle shaft bearings preload	9
E. Wheel stud replacement	9



6C02.2

## 3000/3100 SERIES TRACTORS



# Rear axle - 3100 Tractor trumpet

### General

#### Description

The trumpet housings support the RH and LH axle shafts and house the final reduction units which transmit the drive from the differential assembly.

The two trumpet housings are identical and are fitted on either side of the centre housing.

#### Construction

The half shaft (2) is supported by two taper roller bearings (5) and (8) fitted opposite each other. The unit is sealed on the outside by a triple lip seal /3\ and on the inside by a single lip seal /7\ . The final reduction planetary carrier assembly (21) fitted with three pinions (18) is splined onto the half shaft (2). Shims [22] located at the end of the axle shaft allow the taper roller bearing preload to be adjusted. The half shaft (2) and the planetary carrier assembly (21) are held by the washer (23) and the bolt (24). The ring gear (10) is a force fit in the trumpet housing. It comprises five locating dowels (9) which centre the brake plate (26). Drive from the differential is transmitted to the final reduction planetary gears through a planetary shaft (25) on to which the brake disc (27) is splined.


#### Key to illustrations

- |                          |                         |
|--------------------------|-------------------------|
| (1) Wheel stud           | (14) Spacer             |
| (2) Axle shaft           | (15) Circlip            |
| /3\ Triple lip seal      | (16) Planetary gear pin |
| (4) Seal housing         | (17) Thrust washer      |
| (5) Bearing cup          | (18) Planetary gear     |
| (5A) Bearing cone        | (19) Spacer             |
| (6) Trumpet housing      | (20) Needle roller      |
| /7\ Seal                 | (21) Planetary carrier  |
| (8) Bearing cup          | [22] Shim(s)            |
| (8A) Bearing cone        | (23) Retaining washer   |
| (9) Locating dowel       | (24) Bolt               |
| (10) Planetary ring gear | (25) Sun wheel          |
| (11) Spur washer         | (26) Brake plate        |
| (12) Plug                | (27) Brake disc         |
| (13) Bolt                | (28) Locating dowel     |
|                          | (29) Bolt               |



# Rear axle - 3100 Tractor trumpet

6C02.3






6C02.4

3000/3100 SERIES TRACTORS



Rear axle - 3100 Tractor trumpet

Exploded view





## Rear axle - 3100 Tractor trumpet

6C02.5

### A. Trumpet housing assembly

#### Removal

1. Immobilize the tractor. Apply the handbrake. Fit chocks between the frame and the front axle (see 3 A02 Fig 2).
2. Drain the rear axle only.
3. Using a trolley jack, raise the side of the tractor involved.
4. Support the tractor with an axle stand.
5. Remove the wheel.
6. Remove the stabilizer bracket
7. Disconnect the draft control sensor harness (without disconnecting the harness).
8. Remove the cab attaching bolts (A) with the nuts (Fig. 1).
9. Raise the cab sufficiently to lift the support spacer (B) clear (Fig. 1).  
**Note : Check the clearance between the hood and the windscreen (if insufficient remove the sheet metal).**
10. Position a suitable support on a trolley jack under the trumpet housing.
11. For the LH trumpet housing disconnect the lift hydraulics valve supply hose (plug the ends).
12. Unscrew the attaching bolts (29).
13. Separate the trumpet housing from the rear axle housing.
14. Remove :
  - . the brake disc (27)
  - . the planetary shaft (25)
  - . the locating dowel (28)**Note: To prevent the brake piston (C) from coming out of the housing, it is recommended that two wide washers and two bolts be fitted diametrically opposite each other to hold it in place. (Fig.2)**
15. Remove the brake plate (26).




Fig. 1




Fig. 2



## Rear axle - 3100 Tractor trumpet

### Refitment

16. Clean the mating faces of the centre housing and the trumpet housing with a non-greasy solvent.
17. Apply a bead of oil resistant silicone (Silicomex type) to the inner edge of the centre housing (Fig.3).

**Note: Do not block up the oil drain hole in the housing.**

18. Check that the disk (27) slides freely on the planetary shaft (25) (Fig.4).
19. Refit the locating dowel (28), the planetary shaft (25) and the brake disc (27).
20. Screw two dowel pins into diametrically opposite positions on the centre housing.
21. Refit the brake plate (26) in the trumpet housing.

**NOTE: To retain the plate, apply three spots of "Amber Technical" or equivalent grease to the surface of the ring gear (10).**

22. Fit the trumpet housing to the centre housing.  
**Note: Turn the shaft (2) to engage the planetary shaft (25) in the planetary gears (18)**
23. Clean the bolts (32) and coat them with Plastex, Hylomar or an equivalent gasket sealant.
24. Fit and tighten the bolts (29) to a torque of 170 - 210 Nm.
25. Carry out procedures 9 to 11 in reverse.
26. Refit the cab attaching bolts with the nuts and locknuts to a torque of:  
Nut : 27-35 Nm  
Locknut : 13-20 Nm (with Loctite 270)
27. Refit the draft control sensor.




**Note: Lightly coat the draft control sensor with Loctite Anti-seize or equivalent grease.**

28. Carry out procedures 6 and 3 in reverse
29. Refit the wheel. Tighten to a torque of 400 - 450 Nm.
30. Remove the axle stand.
31. Carry out procedures 1 and 2 in reverse.
32. Test the hydraulic lift and brake circuits.
33. **Check for leaks :**
  - between the trumpet housing and the centre housing
  - from the lift system valve supply hose (LH trumpet housing)

### B. Planetary carrier assembly

#### Disassembly

1. Remove the trumpet housing (see Section A).
2. Remove the bolt (24).
3. Remove the retaining washer (23) and the shim(s) [22] (Fig.5).





## Rear axle - 3100 Tractor trumpet

4. Remove the planetary carrier assembly (21).
5. Remove the bolt (13) and the spacer (14).
6. Open out the circlip (15) (Fig.6).
7. Using a copper tipped mallet, tap lightly on the three pins (16) (Fig.6).
8. Remove the three pins (16) and the circlip (15).
9. Remove the three planetary gears (18), the needle rollers (20), the spacers (19) and the thrust washers (17).

### Reassembly

10. Clean the planetary carrier (21), the pins (16) and the planetary gears (18). Check the condition of the parts.
11. Coat the needle rollers (20) with "Amber Technical" or an equivalent grease. Into each planetary gear (18) insert two rows of needle rollers separated by a spacer (19).
- Note: Each planetary gear has 56 needle rollers.**
12. Fit the planetary gears (18) and the thrust washers (17).
13. Fit three pins (16) with the circlip (15) (Fig.7).
14. Open out the circlip (15) (Fig.6).
15. Tap lightly on the three pins to insert the circlip (15) into the planetary carrier groove (Fig.7).
16. Position one end of the circlip in contact with the pin (16) (Fig.8)
17. Clean the threads of the bolt (13). Fit the spacer (14). Coat the bolt (13) with Loctite 270 before fitting. Tighten to a torque of 34 - 50 Nm (Fig.8).
18. Check that the spur washer (11) is fitted.
19. Refit the planetary carrier.
20. Fit shims to obtain the required preload (see Section D).
21. Refit the trumpet housing (see Section A).




Fig. 6




Fig. 7




Fig. 8



6C02.8

**Rear axle - 3100 Tractor trumpet****C. Bearings and Seals****Disassembly**

1. Separate the trumpet housing from the centre housing (see Section A).
2. Remove the planetary carrier (see Section B).
3. Remove :
  - the spur washer (11) (Fig. 9)
  - the bearing cone (8A) (runs free on shaft)
4. Withdraw the shaft (2) from the trumpet housing.
5. Extract the cone (5A).
6. Drive out the triple lip seal /3\.
7. Using an extractor, remove:
  - the cup (5)
  - the housing (4) for seal /3\
  - the cup (8)
8. Drive out the seal /7\.




Fig. 9

**Reassembly**

9. Clean the seal contact surfaces, the cup seats and the cones in the trumpet housing and on the shaft. The seal, cup and cone contact surfaces must be free from burrs and damage.
10. Coat the outside diameter of the seal /7\ with Loctite 542.
 

**Note: Fit the seal the correct way round.**
11. Replacement of seal /7\ :
  - a) Without replacing the shaft (2)
 

So that the seal lip is not in the same place on the shaft, press on the seal until it is 9 mm from the shoulder of the cup (Fig 9).
  - b) Replacing the shaft (2)
 

Position the seal 8 mm from the shoulder of the cup (Fig. 10).
12. Lubricate the cups (8) and (5) and press them fully on to the shoulder.
13. Press the housing (4) to within 20 mm of the trumpet housing (Fig. 11).
14. Push the triple lip seal /3\ up against the shaft shoulder.
 

**Note: Ensure that the seal is fitted the correct way round (Fig. 11).**
15. Lubricate the shaft (2) and press the cone (5A) against the shoulder.
16. Lightly grease the cone (5A), the lips of seals /3\ and /7\ (use BP Agricharge or an equivalent grease).




Fig. 10




Fig. 11





## Rear axle - 3100 Tractor trumpet



17. Protect the splines of the shaft (2) and insert it into the trumpet housing.  
**Note: The lips of the seal /3\ must face outwards.**
18. Remove the protection from the shaft and lightly lubricate the cone (8A).
19. Carry out procedures 2 and 3 in reverse.
20. Fit shims to obtain the required preload (see D).
21. Replace the plug (12) by a grease nipple. Partly fill the cavity at the end of the trumpet housing between the cone (5A) and the seal /3\ with BP Agri-charge or an equivalent grease. Remove the grease nipple and refit the plug (Fig. 11).
22. Refit the trumpet housing (see Section A).

### D. Axle shaft bearings preload

1. Place the trumpet housing assembly in a vertical position.
2. Remove the bolt (24) and the washer (23).
3. Seat the cones (5A) and (8A) in their cups by turning the trumpet housing on its shaft.
4. Fit shims [22] required to provide thickness greater than dimension X to obtain end play (Fig. 12).
5. Fit the washer (23) and the bolt (24) and tighten to a torque of 270 - 440 Nm.
6. Using a dial gauge, check the end play by moving the planetary carrier laterally (Fig. 13).
7. Remove the bolt (24) and the washer (23).  
On the basis of the reading obtained, remove the number of shims [22] required to obtain a preload of :  $P1 = 0.025$  to  $0.125$
8. Clean the threads at the end of the shaft (2).
9. Refit the washer (23).
10. Clean the bolt (24) and coat it with Loctite 241. Tighten to a torque of 270 - 440 Nm.

### E. Rear wheel stud replacement

1. Drive out the damaged stud using a hammer and bronze drift.
2. Clean the marks left by the stud ridges with a paint brush dipped in solvent.
3. Dry with compressed air.
4. Apply a few drops of Loctite 270 to the new stud ridges.
5. Place the new stud in the ridge marks left by the old stud.
6. Make sure that the ridges are properly engaged and then knock the stud head up against the half shaft flange with a bronze mallet.





*6 D01 Intermediate shaft - Driving pinion -  
Power-take-off brake*

CONTENTS

-	General	2
-	Operation	2
A.	2-speed PTO (without shimming)	5
B.	2-speed PTO (with shimming)	6
C.	4-speed economy PTO (without shimming)	8
D.	4-speed economy PTO (with shimming)	10
E.	Adjustment of PTO control 4-speed economy	12



6D01.2

Rear axle - Inter<sup>e</sup> shaft - Driv<sup>ing</sup> pinion - PTO brake

General

The drive from the engine is transmitted to the power-take-off clutch mounted at the front of the centre housing.

The intermediate shaft (2) is connected by splines at one end to the clutch and at the other end either to the double pinion (13) in the 2-speed PTO version or to the coupler (31) in the 4-speed economy PTO version.

The compound pinion (13) turns on two taper roller bearings (3) (4) and (7) (8), mounted in the bore of the centre housing and the top link support (10) respectively.

A piston (9) housed in the 3rd point support and controlled by the 17 bar hydraulic circuit enables the compound pinion (13) to be braked when the control lever is moved to the PTO braking position.

Operation

2-speed PTO

When the PTO solenoid valve feeds the clutch, the intermediate shaft (2) is driven. This in turn drives the compound driving pinion (13) which engages constantly with the 540 rpm and 1000 rpm pinions of the lower line.

4-speed PTO

This feature enables speeds of 540 rpm or 1000 rpm to be obtained with an engine speed of 1550 rpm.

Standard position (engine speed 2000 rpm)

When the coupler (31) is moved forwards, the intermediate shaft (2) turns with the shaft (35) which drives the compound driving pinion (13). This configuration is identical to the 2-speed PTO version.

Economy position (engine speed 1550 rpm)

When the coupler (31) is moved backwards, the drive is transmitted to the coupler (34) (fitted loose on the shaft (35)) and to the compound pinion (18) which drives the driving pinion (13). The ratio of the compound pinion (18) is 1.292.

Power-take-off brake

The movement of the control lever in the cab acts on an electrical contactor which enables the solenoid valve of the PTO brake mounted on the right cover to open. Oil is supplied to the chamber situated behind the piston (9). The piston moves and presses the bearing cup (8) against the bearing cone (7), progressively immobilising the driving pinion (13) which constantly engages with the 540 and 1000 rpm pinions.

Power-take-off 4-speed 2-speed


	4-speed	2-speed
(1) Clutch	•	•
(2) Intermediate shaft	•	•
(3) Bearing cup	•	•
(4) Bearing cone	•	•
(5) Washer	•	•
(6) Bolt	•	•
(7) Bearing cone	•	•
(8) Bearing cup	•	•
(9) Brake piston	•	•
(10) Top link support	•	•
(11) Shims	•	•
(12) O-ring	•	•
(13) Driving pinion	•	•
(14) Compound pinion assembly	•	•
(15) Deflector	•	•
(16) Washer	•	•
(17) Needle roller bearing	•	•
(18) Compound pinion	•	•
(19) Spacer	•	•
(20) Needle roller bearing	•	•
(21) Washer	•	•
(22) Set screw	•	•
(23) Shaft	•	•
(24) Locking screw	•	•
(25) Nut	•	•
(26) Fork	•	•
(27) Screw	•	•
(28) Needle roller bearing	•	•
(29) Circlip	•	•
(30) Ring	•	•
(31) Dog tooth coupler	•	•
(32) Circlip	•	•
(33) Washer	•	•
(34) Dog tooth pinion	•	•
(35) Shaft	•	•
(36) Cup plug	•	•



3000 / 3100 SERIES TRACTORS

Rear axle - Inter<sup>re</sup> shaft - Driv<sup>ing</sup> pinion - PTO brake

6D01.3






6D01.4

3000 / 3100 SERIES TRACTORS



Rear axle - Inter<sup>re</sup> shaft - Driving pinion - PTO brake





## A. 2-speed PTO (without shimming)

### Disassembly

1. Disconnect (Fig. 1):
  - the auxiliary spool valve supply hose (1)
  - the supply hose of the lift valve (3)
  - the return hose (2)
2. Remove the bolts (4) of the auxiliary spool valve support (5) (Fig. 1).
3. Detach the auxiliary spool valve support.  
**Note: Tilt the support and auxiliary spool valve assembly without detaching the control cables (1) (Fig. 2).**
4. Disconnect the supply tube (1) of the PTO brake (Fig. 3).
5. Disconnect the lubrication tube (4) (Fig. 3).
6. Remove the bolts (3) and the top link support (10) (Fig. 3).
7. Withdraw the pinion (13) and shaft (2) assembly held by the washer (5) and screw /6/. Remove the bearing cone (4).  
**Note: The shaft (2) is mounted in the clutch (1) without locking screw.**

### Reassembly

8. Check and clean the parts. Replace those which are defective.
9. Refit the bearing cone (4). Fit the pinion (13) and shaft (2) assembly held by the washer (5) and screw /6/.
10. Clean the joint face of the top link support.
11. Smear the joint face of the housing with a sealing compound (Loctite 510 or equivalent).  
**Note: To ensure the lubrication of the bearing cone (7), a cup plug (36) is fitted without Loctite, recessed into the face of the housing.**
12. Refit the top link support (10). Fit and tighten the bolts (3) to a torque of 130-170 Nm (Fig. 3).  
**Note: Ensure that the cup (8) is present.**
13. Reconnect the supply tube of the PTO brake (1) and the lubrication tube (4) (Fig. 3).
14. Clean the joint face of the spool valve support.
15. Smear the joint face of the support cover with a sealing compound (Loctite 510 or equivalent).
16. Refit the support, tilting it, with the control cables (1) (Fig. 2).
17. Smear the threads of the two lower bolts (4) with Loctite 510. Fit and tighten the bolts (4) to a torque of 50-70 Nm (Fig. 1).




Fig. 1




Fig. 2




Fig. 3



6D01.6

Rear axle - Inter<sup>te</sup> shaft - Driv<sup>ing</sup> pinion - PTO brake

18. Reconnect (Fig. 1):
  - . the spool valve supply hose (1)
  - . the supply hose of the lift valve (3)
  - . the return hose (2).
19. Check the operation of the PTO and its brake.
20. Check for leaks
  - . at the joint faces (spool valve support, top link support)
  - . at the hydraulic connectors.




Fig. 4

**B. 2-speed PTO (with shimming)**

**Note: Shimming J1 must be carried out when working on the following parts: Pinion (13), deflector (15), bearing cones (4) (7), cups (3) (8), piston (9), support (10).**

**For correct shimming of the bearing cones (4) (7) and of the cups (3) (8), it is necessary to remove the lift cover.**

**Disassembly**

21. Remove the lift cover. Carry out operations 1 to 11, chapter 6B01.
22. Disconnect the supply tube (1) from the PTO brake (Fig. 3).
23. Disconnect the lubrication tube (4) (Fig. 3).
24. Remove the bolts (3) of the top link support (Fig. 3) and detach it.
25. Withdraw the pinion (13) and shaft (2) assembly held by the washer (5) and bolt (6).
26. Remove the screw (6) and the washer (5).
27. Separate the pinion (13) from the shaft (2).

**Note: The shaft (2) is mounted in the clutch (1) without locking screw.**

**Note: A deflector (15) mounted between the pinion (13) and the bearing cone (7), in contact with the cup (8) (Fig.4), has been introduced on 3000 tractors from serial number N120009 onwards.**

28. Extract the bearing cone (7) and the deflector (15) (Fig. 5), then remove the bearing cone (4).
- Note: To extract the cup (3) it is necessary to remove the 540/1000 rpm pinions. Partly drain the rear axle housing. Carry out operations 29, 8 to 11 and 31, chapter 6E01.**




Fig. 5

**Reassembly**

29. Check and clean the parts. Replace those which are defective.
30. Place the deflector (15) on the pinion (13). Push the bearing cone (7) on as far as the shoulder with the aid of a press (Fig. 6).  
Lubricate the bearing cone (4) and place it in the cup (3).  
**Note: If replacing the cup (3), refit the 540/1000 rpm pinions. Carry out operations 33, 36 and 37, 12 to 15, chapter 6E01. Top up the oil of the rear axle housing.**
31. Withdraw the piston (9) from the top link support (10).
32. Remove the shims [11] and the O-ring (12) in order to prepare for shimming J1.
33. Fit the piston (9) (without O-ring) and the cup (8) in the support (10).
34. Lubricate the cup and the bearing cone (7).
35. Fit the pinion (13) in the housing.
36. Refit the top link support.  
Tighten the bolts to a torque of 130 - 170 Nm.
37. Carry out shimming (Fig. 7) to obtain:  
**J1 = -0.05 to +0.05.**
38. Place the tip of the dial gauge against the end of the pinion (13) (Fig. 8).
39. Pull on the pinion, turning it alternately from right to left, so as to compress the deflector (15), to seat the bearing cone (7) correctly in the cup (8).
40. Set the dial gauge to zero.
41. Push the pinion, turning it alternately from right to left, to seat the bearing cone (4) correctly in the cup (3).
42. Select shims of the correct thickness as a function of the dial gauge reading so as to obtain clearance of J1.
43. Remove the support (10) and withdraw the cup (8) and piston (9).
44. Place the shims [11] selected in operation 42 in the support (10).




Fig. 6




Fig. 7




Fig. 8





6D01.8

**Rear axle - Inter<sup>te</sup> shaft - Driv<sup>ing</sup> pinion - PTO brake**

45. Fit the piston (9) with a new O-ring (12).  
**Note: Position the lubrication holes of the piston toward the bearing cone (Fig. 9).**
46. Fit the cup (8) in the support.
47. Withdraw the pinion (13) and assemble on the shaft (2) with the washer (5) and bolt (6). Tighten to a torque of 50 Nm.
48. Refit the bearing cone (4). Fit the pinion (13) and shaft (2) assembly.
49. Smear the face supporting the top link support on the rear axle housing with a sealing compound (Masterjoint 510 or equivalent).
50. Refit the top link support (10). Fit and tighten the bolts (3) to a torque of 130-170 Nm (Fig. 3).  
**Note: Ensure that the cup (8) is present.**
51. Reconnect the supply tube (1) of the PTO brake and the lubrication tube (4) (Fig. 3).
52. Refit the lift cover.
53. Carry out operations 53 to 57, chapter 6B01.
54. Reverse operation 7, chapter 6B01.
55. Carry out operations 64 to 69, chapter 6B01.
56. Carry out operations 71, 72 and 84, chapter 6B01.
57. Check the operation of the PTO and its brake.
58. Check for leaks:
  - . at the joint faces (spool valve support, top link support, lift cover)
  - . at the hydraulic connectors.




Fig. 9




Fig. 10

**C. 4-speed economy PTO (without shimming)**

**Disassembly**

59. Remove the left side cover.  
If removing the screw (27) and the intermediate shaft (2), carry out operations 1 to 6, chapter 8I02.  
**Note: A new assembly without coupling between the clutch and the intermediate shaft has been introduced on 3000 tractors from serial number N342012 onwards.**  
**For earlier tractors and certain tractors equipped with the old assembly following the introduction: N342017 - N342018 - N342022 - N342026 - N348029 refer to workshop manual 1646640 M1.**
60. Disconnect (Fig. 1):
  - . the spool valve supply hose (1)
  - . the supply hose of the lift valve (3)
  - . the return hose (2).

61. Remove the bolts (4) fastening the support (5) to the lift cover (Fig. 1).
62. Remove the support.  
**Note: Tilt the support and spool valve assembly without detaching the cables (1) (Fig. 2).**
63. Disconnect the supply tube (1) of the PTO brake (Fig. 10).
64. Disconnect the lubrication tube (4) (Fig. 10).
65. Remove the bolts (3) of the top link support (10) and detach it (Fig. 10).

**Rear axle - Inter<sup>e</sup> shaft - Driving pinion - PTO brake**

66. Remove the nut (25) and the locking screw (24) of the fork (26).
67. Remove the screw (22) (Fig. 11).
68. Withdraw the shaft (23) from the compound pinion assembly (14) in order to disengage the fork (26).  
**Note: To disengage the fork alone, gently pull the shaft (23) towards the rear.**
69. Remove the friction washers (16) and (21).  
**Note: Take care not to drop the washers in the housing.**
70. Withdraw the compound pinion assembly (14) (through the aperture of the spool valve support for version without shimming only) (Fig. 12).
71. Remove the needle roller bearings (17) and (20) and the spacer (19) of the pinion (18).  
**Note: A new coupler and a new pinion have been introduced on 3000 tractors from serial number P181042 onwards.**
72. Remove the circlip (32) (Fig. 13).  
**Note: Use short-handled pliers to facilitate access to the circlip.**
73. Withdraw the pinion (13) and shaft (35) assembly held by the washer (5) and bolt (6).
74. Remove the flat washer (33).  
**Note: Take care not to drop the circlip and the washer in the housing.**  
**Hold the pinion (34) and the needle roller bearing (28).**  
**The bearing cone (4) remains in the cup (3) during removal of the pinion (13).**
75. Remove the pinion (34) and the needle roller bearing (28).
76. Remove the bearing cone (4).
77. Remove the hexagon socket setscrew (27) (if necessary).
78. Withdraw the shaft (2) and the coupler (31) (if necessary).  
**Note: The circlip (29) remains on the shaft (2).**

**Reassembly**

79. Clean and check the parts. Replace those which are defective.
80. Refit the shaft (2) and the coupler (31) (if removed).
81. Smear the screw (27) with Loctite 221 and tighten (if removed).
82. Refit the bearing cone (4). Advance the pinion (13) prepared with the shaft (35). Fit the coupler (34), the needle roller bearing (28), the washer (33) and the circlip (32). Push on to the pinion (13). Position the washer (33). Fit the circlip (32).




Fig. 11




Fig. 12




Fig. 13



6D01.10

**Rear axle - Inter<sup>te</sup> shaft - Driv<sup>ing</sup> pinion - PTO brake**

83. In the pinion (18), place the spacer (19) and the needle roller bearings (17) and (20). Position the compound pinion assembly (14). Fit the washer (16) smeared with miscible grease (Amber Technical or equivalent).
84. Lightly engage the shaft (23) to hold the washer (16) in place. Fit the washer (21) smeared with miscible grease. Centre the compound pinion assembly (14).
85. Mount the shaft (23) finally in the pinion assembly (14) and in the fork (26), ensuring that the hole of the screw (22) is properly positioned.
86. Smear the screw (22) with Loctite 542. Fit and tighten to a torque of 28-43 Nm.
87. Clean the joint face of the top link support.
88. Smear the joint face of the housing with a sealing compound (Loctite 510 or equivalent).
89. Ensure that the cup (8) is present. Fit and tighten the bolts (3) to a torque of 130-170 Nm (Fig. 10).
90. Reconnect the tubes (1) and (4) (Fig. 10).
91. Refit the screw (24) and the nut (25) on the fork (26).
92. **Adjustment of locking of fork (26) (Fig. 14):**
- . Position the fork (26) and the locking screw (24) on the flat part M of the shaft (23) (between the two locking notches). Tighten the screw as far as it will go so as to compress the ball.
  - . Loosen the screw by 1/4 of a turn. Smear the nut (25) with Loctite 241. Tighten to a torque of 15-20 Nm.
  - . Check that the fork is locked correctly.
93. Adjust the control.
- Carry out operations 127 and 132 to 137 .
94. Clean the joint face of the spool valve support.
95. Smear the joint face of the support with a sealing compound (Loctite 510 or equivalent).
96. Refit the support, tilting it, with the control cables (1) (Fig. 2).
97. Smear the threads of the two lower bolts (4) with Loctite 510. Tighten the four screws to a torque of 50-70 Nm (Fig. 1).
98. Reconnect the hoses (1) (2) (3) (Fig. 1).
99. If the screw (27) and intermediate shaft (2) have been removed, refit the left side cover. Carry out operations 7 to 20, chapter 8I02.
100. Check the operation of the PTO and its brake.




Fig. 14

**101. Check for leaks**

- . at the joint faces (spool valve support, top link support, left side cover)
- . at the hydraulic connectors.

**D. 4-speed economy PTO (with shimming)**

**Note: Shimming J1 must be carried out when working on the following parts: Pinion (13), deflector (15), bearing cones (4) (7), cups (3) (8), piston (9), top link support (10).**

**For correct shimming of the bearing cones (4) (7) and of the cups (3) (8), it is necessary to remove the lift cover.**

**Disassembly**

102. Remove the lift cover. Carry out operations 1 to 11, chapter 6B01.

103. Carry out operations 63 to 76.

**Note: A strengthened shaft (35) has been introduced on 3000 tractors. The old needle cage has been replaced with a friction ring (30) having an external diameter of 14 mm.**

**The modified shaft has been introduced:**

**. On tractors MF 3050 - 3060 - 3065 - 3070 and 3090 from serial number N287019 onwards.**

**. On tractors MF 3080 from serial number N288017 onwards.**

**For tractors prior to these numbers, refer to workshop manual 1646640 M1.**

**Rear axle - Inter<sup>te</sup> shaft - Driv<sup>ing</sup> pinion - PTO brake**

6D01.11

104. Separate the pinion (13) from the shaft (35) with the aid of a press and a suitable tool (Fig. 15).

**Note: The friction ring (30) is force-fitted in the shaft (35).**

105. Extract the bearing cone (7) and the deflector (15) (Fig. 5).

**Note: To extract the cup (3) it is necessary to remove the 540/1000 rpm pinions.**

**Partly drain the axle housing.**

**Carry out operations 21 to 24, 2 to 6 and 26 of chapter 6E02.**

**Reassembly**

106. Check and clean the parts. Replace those which are defective.

**Note: To obtain correct lubrication of the friction ring (30), a deflector (15) (mounted between the pinion (13) and the bearing cone (7) in contact with the cup (8) (Fig. 16)) has been introduced on 3000 tractors from serial number N120009 onwards.**

107. Place the deflector (15) on the pinion (13). Push the bearing cone (7) on as far as the shoulder with the aid of a press (Fig. 6). Place the bearing cone (4) in the cup (3).

**Note: If replacing the cup (3), refit the 540/1000 rpm pinions. Carry out operations 31 and 32, 7 to 10 and 34 to 37, chapter 6E02.**

**Top up the oil of the rear axle housing.**

108. Carry out operations 31 to 46.

109. Withdraw the pinion (13) and assemble on the shaft (35) (Fig. 17). Mount the washer (5) and bolt /6\.

Tighten to a torque of 50 Nm.

110. Refit the bearing cone (4), the coupler (34) and the needle roller bearing (28).

111. Fit the pinion (13) and shaft (35) assembly.

**Note: Ensure that the coupler (31) is present.**

112. Position the washer (33). Fit the circlip (32).

113. In the pinion (18), place the spacer (19) and the needle roller bearings (17) and (20). Position the compound pinion assembly (14). Fit the washer (16) smeared with miscible grease (Amber Technical or equivalent).

114. Lightly engage the shaft (23) to hold the washer (16) in place. Fit the washer (21) smeared with miscible grease. Centre the compound pinion assembly (14).




Fig. 15




Fig. 16




Fig. 17



6D01.12

Rear axle - Inter<sup>te</sup> shaft - Driv<sup>ing</sup> pinion - PTO brake

115. Fit the shaft (23) finally in the pinion assembly (14) and in the fork (26), ensuring that the hole of the screw (22) is properly positioned.
116. Smear the screw (22) with Loctite 542. Fit and tighten to a torque of 28-43 Nm.
117. Clean the joint face of the top link support.
118. Smear the joint face of the housing with a sealing compound (Loctite 510 or equivalent).
119. Ensure that the cup (8) is present. Fit the top link support with the bolts (3) and tighten to a torque of 130-170 Nm (Fig. 10).
120. Reconnect the tubes (1) and (4) (Fig. 10).
121. Fit the locking screw (24) and the nut (25). Adjust the fork (26), carry out operation 92.
122. Refit the lift cover.  
Carry out operations 53 to 57, chapter 6B01. Reverse operation 7, chapter 6B01. Carry out operations 64 to 69, 71, 72 and 84, chapter 6B01.
123. Adjust the economy PTO control.  
Carry out operations 127 and 132 to 137.
124. Adjust the shiftable PTO control.  
Carry out operations 47 and 52 to 58, chapter 6E02.
125. Check the operation of the PTO and its brake.
126. Check for leaks:  
at the joint faces (spool valve support, top link support)  
at the hydraulic connectors.




Fig. 18




Fig. 19

### E. Adjustment of PTO control 4 speed economy

**Note: Operations 128 to 131 must be carried out when replacing the control cable.**

127. Set the control lever L to the «Economy 1550 rpm» position.
128. Screw the clevis (1) until it reaches the end of the threaded part of the cable (6) (Fig. 18).
129. Mount the clevis (1) on the lever with the clip (7). Tighten the nut (2).
130. Adjust the outer cable stop (5), with the nut (3) reaching the end of the threaded part.
131. Tighten the nut (4).

**Note: Check that the cable is not constrained.**

132. Set the lever M to the «Economy 1550 rpm» position (Fig. 19) (coupler engaged towards the rear, fork locked).

133. Screw the clevis (7) until it reaches the threaded part of the cable (1).
134. Fit the clevis (7) on the lever M with the clip (6). Tighten the nut (5).
135. Adjust the outer cable stop (4), ensuring that the lever M is still locked.
136. Tighten the nuts (2) and (3).  
**Note: After tightening, check that the cable is not subject to any constraint.**
137. Check the locking of the control in the «2000 rpm» position.



**Rear Axle - Removable PTO shaft**

**6 E01 Removable PTO shaft**

CONTENTS

- General	2
A. Replacement of 540 or 1000 rpm shaft	5
B. Removal and refitting of rear cover	5
C. Disassembly and reassembly of rear cover	6
D. Disassembly and reassembly of 540 and 1000 rpm gear and of front bearing	7



6E01.2

## 3000/3100 SERIES TRACTORS



# Rear Axle - Removable PTO shaft

### General

The driven gears **(5)** and **(6)** are fitted on the PTO shaft situated in the lower rear part of the axle housing. These gears constantly engage with the driving compound gear which is driven by the upper shaft whose movement is transmitted by the PTO clutch.

The PTO shaft **(10)** is fitted at the front on a roller bearing **(1)** force-fitted in the axle housing and at the rear on a hub **(9)** turning on a roller bearing **(15)**.

It has 6 splines in the 540 rpm version and 21 splines in the 1000 rpm version.

In the 540 rpm configuration, the gear **(5)** is driven through the splines of shaft **(10)**. The gear **(6)** and bush **(4)** assembly runs idle on the shaft **(10)**.

In the 1000 rpm configuration, the gear **(6)** is driven via the splines of shaft **(10)**. The gear **(5)** and shaft **(3)** assembly runs idle on the shaft **(10)**.

The snap ring **(20)** holds the shaft in place.


Sealing is provided by the seal **/14\** or **/14A\** and the O-rings **(11)** and **(19)**. The deflector **(13)** ensures protection against foreign material.

### Parts list

- (1)** Roller bearing
- (2)** Deflector
- (3)** Bush
- (4)** Bush
- (5)** 540 rpm gear
- (6)** 1000 rpm gear
- (7)** Circlip
- (8)** Snap ring
- (9)** Hub
- (10)** 540 or 1000 rpm p.t.o. shaft
- (11)** O-ring
- (12)** Cover
- (13)** Deflector
- /14\** Sealing ring
- /14A\** Reinforced sealing ring
- (15)** Roller bearing
- (16)** Bolt
- (17)** PTO speed sensor
- (18)** Nut
- (19)** O-ring
- (20)** Snap ring



# Rear Axle - Removable PTO shaft








6E01.4

3000/3100 SERIES TRACTORS



# Rear Axle - Removable PTO shaft





## Rear Axle - Removable PTO shaft

### A. Replacement of 540 or 1000 rpm shaft

#### Disassembly (Fig. 1)

1. Raise rear of tractor to avoid oil spillage.
2. Remove snap ring (20).
3. Withdraw shaft (10).
4. Remove O-ring (11) and discard it.

#### Reassembly

5. Fit a new O-ring (11).
6. Clean and refit shaft (10).
7. Refit snap ring (20) and lower rear of tractor.




Fig. 1

### B. Removal and refitting of rear cover

#### Removal

8. Partially drain the rear axle housing. Remove two diametrically opposed bolts (16) (Fig. 2).
9. Screw two guide studs (Fig. 2) against the gear (6). The purpose of this is to hold the gears (5) and (6) in line when removing the shaft (10) and the rear cover assembly (Fig. 3).
10. Remove the other two bolts (16) (Fig. 2).
11. Withdraw the shaft and bearing assembly (Fig. 4).

#### Refitting

12. Mount the shaft and rear bearing assembly (Fig. 4).




Fig. 2




Fig. 3




Fig. 4



6E01.6

## Rear Axle - Removable PTO shaft

13. Smear Loctite 542 on two bolts (16) then tighten to a torque of 105 - 120 Nm.
14. Remove the two guide studs.
15. Smear Loctite 542 on the other two bolts (16) then tighten to a torque of 105 - 120 Nm.
16. Top up the oil level of the rear axle housing.

### C. Disassembly and reassembly of rear cover

Remove the rear bearing by carrying out operations 8 to 11.

#### Disassembly

17. Remove O-ring (19).
18. Remove snap ring (20).
19. Separate the shaft (10) from the bearing assembly.
20. Remove O-ring (11).
21. Remove circlip (7).
22. Separate the cover (12) from the roller bearing (15).
23. Remove snap ring (8).
24. Extract the roller bearing (15) from the hub (9).
25. Dismantle :
  - version a : the sealing ring /14\ and the deflector (13).
  - version b : the reinforced sealing ring /14A\.

#### Reassembly



##### Version a (Fig. 5)

26. Using a press and a suitable device, fit the deflector (13) against the shoulder of the cover (12).
- Note: Assemble in the correct way.**
27. Using a press and a suitable device, fit the sealing seal ring /14\ flush with the chamfer of the cover (12) with the lip facing towards the bearing (15).

##### Version b (Fig. 6)

Depending on the option, a reinforced sealing ring /14A\ is fitted in place of the seal /14\ and deflector (13). Smear Loctite 542 on the exterior of the sealing ring and using a suitable device, fit it against the shoulder of the cover (12). The double lip should face towards the bearing (15).

28. Reverse operations 17 to 24 and refit the rear bearing assembly by carrying out operations 12 to 15.





## Rear Axle - Removable PTO shaft

### D. Disassembly and reassembly of 540 or 1000 rpm gear and of front bearing

#### Disassembly

To disassemble gears (5) and (6) it is necessary to remove :

- The lift cover by carrying out operations 1 to 11, chapter 6 B01.

- The top link support, the driving gear and the intermediate shaft by carrying out operations 4 to 7, chapter 6 D01.A.

29. In order to gain access to the sensor, remove the left cylinder by dismantling the lower fastening and disconnecting the supply hose.

Remove the PTO sensor (Autotronic - Datatronic).

30. Remove the rear cover assembly by carrying out operations 8 to 11.

31. Remove the gears (5) and (6).

32. Extract the bearing (1) and the deflector (2).

#### Reassembly

33. Clean and check the parts. Replace those which are defective.

34. Smear Loctite 648 on the face of the deflector (2) which meets the housing and place it in its hole. Position so that the aperture faces upward (Fig. 7).

35. Fit the roller bearing (1) in the housing abutting on the deflector (2).

36. Lubricate the bushes (3) and (4).

37. Refit the gears (5) and (6) and screw two guide studs against the gear (6). The purpose of this is to hold the gears in line (Fig. 3) when refitting the rear cover assembly.

**Note: If the bushes (3) and (4) are damaged, replace the gears (5) and (6).**

38. Refit the rear cover assembly by carrying out operations 12 to 15.

39. Smear Loctite «Form A gasket 2» (sensor sealing or equivalent) on the thread of the PTO sensor. Fit and adjust the sensor:


a) Screw the sensor fully in, without forcing it, so that it is in contact with the gear (6).

b) Unscrew the sensor 3/4 of a turn.

c) Tighten the nut (18) moderately and connect the harness.

Refit the LH cylinder, reassemble the lower fastening and reconnect the supply hose.

Refit the driving gear with the intermediate shaft and the top link support.



40. Carry out operations 9 to 13, chapter 6 D01 (2 speeds).

Refit the lift cover.

41. Carry out operations 53 to 57, chapter 6 B01.

42. Reverse operation 7, chapter 6 B01.

43. Carry out operations 64 to 69, chapter 6 B01.

44. Carry out operations 71, 72 and 84, chapter 6 B01.

45. Top up the oil level of the rear axle housing.

46. Check the operation of the p.t.o. and its brake.

47. Check for leaks:

- of the joint faces (Auxiliary spool valve support, top link support, PTO rear cover assembly, lift cover)

- of the hydraulic fittings.



**Rear Axle - Shiftable PTO shaft**

**6 E02 Shiftable PTO shaft**

**CONTENTS**

- General .....	2
A. Removal and refitting rear cover .....	5
B. Disassembly and reassembly of rear cover .....	5
C. Disassembly and reassembly of 540 and 1000 rpm gear and of the front roller bearing of the shaft .....	7
D. Adjustment of control cable .....	9



6 E02.2

## 3000/3100 SERIES TRACTORS



# Rear Axle - Shiftable PTO shaft

### General

The driven gears **(4)** and **(7)** are fitted on the p.t.o. shaft **(13)** situated in the lower rear part of the axle housing. These gears constantly engage with the driving compound gear which is driven by the upper shaft whose movement is transmitted by the p.t.o. clutch.

The p.t.o. shaft is fitted free in the roller bearing **/2\** and is force-fitted in the roller bearing **(10)** which are fitted in the axle housing and in the cover **(14)** respectively. The hub coupler **(6)** is driven by the splined shaft **(13)**. The gears **(4)** and **(7)** drive the shaft when the coupler **(5)** is moved towards the front (540 rpm) or the rear (1000 rpm). When one of the gear **(4)** or **(7)**, equipped with bushes **(19)** and **(20)** respectively, is passive, it rotates either on the bush **/3\** or on the shaft **(13)**.

A fork **(25)** fitted on a selector rail **(22)** enables speed selection (540 or 1000 rpm).

Sealing is by means of a seal **/11\** or **/11A\** and the O-ring **(18)**. The deflector **(12)** ensures protection against foreign material.

### Lubrication of gears **(4)** and **(7)**


The two gears are lubricated by the transmission oil. The roller bearing **/2\** has a sealed face oriented towards the 540 rpm gear. The gears are lubricated via the deflector **(1)** and the shaft **(13)** which has an axial channel and radial holes.

### Parts list

- (1)** Deflector
- /2\** Roller bearing
- /3\** Bush
- (4)** 540 rpm gear
- (5)** Coupler
- (6)** Hub
- (7)** 1000 rpm gear
- (8)** Circlip
- (9)** Retainer ring
- (10)** Roller bearing
- /11\** Seal
- /11A\** Reinforced seal
- (12)** Deflector
- (13)** PTO shaft
- (14)** Cover
- (15)** Screw
- (16)** Sensor
- (17)** Nut
- (18)** O-ring
- (19)** Bush
- (20)** Bush
- (21)** Lever
- (22)** Selector rail
- (23)** O-ring
- (24)** Pad
- (25)** Fork
- (26)** Set screw
- (27)** Pad
- (28)** Plug



# Rear Axle - Shiftable PTO shaft






6 E02.4

3000/3100 SERIES TRACTORS



# Rear Axle - Shiftable PTO shaft

Exploded







## Rear Axle - Shiftable PTO shaft

### A. Removal and refitting of rear cover

#### Disassembly

1. Partially drain the rear axle housing.
2. Place the coupler (5) on the gear (7).
3. Remove two diametrically opposed screws (15) (Fig. 1).
4. Screw two guide studs against the gear (7). The purpose of this is to hold the gear (4) and (7) (Fig. 2), the hub and the coupler in line when removing the shaft (13) and the cover assembly.
5. Remove the other two bolts (15).
6. Withdraw the shaft and cover assembly (Fig. 3). Discard the O-ring (18).

#### Refitting

7. Replace the O-ring (18). Fit the shaft and cover assembly (Fig. 3).
8. Smear Loctite 542 on two screws (15) then tighten to a torque of 105 - 120 Nm.
9. Remove the two guide studs.
10. Smear Loctite 542 on the other two screws (15) then tighten to a torque of 105 - 120 Nm.
11. Top up the oil level of the rear axle housing.




Fig. 1




Fig. 2

### B. Disassembly and reassembly of rear cover

Remove the rear cover by carrying out operations 1 to 6.

#### Disassembly

12. Remove O-ring (18).
13. Remove circlip (8).
14. Separate the cover (14) from the roller bearing (10).
15. Remove the retainer ring (9).
16. Extract the roller bearing (10) from the shaft (13).
17. Remove :
  - Version a : the seal /11\ and the deflector (12).
  - Version b : the reinforced seal /11A\.




Fig. 3



6 E02.6



## Rear Axle - Shiftable PTO shaft

### Reassembly

#### Version a (Fig. 4)

18. Using a press and a suitable device, fit the deflector (12) against the shoulder of the cover (14).

**Note: Assemble in the correct direction.**



19. Using a press and a suitable device, fit the seal /11\ flush with the chamfer of the cover (14) with the lip facing towards the roller bearing (10).

#### Version b (Fig. 5)

Depending on the option, a reinforced seal /11A\ is fitted in place of the seal /11\ and deflector (12).

Smear Loctite 542 on the exterior of the seal and using a suitable device, fit it against the shoulder of the cover (14) (Fig. 12). The double lip should face towards the roller cover (10).

20. Reverse operations 12 to 16 and refit the rear cover by carrying out operations 7 to 10.





## Rear Axle - Shiftable PTO shaft

### C. Disassembly and reassembly of 540 and 1000 rpm gears and of the front roller bearing of the shaft

#### Disassembly

To disassemble gears (4) and (7) it is necessary to remove:

- the lift cover by carrying out operations 1 to 11, chapter 6 B01.

- the top link support and the driving gear by carrying out operations 63 to 76, chapter 6 D01.

21. In order to gain access to the sensor, remove the left-hand lift cylinder by removing the lower fastening and disconnecting the supply hose. Remove the sensor (Autotronic - Datatronic).

22. Unscrew the set screw (26).

23. Remove the selector rail (22) with the lever (21) towards the left-hand side of the tractor. Discard the O-ring (23).

**Note: The plug (28) remains in the housing.**

24. Withdraw the fork (25) with the pads (24) and (27), taking care not to drop them into the housing.

25. Remove the rear cover assembly by carrying out operations 1 to 6.

26. Remove the hub (6) with the coupler (5), the gears (4) and (7) and the bush (3).

27. Extract the roller bearing (2) and the deflector (1).

#### Reassembly

28. Clean and check the parts. Replace those which are defective.

29. Smear Loctite 648 on the face of the deflector (1) which meets the housing and place it in its hole. Position the aperture upwards (Fig. 6).

30. Fit the roller bearing (2) in the housing against deflector (1) (Fig. 6).

**Note: Place the sealed part of the roller bearing towards the gear (4).**

31. Using a jet of compressed air, ensure that the channel of the shaft (13) is not obstructed. Lubricate bushes (19) and (20). Refit the gears (4) and (7), the coupler (5) with the hub (6), the bush (3) with the toothed opening facing towards the rear of the tractor (Fig. 7).

**Note: If the bushes (19) and (20) are damaged, replace the gears (4) and (7).**

32. Engage the coupler (5) with the gear (7). Screw two guide studs against the gear (7). The purpose of this is to hold the gears in line (Fig. 2), when refitting the rear bearing assembly.




Fig. 6




Fig. 7

33. Refit the rear cover assembly by carrying out operations 7 to 10.

34. Smear Loctite 577 (sensor sealing or equivalent) on the thread of the PTO sensor (16). Fit and adjust the sensor:

a) Without forcing screw the sensor in contact with the gear (7).

b) Unscrew the sensor 3/4 of a turn.

c) Tighten the nut (17) moderately and connect the harness.

35. Refit the fork (25) with the pads (24) and (27), held on the fork by two spots of miscible grease (Amber Technical or equivalent).

36. Fit a new O-ring (23). Fit the selector rail (22) with lever (21).







6 E02.8



## Rear Axle - Shiftable PTO shaft

37. Smear Loctite 221 on the screw (26). Fit and tighten. Manually check the operation of the fork. Refit the left-hand lift cylinder. Reassemble the lower fastening and reconnect the supply hose.
  38. Refit the driving gear and the top link support. Carry out operations 82 to 92, chapter 6 D01.
  39. Refit the lift cover. Carry out operations 53 to 57, chapter 6 B01.
  40. Reverse operation 7, chapter 6 B01.
  41. Carry out operations 64 to 69, 71, 72 and 84, chapter 6 B01.
  42. Adjust the p.t.o. control (4 speeds), carry out operations 127 and 132 to 137, chapter 6D01.
  43. Adjust the shiftable p.t.o. control, carry out operations 47 and 52 to 58, section D.
  44. Top up the oil level of the rear axle housing.
  45. Check the operation of the PTO and its brake.
  46. Check for leaks:
    - of the joint faces (spool valve support, 3rd point support, PTO rear cover assembly, lift cover)
    - of the hydraulic fittings.
- Note: On tractors equipped with a shiftable PTO, there are two types of control:**
- a) internal control via cable (Figs. 8 and 9).
  - b) external control (depending on option) (Figs. 10 and 11).





## Rear Axle - Shiftable PTO shaft

### D. Adjustment of control cable

**Note: Operations 48 to 51 must be carried out when replacing the control cable.**

47. Set the U-lever to the «1000 rpm» position.
48. Screw the clevis (1) until it reaches the end of the threaded part of the cable (6) (Fig. 12).
49. Fit the clevis (1) on the U-rod with the clip (7). Tighten the nut (2).
50. Adjust the outer cable stop (5), with the nut (3) reaching the end of the threaded part.
51. Tighten the nut (4).
- Note: Check that the cable is not constrained.**
52. Set the lever V to the «1000 rpm» position (Fig. 13).
53. Screw the clevis (6) until it reaches the threaded part of the cable (4).
54. Temporarily fit the clevis (6) on the lever V with the clip (7).
55. Adjust the outer cable stop (1), ensuring that the lever V is still in the «1000 rpm» position.
56. Tighten the nuts (2) and (3).
57. Set the adjustment with the clevis (6), tighten the nut (5).
- Note: After tightening, check that the cable is not subject to any constraint in the 1000 rpm and 540 rpm positions.**
58. Check the operation of the control in the «540 rpm» position.




Fig. 12




Fig. 13



**Rear Axle - GSPTO**

**6 F01 Ground speed Power take-off**

CONTENTS

- General	2
A. Disassembly of power take-off (2WD version)	7
B. Reassembly of power take-off (2WD version)	9
C. Disassembly of power take-off (4WD version)	11
D. Reassembly of power take-off (4WD version)	12
E. Adjustment of control	13



6F01.2

# Rear Axle - GSPTO

## General

3000/3100 series tractors can be equipped with a ground speed power take-off .

Unlike the independent p.t.o. system or the p.t.o. system which depends on the engine speed, the ground speed p.t.o. is driven by the driving pinion, and the speed of the p.t.o. shaft is proportional to the speed of the tractor.

## Operation

The bevel drive pinion comprises a gear (31) which constantly engages either with the pinion (16) (2WD - page 4) or with the transfer gear (33) (4WD - page 3). The shaft (18) (2WD) or the shaft (32) (4WD) can be made to rotate with the shaft (8) by means of the coupler (10). The pinion (3) mounted at the end of the shaft (8) drives the 540 rpm gear of the rear power take-off shaft.

The coupler (10) is moved by a finger fixed on a pin mounted at the bottom left of the rear axle housing and controlled by a connecting rod and a cable activated by a lever in the cab.

## Parts list

	2WD	4WD
(1) Plug	•	•
(2) Circlip	•	•
(3) Pinion	•	•
(4) Circlip	•	•
(5) Ball bearing	•	•
(6) Circlip	•	•
(7) Circlip	•	•
(8) Shaft	•	•
(9) Circlip	•	•
(10) Coupler	•	•
(11) Screw	•	•
(12) Cover	•	•
(13) Needle roller bearing	•	•
(14) Bearing cup	•	
(15) Bearing cone	•	
(16) Gear	•	
(17) Circlip	•	
(18) 2WD shaft	•	
(19) Bearing cone	•	
(20) Bearing cup	•	
(21) Shim(s)	•	
(22) Spacer	•	
(23) Circlip	•	
(24) Plug	•	
(25) Double pin	•	•
(26) Double pin	•	•
(27) Sleeve	•	•
(28) Sleeve	•	•
(29) Shaft	•	•
(30) Circlip	•	•
(31) Gear	•	•
(32) 4WD shaft		•
(33) Transfer gear		•




3000/3100 SERIES TRACTORS

### Rear Axle - GSPTO



6F01.3

General arrangement








6F01.4

3000/3100 SERIES TRACTORS



Rear Axle - GSPTO

General arrangement






# Rear Axle - GSPTO

Exploded diagram

4WD G.S. PTO.





6F01.6


3000/3100 SERIES TRACTORS



# Rear Axle - GSPTO

Exploded diagram

2WD G.S. PTO





## Rear Axle - GSPTO

### A. Disassembly of power take-off (2WD version)





1. Immobilise the tractor. Drain the transmission oil.
2. Remove the screws (11).
3. Remove the cover (12).

**Note: Save the spring (3) (Fig. 1).**

4. Remove the retaining tube (4) for the control pivot (7) and the locking plunger (2) (Fig. 1).
5. Disconnect the control cable (1) and remove the control pivot (7) (Fig. 2).

**Note: The finger (1) is force-fitted in the control pivot (Fig. 1).**

6. Remove the O-ring (5) (Fig. 1).
7. Remove the drawbar.
8. Extract the plug (1) (Fig. 3).
9. Remove the circlip (2).
10. Withdraw the pinion (3) (Fig. 4).





6F01.8



# Rear Axle - GSPTO

11. Remove the circlip (4) with long-nose pliers (Fig. 5).
12. Withdraw the shaft (8) with the ball bearing (5), then remove the coupler (10).  
**Note: If it is unnecessary to remove the circlip (7), leave it in the housing.**
13. Remove the circlips (6) and (9).
14. Extract the ball bearing (5) with a press.
15. Extract the plug (24).
16. Remove the circlip (23) and the spacer (22).
17. Remove the shims [21].
18. Remove the cup (20).
19. Withdraw the shaft (18) assembled with the bearing cone (19) and the circlip (17), while holding the gear (16).
20. Remove the gear (16) and the bearing cone (15).
21. Extract the cone (19) and remove the circlip (17) from the shaft (18).  
**Note: Keep the cones and the cups paired if they are to be reused.**  
**The roller bearing (13) is pressed in to the shaft (18).**
22. Extract the cup (14) with a suitable extractor.

**If removing the gear (31) it is necessary to remove the right-hand hydraulic cover.**

23. Immobilise the tractor.
24. Apply the handbrake.
25. Lift the tractor with a jack.
26. Put a prop in position.
27. Remove the wheel.
28. Remove the right hydraulic cover.  
Carry out operations 2 to 14, chapter 8I01.

### Tractors without creeper gears

29. Drive the double pins (25) and (26) from the sleeves (27) and (28).
30. Slide the sleeves towards one another on the shaft (29).
31. Detach the shaft and sleeve assembly.
32. Remove the circlip (30).
33. Detach the gear (31).  
**Note: On 2WD tractors (without G.S. PTO) the gear (31) is omitted but the circlip (30) must remain in place.**




Fig. 5

### Tractors with creeper gears

34. Remove the fork, the sleeve assembly, the connecting shaft and the coupler. Carry out operations 3 to 8 in chapter 5D01.A.
35. Carry out operations 13 to 16 in chapter 5D01.A.
36. Remove the circlip (30).
37. Remove the gear (31).



## Rear Axle - GSPTO

### B. Reassembly of power take-off (2WD version)

38. Clean and check the parts, replacing any which are defective.

**If carrying out work on the gears (31).**

**Tractors with creeper gears**

39. Refit the gear (31).

40. Refit the circlip (30).

41. Reattach the fork, the sleeve assembly, the connecting shaft and the coupler. Carry out operations 22 to 31 in chapter 5D01.A.

**Tractors without creeper gears**

42. Refit the gear (31).

43. Refit the circlip (30).

44. Refit the assembly (connecting shaft and sleeves), then position the sleeves (27) and (28) on the shaft (29).

45. Mount the double pins (26) and (25) on the sleeves.

**Note: Position the grooved end of the sleeve (28) towards the rear of the tractor (Fig. 6). Replace the pins. The long pin is fitted into the sleeve (27).**

**Tractors with or without creeper gears**

46. If necessary, refit the right hydraulic cover.

Carry out operations 15 to 27, chapter 8I01.

47. Push the cup (14) as far as it will go against the shoulder of the housing.

48. Push the bearing cone (19) on the shaft (18) as far as it will go against the shoulder using a press and a suitable device, then position the circlip (17).

49. Check that the needle roller bearing (13) is present.




Fig. 6

50. In order to be able to turn the shaft to carry out spacing J1, do not mount the gear (16).

Position the cone (15). Fit the shaft (18) assembled with the cone (19) and the circlip (17).

51. Refit the cup (20), the spacer (22) and the circlip (23).

**Note: To obtain correct shimming, ensure that the spacer moves freely in the bore of the housing.**

52. Carry out shimming on the shaft (18) so as to obtain:

**J1 = 0 to +0.10**

53. Place the tip of the dial gauge against the spacer (22) (Fig. 7).







Fig. 7




6F01.10

## Rear Axle - GSPTO

54. Through the opening in the cover (12), pull on the shaft, turning it back and forth, in order to seat the bearing cones correctly in the cups.
55. Set the dial gauge to zero.
56. Repeat the operation while pushing the shaft.
57. Select the necessary thickness of shims to provide J1.
58. Remove the circlip (23) and the spacer (22). Withdraw the shaft (18) assembled with the bearing cone (19) and the circlip (17) while holding the bearing cone (15). Refit the gear (16) the shaft (18) and the cup (20).
59. Apply two spots of grease to the shims [21] selected in operation 57 and place them against the cup (20).
60. Fit the spacer (22) and the circlip (23).
61. Clean the plug (24) and its recess in the housing.
62. Smear the edge of the plug with Loctite 542, then push it in.
63. Place the coupler (10) on the shaft (18).  
**Note: Position the small shoulder E towards the shaft (18) (Fig. 8).**
64. Fit the circlips (6) and (9) on the shaft (8).
65. Using suitable equipment, press the ball bearing (5) on to the shaft (8), until it contacts the circlip (6).
66. Check that the circlip (7) is present.
67. Mount the assembled shaft (8) in the housing (Fig. 9).
68. Mount the circlip (4).
69. Fit the pinion (3).
70. Mount the circlip (2) (Fig. 10).
71. Check the movement of the coupler (10) through the opening in the cover (12).
72. Clean the plug (1) and the bore in the housing.
73. Smear the plug with Loctite 542, then push it so that it is slightly recessed from the face of the housing.
74. Mount the control pivot (7) (equipped with a new O-ring (5), placing the finger (1) in the groove of the coupler (10) (Fig. 1).
75. Clean and degrease the joint faces (cover and housing).
76. Smear the joint face of the cover with a sealing compound (Master Joint 510 or equivalent).
77. Screw two guide studs in opposite positions into the housing.
78. Mount the retaining tube (4) for the control pivot, the locking plunger (2) and the spring (3) (Fig. 1).
79. Refit the cover (12).





## Rear Axle - GSPTO

80. Remove the guide studs. Fit and tighten the screws to a torque of 130 - 170 Nm.
81. Reconnect the G.S. PTO control cable (1) (Fig. 2).
82. Adjust the control.  
Carry out operations 114 to 120.

**If the right hand hydraulic cover has been removed, carry out operations 83 to 85.**

83. Lift the tractor with a trolley jack.
84. Refit the wheel. Remove the prop and the jack.
85. Tighten the wheel nuts to a torque of 400 - 450 Nm.
86. Replenish transmission oil.
87. Refit the drawbar. (For tractors equipped with an automatic hook, check its operation. If adjustment should prove to be necessary, carry out operations 1 and 6 to 19, chapter 6M01.)
88. Check the operation of the GSPTO.
89. **Check for leaks:**
  - . at the joint faces
  - . at the cover under the rear axle housing.
  - . at the right hydraulic cover (if removed)
  - . at the hydraulic connectors

91. Lift the tractor with a jack. Put a prop in position. Remove the wheel. Remove the right hydraulic cover.
92. Carry out operations 2 to 14, chapter 8I01.

### Tractors without creeper gears

93. Drive the double pins (25) and (26) from the sleeves (27) and (28).  
**Note: If the double pins are not accessible, carry out operations 9 to 12, chapter 5D01.A.**
94. Slide the sleeves towards one another on the shaft (29).
95. Remove the assembly (shaft and sleeves).
96. Remove the circlip (30) and the gear (31).

### Tractors with creeper gears

97. Remove the fork, the sleeve assembly, the connecting shaft and the coupler. Carry out operations 3 to 8 and 13 to 16, chapter 5D01.A.
98. Remove the circlip (30) and the gear (31).

---

## C. Disassembly of power take-off (4WD version)

---

90. Carry out operations 1 to 14.

**Should it prove necessary to carry out work on the 4WD clutch assembly, on the bearing cones and cups, on the shaft and the needle roller bearing, refer to chapter 7A01.**

**If removing the gear (31) it is necessary to remove the right hand hydraulic cover.**





6F01.12

## Rear Axle - GSPTO

### D. Reassembly of power take-off (4WD version)

99. Clean and check the parts, replacing any which are defective.

**If carrying out work on the gear (31).**

**Tractors with creeper gears**

100. Refit the gear (31) and refit the circlip (30).

101. Refit the fork, the sleeve assembly, the connecting shaft and the coupler. Carry out operations 22 to 31 in chapter 5D01.A.

**Tractors without creeper gears**

102. Refit the gear (31) and refit the circlip (30).

103. Refit the assembly (connecting shaft and sleeves), then position the sleeves (27) and (28) on the shaft (29).

104. Fit two new double pins (25) and (26) on the sleeves.

**Note : Position the grooved end of the sleeve (28) towards the rear of the tractor (Fig. 11).**

**The long double pin is fitted in to the sleeve (27).**

**Tractors with or without creeper gears**

105. If necessary, refit the right hand hydraulic cover. Carry out operations 15 to 27, chapter 8I01.

**If the 4WD clutch assembly, the bearing cones and cups, the shaft and the needle roller bearing have been disassembled, refer to chapter 7A01 for reassembly.**

**If necessary, carry out operations 9 to 12, chapter 5D01.A in reverse.**

106. Place the coupler (10) on the shaft (32).

**Note : Position the small shoulder E towards the shaft (32) (Fig. 12).**

107. Carry out operations 64 to 82.

**If the right hand hydraulic cover has been removed, carry out operations 83 to 85.**

108. Carry out operations 86 to 88.

109. **Check for leaks:**

- . at the joint face of the cover under the rear axle housing
- . at the right hydraulic cover (if removed)
- . at the hydraulic connectors.




Fig. 11




Fig. 12



## Rear Axle - GSPTO

### E. Adjustments of control

**Note: Carry out operations 110 to 113 when replacing the control cable.**

110. Screw the clevis (1) on to the end of the threaded part of the cable (7) (Fig. 13).
111. Mount the clevis (1) on the selector lever U with the clip (8). Tighten the nut (2) (Fig. 13).
112. With the inner cable (7) extended the outer cable end (5) (Fig. 13) is to be positioned in support (6) so that selector lever U has a neutral dimension of 105 mm between the clevis hole (1) and the support (6).
113. Tighten the nut (4).  
**Note: Check that the cable is not restricted.**
114. Place the selector lever U in the «engaged» position (Fig. 14).
115. Place the control pivot V in the «engaged» position (Fig. 15).  
**Note: Make sure that the control pivot V is fully engaged.**
116. Screw the clevis (6) on to the threaded part of the cable (4) (Fig. 15).
117. Fit the clevis (6) on control pivot V with the clip (5). Tighten the nut (7).
118. Adjust the outer cable stop (1) with the nut (3), ensuring that the control pivot V is still in the «engaged» position.
119. Tighten the nut (2).  
**Note: After tightening, make sure that the cable operates freely to the «disengaged» and «engaged» positions (Fig. 15).**
120. Check the operation of the control in the «disengaged» position.




Fig. 13




Fig. 14




Fig. 15



**Rear axle - PTO clutch**

**6 G01 Power take-off clutch**

**CONTENTS**

- General	2
- Operation	2
A. Removal and refitting of PTO clutch (2-speed version)	7
B. Removal and refitting of PTO clutch (4-speed version)	7
C. Disassembly and reassembly of clutch (Valeo make)	8
D. Disassembly and reassembly of clutch (M.F. make)	10
E. Service tool	12



6 G01.2



# Rear axle - PTO clutch

## General

The power-take-off clutch, fitted at the front of the rear axle housing, is driven by a shaft traversing the primary shaft of the gearbox, the speedshift, the reverse shuttle and the layshaft. This shaft is connected via splines to a sleeve fixed on the engine flywheel.

The clutch assembly, Valeo version, is composed of the following principal components :

- A housing (9) supported by two ball bearings (2) and (7) separated by a sleeve (4) centred in a hole in the centre housing. The housing contains a shaft supported by the ball bearing (23) in the hub (24).
- A piston (11) sliding inside the housing.
- A set of inner plates (16) and outer plates (15).
- A driving hub (24).
- A cover (20).

The housing has exterior helical teeth which drive the gear of the hydraulic pump. The roller bearings and the plates are lubricated.

A new clutch made by MF operating in an identical manner is now fitted on 3000 and 3100 tractors. The clutch has 3, 4 or 5 plates, depending on the version.

### Version without PTO (Fig. 1)

On tractors without PTO, an assembly comprising a driving gear (1) and sleeve (2) (see diagram) replaces the PTO clutch. The sleeve is smeared with Loctite 648 and is inserted in the gear by a press.

On the right cover, the solenoid valves of the PTO and of the PTO brake are replaced with plugs.

The PTO brake feeder tube is absent.

The PTO speed sensor is replaced with a plug.

The top link support has 2 plugs mounted on the lubrication and brake ducts of the PTO

A cover plate (fitted using Loctite 510 or equivalent) replaces the rear cover assembly.

The lubrication tube of the gear driving the PTO is absent. A right-angled connector replaces the T-connector.

## Operation


### PTO engagement

The clutch is fed by the 17 bar hydraulic circuit through the PTO solenoid valve situated on the right side cover. The oil enters the support housing (9) through channels a, b and c. It pushes the piston (11) which presses the outer plates (15) against the inner plates (16). The outer plates (15) have lugs which are driven by the clutch housing (17) and the inner plates (16) drive the hub (24), which is splined to the intermediate shaft which is in turn splined to the PTO compound gear. At the same time the pressure which was acting on the PTO brake piston is cut off, enabling the 540 and 1000 rpm gears to turn freely. When the clutch is engaged, the plates are cooled and lubricated.

### PTO braking

When the supply is cut off, the spring pushes the piston against the housing (9).

At the same time, the solenoid valve for the PTO brake directs the oil to the PTO brake situated in the top link support. The pressure acts on a piston which supports the cup on the rear taper roller bearing, progressively stopping the driving gear.





# Rear axle - PTO clutch

6 G01.3

General arrangement of Valeo clutch




Fig. 2



6 G01.4

3000 / 3100 SERIES TRACTORS



# Rear axle - PTO clutch

Exploded view - Valeo clutch





Fig. 3



### Rear axle - PTO clutch

Fig. 4

General arrangement of M.F. clutch



- |                        |                     |                                  |
|------------------------|---------------------|----------------------------------|
| (1) Circlip            | (13) Retainer       | (19) Spring seat                 |
| (2) Ball bearing       | (14) Outer plate    | (20) Securing ring               |
| (3) O-ring             | A : 3-plate clutch  | (21) Hub                         |
| (4) Sleeve             | B : 4-plate clutch  | (22) Ball bearing                |
| (5) Seal rings         | C : 5-plate clutch  | (23) Washer                      |
| (6) O-ring             | (15) Clutch housing | (24) Screw                       |
| (7) Ball bearing       | (16) Bolt           | (25) O-ring                      |
| (8) Valve              | (17) Inner plate    | (26) O-ring                      |
| (9) Support housing    | A : 3-plate clutch  | (27) Sleeve                      |
| (10) Piston            | B : 4-plate clutch  | (28) Spacer, 3- and 4-plate type |
| (11) O-ring            | C : 5-plate clutch  | (29) Spacer, 3-plate type        |
| (12) Belleville washer | (18) Spring         | (30) Pins                        |



6 G01.6

3000 / 3100 SERIES TRACTORS



# Rear axle - PTO clutch

Exploded view - M.F. clutch




Fig. 5





## Rear axle - PTO clutch



### A . Removal and refitting of PTO clutch (2-speed version)

#### Removal

1. Remove the left side cover. Carry out operations 1 to 6, chapter 8 I02.
2. Remove the top link support, the compound gear and the intermediate shaft. Carry out operations 1 to 7, chapter 6 D01.
3. Remove the retaining screw (3) of the clutch (1). Remove the clutch and the spring (5) (Fig. 6).

#### Refitting

4. Clean and check the parts. Replace those which are defective.
5. Check that the O-rings (2) and (4) (Fig. 6) have not deteriorated.
6. Place the spring (5) (Fig. 6) in the hollow clutch shaft and refit the clutch, pushing it as far as possible with a lever (Fig. 7) so as to compress the spring in order to fit the screw (3) (Fig. 6).
7. Clean the screw and smear it with Loctite 221 and tighten it with a ring spanner (Fig. 6).
8. Refit the intermediate shaft, the compound gear and the top link support. Carry out operations 9 to 18, chapter 6 D01.
9. Replace the left cover. Carry out operations 7 to 19, chapter 8 I02.
10. Check the operation of the PTO clutch, the PTO brake and of the lift.
11. Check for leaks:
  - at the joint faces (spool valve support, top link support, left side cover)
  - at the hydraulic connectors.



### B. Removal and refitting of PTO clutch (4-speed version)

#### Removal

12. Remove the left side cover.  
Carry out operations 1 to 6, chapter 8 I02.  
**Note: A new assembly has been introduced without intermediate shaft sleeve (clutch outlet) on 3000 tractors as of serial number N342012.**  
**Serial numbers of tractors equipped with old assembly after introduction: N342017, N342018, N342022, N342026, N348023.**  
**For tractors equipped with old assembly, refer to workshop manual 1646640M1**

13. Remove the top link support, the compound gear and the intermediate shaft. Carry out operations 60 to 68 and 72 to 78, chapter 6 D01.
14. Remove the retaining screw (3) of the clutch (1). Remove the clutch and the spring (5) (Fig. 6).

#### Refitting

15. Clean and check the parts. Replace those which are defective.
16. Check that the O-rings (2) and (4) (Fig. 6) have not deteriorated.
17. Place the spring (5) (Fig. 6) in hollow clutch shaft and refit the clutch, pushing it as far as possible with a lever (Fig. 7) so as to compress the spring in order to fit the screw (3) (Fig. 6).



6 G01.8



## Rear axle - PTO clutch

18. Clean the screw and smear it with Loctite 221 and tighten it with a ring spanner (Fig. 6).
19. Refit the intermediate shaft, the compound gear and the top link support. Carry out operations 80 to 82 and 85 to 98, chapter 6 D01.
20. Replace the left cover. Carry out operations 7 to 19, chapter 8 I02.
21. Check the operation of the clutch, the PTO brake and of the hydraulic lift.
22. Check for leaks :
  - at the joint faces (spool valve support, top link support, left side cover)
  - at the hydraulic connectors.

### C. Disassembly and reassembly of clutch (Valeo make)

#### Disassembly

23. Place the clutch housing (9) in a vice (Fig. 8).
24. Remove the retaining ring (19) (Fig. 8) with vice grips.
25. Remove the cover (20) with the circlip (18), the outer plates (15) and the inner plates (16) (page 4).
26. Remove the O-rings (3) and (6).
27. Remove the circlip (1).
28. Extract the ball bearings (2) and (7) with the sleeve (4) (Fig. 9). Remove the sealing rings (5).
29. Hold the spring (21) with a locally manufactured tool (Fig. 10). For tool see page 12.
30. Remove the screw (25) and the washer (26).
31. Remove the hub (24), the spring seat (22), the spring (21), the retainer (14) and the Belleville washer (13).
32. Extract the ball bearing (23).
33. Take out the piston (11).
34. Remove the O-rings (10) and (27).

#### Reassembly

**Note:** The valves (12) are fitted in the piston (11) and the ball (28) in the support housing (9). The support and clutch (17) are fastened together by rivets (8).

35. Clean and check the parts. Replace those which are defective.




Fig. 8




Fig. 9




Fig. 10



## Rear axle - PTO clutch

36. Using a suitable device and a press, push the ball bearing (7) in as far as the shoulder (Fig. 11).
37. Place the seal rings (5) in their grooves. Ensure that they turn freely.
38. Slide the sleeve (4) over the rings, taking care not to damage them.

**Note: Position the larger diameter end of the sleeve towards the ball bearing (7).**

39. Using a suitable device and a press, push the ball bearing (2) in until it meets the shoulder of the support (9) (Fig. 12).
40. Fit the circlip (1).
41. Replace and lubricate the O-rings (10) and (27).
42. Lubricate the hole of the support housing (9) and the piston (11) and insert into the housing with a plastic mallet.

43. Fit the ball bearing (23) in the hub (24).
44. Refit the Belleville washer (13), the retainer (14), the spring (21), the spring seat (22) and the hub (24).
45. Compress the spring (21) with the tool (Fig. 10) (see section E). Fit the washer (26) and tighten the screw (25) smeared with Loctite 242 to a torque of 24 - 28 Nm.

**Note: Take care not to obstruct the lubricating hole with Loctite.**

46. Place the outer plates and the inner plates on the hub (24).

**Note: The clutch is equipped with 5 inner plates and 6 outer plates. Check that the plates slide freely on the hub.**

47. Fit the cover (20) with the circlip (18).




Fig. 11




Fig. 12




Fig. 13



6 G01.10



**Rear axle - PTO clutch**

48. Fit the retaining ring (19).

**Note :** *The retaining ring must be fitted between the cover (20) and the circlip (18) (Fig. 13). After fitting, bend back the end of the retaining ring (19) (Fig. 14).*

49. Manually check that the inner plates and outer plates do not bind together.

50. Lubricate and fit the O-rings (3) and (6).

**Note :** *The O-rings have different diameters.*

**D. Disassembly and reassembly of clutch (M.F. make)**

**Disassembly**

51. Remove the bolts (16).

52. Remove the clutch housing (15), the inner plates (17) and the outer plates (14).

**Note:** *The number of inner plates and outer plates varies according to the type of tractor.*

**Assembly A :** *3 inner plates, 3 outer plates and 2 spacers (28) and (29) for 3050 - 3060 - 3065 tractors.*

**Assembly B :** *4 inner plates, 4 outer plates and 1 spacer (28) for 3070, 3080-3095.*

**Assembly C :** *5 inner plates, 5 outer plates for 3115, 3125, 3120, 3140 tractors.*

53. Place the support housing (9) in a vice.

54. Remove the O-rings (3) and (6).

55. Remove the circlip (1).

56. Extract the ball bearing (2) with the sleeve (4) (Fig. 15).

57. Remove the seal rings (5) (Fig. 20). Extract the ball bearing (7) (Fig. 16).

58. Hold the spring (18) with the aid of a locally made tool (Fig. 17). For tool see page 12.

59. Remove the screws (24) and take off the washer (23) (Fig. 17). Gradually decompress the spring with the tool.

60. Remove the hub (21), the spring seat (19), the spring (18), the retainer (13) and the Belleville washer (12).

61. Remove the securing ring (20).

62. Extract the ball bearing (22).

63. Take out the piston (10).

64. Remove the O-rings (11), (25) and (26).




Fig. 14




Fig. 15




Fig. 16



## Rear axle - PTO clutch

### Reassembly

**Note:** The valve (8) is fitted in the support housing (9).

The sleeve (27), smeared with Loctite 648 (Fig. 18) is fitted with a press. If disassembly proves necessary, check when reassembling that the channel is not obstructed with Loctite.

Two pins (30) are fitted in the support housing (9) 5 mm from the face (Fig. 19).

65. Clean and check the parts. Replace those which are defective.

66. Using a suitable device and a press, push the ball bearing (7) in until it meets the shoulder.

67. Place the seal rings (5) in their grooves and join up the ends (Fig. 20). Ensure that they turn freely.

68. Slide the sleeve (4) on to the seal rings, taking care not to damage them.

**Note:** Position the larger diameter end of the sleeve towards the ball bearing (7).




Fig. 17




Fig. 18




Fig. 19




Fig. 20





**Rear Axle - Handbrake**

6101.1

*6 101 Handbrake*

CONTENTS

- General	2
- Operation	2
A. Disassembly	5
B. Reassembly	7
C. Fitting and adjustment of control	9



6101.2

## 3000/3100 SERIES TRACTORS



### Rear Axle - Handbrake

#### General

The handbrake assembly is fitted on the bevel drive pinion. It consists of a mechanism placed between two friction discs which are driven by the bevel drive pinion via splines.

The mechanism comprises two cast iron plates held by springs and separated by balls housed in cams.

#### Operation

When the handbrake lever in the cab is pulled, the cam (14) is moved via the pin (20). The cam pushes the actuator lever (13) which causes the plates of the mechanism (31) to rotate and move apart. The discs (30) are thus compressed between the moving plates, the closing plate (24) and the supporting plate (29), preventing the bevel drive pinion from rotating.

When the handbrake lever is released, the spring (17) moves the cam (14) to the rest position and the mechanism is closed by its springs.


#### Parts list

- (1) Circlip
- (2) Pinion
- (3) Stud
- (4) Nut
- (5) Plate
- (6) Pin
- (7) Clevis
- (8) Pin
- (9) Cotter pin
- (10) Left cover
- (11) Plug
- (12) Seal Ring
- (13) Actuator lever
- (14) Cam
- (15) Circlip
- (16) Finger
- (17) Spring
- (18) Dowel
- (19) Seal ring
- (20) Control shaft
- (21) Retainer ring
- (22) Washer
- (23) Finger
- (24) Closing plate
- (25) Screw
- (26) Bevel drive pinion
- (27) Shim(s)
- (28) Screw
- (29) Supporting plate
- (30) Discs
- (31) Mechanism





# Rear Axle - Handbrake






6101.4

3000/3100 SERIES TRACTORS



# Rear Axle - Handbrake

Exploded





## Rear Axle - Handbrake

### A. Disassembly

1. Drain the rear axle housing.
2. Block:
  - the front wheels of the tractor
  - between the engine frame and the front axle (Fig. 1).
3. Raise the tractor with a jack.
4. Place props in position.
5. Remove the rear wheels.
6. Remove the right-hand hydraulic cover. Carry out operations 2 to 14, chapter 8 I01.
7. Remove the left-hand cover. Carry out operations 2 to 6, chapter 8 I02.

#### Tractors without creeper gears

8. Drive out the double pins (2) and (4) of the coupling sleeves (1) and (5). Slide the sleeves towards each other on the pin (3).  
Remove the pin and sleeve assembly (Fig. 2).  
On 4RM tractors  
If the double pins are not accessible, carry out operations 9 to 12, chapter 5 D01.A.
9. Remove the circlip (1).
10. Remove the pinion (2) (if fitted).

#### Tractors with creeper gears

11. Remove the creeper gears control fork and the sleeve assembly (linking pin and coupler).  
Carry out operations 3 to 8, chapter 5 D01.A.
12. Carry out operations 13 to 16, chapter 5 D01.A.
13. Remove the circlip (1).
14. Remove the pinion (2) (if fitted).

#### Tractors with or without creeper gears

**Note:** Lift the cab, carry out operations 2 and 3, chapter 6 B01. Examine the space between the hood and the windscreen (if the space is inadequate, remove the sheetmetal).

15. Disconnect the cable (3). Take out the split pin (1) and remove the control arm (2) (Fig. 3).
16. Remove the seal (19).
17. Release the spring (17) using pliers.
18. Undo the nut to release the actuator lever (13) of the cam (14).
19. Remove the circlip (15).
20. Remove the cam (14) with the finger (16).
21. Remove the screws (25).




Fig. 1




Fig. 2




Fig. 3



6101.6



## Rear Axle - Handbrake

22. Remove the closing plate (24) and the control shaft (20).

**Note:** Keep the mechanism (31) and the brake discs (30) towards the rear. Withdraw the closing plate (24) (Fig. 4), inclining it in order to disengage it from the dowel (18), the finger (23) and the bevel drive pinion (26) and to release the shaft (20) from the housing.

23. Remove the spring (17) and the washer (22).  
24. Remove the retainer ring (21) (if necessary) on the control shaft (20).  
25. Remove the discs (30) and the mechanism (31).

### In case of replacement of mechanism

26. Undo the nut (4), remove the plate (5) and the pin (6).  
27. Remove the split pin (9), take out the pin (8) and the clevis (7).

**Note:** The stud (3) is smeared with Loctite 270 and locked in the clevis (7).

### If replacement of the supporting plate (29) is unavoidable

28. Remove two diametrically opposed screws (28) and screw in two guide studs (A) (Fig. 5). The purpose of this is to hold the shims [27] (Fig. 6).  
29. Unscrew the two remaining screws.  
30. Remove the supporting plate.

**Note:** Check that the shims have all remained on the housing.

The finger (16) smeared with Loctite 241 is screwed into the cam (14). The finger (23) smeared with Loctite 241 is screwed into the supporting plate (29).

The dowel (18) is pushed fully home on the shoulder of the closing plate (24).




Fig. 4




Fig. 5




Fig. 6



## Rear Axle - Handbrake

### B. Reassembly

31. Clean and check the parts. Replace any which are defective.

#### In case of replacement of supporting plate (29)

32. Refit the plate.
33. Smear two screws (28) with Loctite 241 then tighten to a torque of 90 - 120 Nm.
34. Remove the two guide studs.
35. Smear the other two screws (28) with Loctite 241 then tighten to a torque of 90 - 120 Nm.

#### In case of replacement of mechanism

36. Refit the clevis (7) prepared with the stud (3) and the pin (8). Replace the split pin (9).
37. Fit the lever (13) with its pin (6) on the stud (3) of the clevis.
38. Refit the plate (5), tighten the nut (4).  
**Note: The plate (5) is rectangular. It must be positioned horizontally, lengthwise, on the pin (6) in the lever (13) to be correct (Fig. 7).**
39. Replace the discs (30), placing the mechanism (31) between them.  
**Note: Fit the lever (13) on the finger (23). Check that the discs slide freely on the bevel drive pinion (26).**
40. Place the retainer ring (21) (if removed) on the shaft (20).
41. Fit the shaft (20) in the closing plate (24) with the washer (22) and the spring (17).
42. Reverse operation 22.
43. Check that the discs (30) and the mechanism (31) are correctly positioned.
44. Fit and tighten the screws (25) to a torque of 90 - 120 Nm.
45. Fit the cam (14) with its finger (16).
46. Fit the circlip (15). Replace the spring (17), positioning its ends E as indicated in Fig. 8.
47. Fit the seal (19) supported by the housing (Fig. 9).




Fig. 7




Fig. 8




Fig. 9



6101.8

## Rear Axle - Handbrake

### Tractors with creeper gears

48. Refit the pinion (2) (if fitted).
49. Position the circlip (1).
50. Refit the sleeve assembly (linking pin and coupler) and the creeper gears control fork. Carry out operations 22 to 31, chapter 5 D01.A.

**Note: If necessary reverse operations 9 to 12 (4 RM), chapter 5 D01.A.**

### Tractors without creeper gears

51. Refit the pinion (2) (if fitted).
52. Position the circlip (1).
53. Refit the sleeve assembly (linking pin and coupler) and the creeper gears control fork. Carry out operations 44 and 45, chapter 6 F01.

**Note: If necessary reverse operations 9 to 12 (4 RM), chapter 5 D01.A.**

### Tractors with or without creeper gears

54. Refit the left cover. Carry out operations 8 to 17, chapter 8 I02.
55. Position the lever (2) (Fig. 10) of the cam (14) in contact with the lever (13) so as to obtain a distance of 315 mm  $\pm$  12 between the cable fastening axis and the support (3). Fit the cotter pin (1) (Fig. 10).
56. Adjust the mechanism (31) with the adjusting nut, so that the cam displacement, from rest position to maximum position, is 60° (Fig. 11).

**Note: Access to the adjusting nut (4) is via the aperture of the plug (11) on the left cover (10) (Fig. 12).**

57. Reconnect the control.
58. Adjust the handbrake control. Carry out operations 73 to 75. Remove the blocks between the cab supports and the trumpet housings. Fit the washers. Position the cab. Tighten the nuts to a torque of 27 - 35 Nm and the lock-nuts, smeared with Loctite 270, to 13 - 20 Nm. Refasten the protecting panels.
59. Refit the right-hand hydraulic cover. Carry out operations 15 to 27, chapter 8 I01.
60. Raise the tractor with a jack.
61. Refit the wheels.
62. Remove the props and the jack.
63. Tighten the wheel nuts to a torque of 400 - 450 Nm.
64. Remove the blocks at the front of the tractor and between the engine frame and the front axle.




Fig. 10




Fig. 11




Fig. 12





## Rear Axle - Handbrake

65. Top up the oil level of the rear axle housing.
66. Check the operation of the electrical circuits, of the low pressure switch, of the solenoids and of the filter vacuum switch.
67. Check the operation of the lift.
68. Check for leaks at the joint faces, covers and hydraulic connectors.

### C. Fitting and adjustment of control

69. Introduce the cable (1) from below towards the cab interior and fasten with the clip (2) (Fig. 13).
70. Fix the cable end (7) on the brake lever (4) with the pin (5), the washer (6) and the split pin (3) (Fig. 13).  
**Note: Check that the cable is not constrained.**
71. Fit the outer cable stop (2) in the bracket (1) (Fig. 14).
72. Attach the end of the cable (7) to the lever (6) (Fig. 14).
73. Place the handbrake lever in the released position. Adjust so as to obtain a distance of  $315 \text{ mm} \pm 12$  between the nut (5) and the axis of the end of the cable (7) (Fig. 14).
74. Tighten the lock-nut (3) on the washer (4) (Fig. 14).  
**Note: For good alignment of the outer cable stop (2) and the cable (7), the nut (5) and the lock-nut (3) are mounted in front of the bracket (1) (Fig. 14).**
75. Check the operation of the control.
  - Pull the lever. Initial travel should be approximately 8 notches. The warning light on the instrument panel should come on.
  - Release the lever. The control should revert freely to the rest position and the warning light on the instrument panel should go off.





**Rear Axle - Differential**

6J01.1

**6 J01 Differential**

**CONTENTS**

- General	2
A. Removal of left hand carrier cover and of differential lock assembly	5
B. Disassembly and reassembly of differential lock	5
C. Refitting of left hand carrier cover and of differential lock assembly	6
D. Removal of differential assembly	7
E. Disassembly of differential assembly and crownwheel	8
F. Removal and disassembly of bevel drive pinion	9
G. Reassembly of crownwheel and differential assembly	10
H. Reassembly and refitting of bevel drive pinion	11
I. Refitting of differential assembly	13
J. Service tool	16





6J01.2

## 3000/3100 SERIES TRACTORS



### Rear Axle - Differential

#### General

The bevel crownwheel and pinion, whose movement is provided by the output shaft of the gearbox, drives the rear axle through a connecting shaft.

The helical bevel drive pinion is supported on either side by taper roller bearings.

The bearing cones are force-fitted on the pinion, and the rear bearing cup is also force-fitted in the rear axle housing. The front bearing cup moves freely in its bore to enable the shimming of the pinion.

The crownwheel is fixed to the differential housing by rivets. The differential assembly turns on two taper roller bearings supported by two side carriers screwed on to the rear axle housing.

The differential assembly comprises two housing halves containing four planetary pinions and two sun gears.

The pinion is fitted in the rear axle housing with a preload obtained by means of shims placed between the handbrake backing plate and the axle housing.

The shimming of the differential assembly is carried out with deflectors (shims) of different thicknesses placed behind the bearing cup of the left hand cup bearing.

#### Differential lock

The left hand carrier houses the differential lock mechanism.

The system comprises a piston and a splined sliding coupler rotating with the left sun gear. The piston acts on the sliding coupler when pressure from the 17 bar hydraulic circuit is supplied by the solenoid valve fitted on the right hand cover. The piston moves, pushing the sliding coupler and compressing the spring.

The teeth of the sliding coupler engage with a fixed coupler attached to the differential housing. In this position, the sun gears of the right and the left hand trumpet housings turn at the same speed. When the pressure is released, the coupler moves back towards the rear under the influence of the spring.

#### Parts list

- (1) O-ring
- (2) Screw
- (3) O-ring
- (4) Circlip
- (5) Piston
- (6) Spring
- (7) Sliding coupler
- (8) O-ring
- (9) Left hand carrier
- (10) Differential lock hydraulic assembly
- (11) Thrust washer
- (12) Finger
- [13] Deflector (shim)
- (14) Bearing cup
- (15) Screw
- (16) Coupler
- (17) Bearing cone
- (18) Washer
- (19) Sun gear
- (20) Planetary pinions
- (21) Washer
- (22) Cross joint
- (23) Crownwheel
- (24) Rivet
- (25) Right hand carrier
- (26) Screw
- (27) Bearing cup
- (28) Bearing cone
- (29) Crownwheel carrier
- (30) Bearing cone
- (31) Bearing cone
- (32) Screw
- (33) Bearing cup
- (34) Bevel drive pinion
- (35) Supporting plate
- [36] Shim(s)
- (37) Bearing cup
- (38) Pipe
- (39) Connector
- (40) Differential lock supply tube



# Rear Axle - Differential


6J01.3

## General arrangement


Backlash J1 between gears and planetary pinions +0.08 to +0.30

Shimming P1  
Preload = -0.05 to -0.12

Backlash J2 = +0.15 to +0.40



**P2**  
Shim with deflector to obtain a preload on the roller bearings of 0 to -0.25






6J01.4

3000/3100 SERIES TRACTORS



# Rear Axle - Differential





## Rear Axle - Differential

### A. Removal of left hand carrier and of differential lock assembly

**Note:** It is possible to work on the differential lock hydraulic assembly (10) with only the left hand axle housing removed.

1. Remove the left hand axle housing .

#### 3000 tractors

Carry out operations 1 to 17, chapter 6C01.A.

#### 3100 tractors

Carry out operations 1 to 15, chapter 6C02.A.

#### 3000 - 3100 tractors

2. Disconnect the supply tube (38), unscrew the connector (39) and withdraw the tube (40) (Fig. 1).  
**Note:** If access to the connector (39) is difficult, on «economy 4-speed p.t.o.» version tractors, remove the control (1) (Fig. 1).
3. Undo the screws (2) alternately so as to release the spring (6) gradually.
4. Remove the carrier (9), the washer (11), the sliding coupler (7) and the spring.




Fig. 1

### B. Disassembly and reassembly of differential lock

#### Disassembly

5. Withdraw the bearing cup (14) and the deflector (13).  
**Note:** Mark the direction of mounting of the deflector.
6. Remove the circlip (4).
7. Withdraw the piston (5) with the aid of a jet of compressed air (Fig. 2). Exercise caution.
8. Remove the O-rings (3), (8) and (1).
9. Unscrew the finger (12) (if necessary).




Fig. 2

#### Reassembly

10. Check the parts and replace any which are defective.
11. Clean the finger (12), smear it with Loctite 221, then fit and tighten it on the carrier (9).
12. Smear the O-rings (3) and (8) with miscible grease (Amber Technical or equivalent), in order to retain them correctly in the bottom of their respective grooves.
13. Using a plastic mallet, fit the piston (5) back in the carrier (9) (Fig. 3), paying attention to the position of the finger (12).




Fig. 3



6J01.6

# Rear Axle - Differential

- 14. Fit the circlip (4), the deflector [13] ensuring that it is fitted the right way round and the bearing cup (14) (Fig. 4).

## C. Refitting of left hand carrier and of differential lock assembly

- 15. Fit the O-ring (1).
- 16. Screw in two guide studs «G» diagonally opposite on the housing (Fig. 5).
- 17. Refit the spring (6), the sliding coupler (7), the thrust washer (11) and the carrier (9).  
**Note: Position the feed port of the differential lock towards the top.**
- 18. Fit and tighten two screws (2) to a torque of 85 - 130 Nm. Remove the guide studs. Fit and tighten the two other screws to the same torque (Fig. 5).
- 19. Fit the pipe (40) and the connector (39) (Fig. 1).




Fig. 4

### Leak test

After working on the piston (5), the seals (3) and (8) and the carrier (9), it is necessary to check the assembly for leaks.

- 20. Fit a pressure gauge and valve on the supply connector (39)(Fig. 6).
- 21. Feed compressed air at approx. 5 bar into the system to check the correct movement of the piston. Reduce the pressure to 0.3 bar to carry out the leak test.
- 22. Close the valve. Over 1 minute the pressure gauge should not show any drop in pressure.
- 23. Disconnect the pressure gauge and connect the supply pipe (38) (Fig. 1).




Fig. 5

**If necessary:** Reconnect the «economy 4-speed p.t.o.» control and carry out adjustment. Carry out operations 127 and 132 to 137, chapter 6D01.

- 24. Reconnect the left hand axle housing.

### 3000 tractors

Carry out operations 18 to 36, chapter 6C01.A.

### 3100 tractors

Carry out operations 16 to 33, chapter 6C02.A.

- 25. Check for leaks of the supply pipe (38) (Fig. 1) and the operation of the differential lock.




Fig. 6



## Rear Axle - Differential

### D. Removal of differential assembly

#### 3000 - 3100 tractors

26. Immobilise the tractor. Apply the handbrake. Chock the front wheels and the axle frame (see 3A.02 - Fig. 2).
27. Drain the rear axle only.
28. Lift the rear of the tractor with a trolley jack.
29. Place stands under the rear axle housing.
30. Remove the wheels.
31. Remove the right and left hand axle housing.

#### 3000 tractors

Carry out operations 6 to 17, chapter 6C01.A.

#### 3100 tractors

Carry out operations 6 to 15, chapter 6C02.A.

**Note: Check the space between the hood and the windscreen. (If the space is too narrow, remove the sheetmetal.)**

On both series of tractor, the cab should be supported on either side with suitable stands in front of the front support of the tank (Fig. 7). On the right hand side, pay attention to the heating pipes. If necessary, unscrew the fastening brackets.

#### 3000 - 3100 tractors

32. Disconnect the fuel supply and return hoses and the harness to the tank gauge.
- Note: Mark the harness connectors.**
33. Partly empty the tank. Remove the fuel tank and then the tank support.
34. Remove the lift cover. Carry out operations 4 to 11, chapter 6B01.
35. Remove the top link support, the drive pinion and the layshaft.

#### 2-speed p.t.o. tractors

Carry out operations 4 to 7, chapter 6D01.

#### 4-speed p.t.o. tractors

Carry out operations 63 to 68 and 72 to 78, chapter 6D01.

36. Remove the pipe (40) (Fig. 8).
37. Support the differential assembly using a hoist and a G clamp (Fig. 9).
38. Slacken the screws (2) alternately so as to release the spring (6) gradually.
39. Remove the carrier (9), the spring (6), the coupler (7) and the washer (11).
40. Remove the screws (26).
41. Remove the cover (25).
42. Withdraw the differential assembly from the housing (Fig. 9).




Fig. 7




Fig. 8




Fig. 9



6J01.8

## Rear Axle - Differential

### E. Disassembly of differential assembly and crownwheel

43. Place the assembly on a workbench.
44. Remove the bearing cones (17) - (28) and the cup (27) (Fig. 10 - 11 - 12).
45. Remove the screws (15).
46. Remove the fixed coupler (16).
47. Separate the two parts of the housing (29).

**Note: These pieces each have the same number. They must be paired.**

48. Remove the washers (18), the sun gears (19), the planetary pinions (20), the washers (21) and the cross joint (22) (Fig. 13).

**Note: When the crownwheel is replaced, the bevel drive pinion must be replaced as well. These pieces each have the same number and must be paired.**

**In the factory the crownwheel and the carrier are assembled by means of rivets.**

**For the purposes of repair, the rivets are replaced with screws and nuts.**




Fig. 10




Fig. 11




Fig. 12




Fig. 13



## Rear Axle - Differential

### Disassembly of the crownwheel (23)

49. Remove the crownwheel from the housing.
50. Make a centre mark in the centre of each rivet (24) (crownwheel teeth side).
51. Drill the rivets to a depth of 10 mm with a 5 mm diameter drill (Fig. 14).
52. Drill out to a diameter of 12 mm and to the same depth.
53. Drive the rivets out with a suitable drift punch (Fig. 15).




Fig. 14




Fig. 15

### F. Removal and disassembly of bevel drive pinion

54. Remove the right hydraulic cover. Carry out operations 2 to 14, chapter 8I01.
55. Remove the left hydraulic cover. Carry out operations 3 to 6, chapter 8I02.

#### Tractors without creeper gears

56. Drive out the double pins (2) and (4) from the sleeves (1) and (5). Slide the sleeves towards one another on the shaft (3) (Fig. 16). Remove the shaft and sleeve assembly.




Fig. 16





6J01.10

## Rear Axle - Differential

### On 4WD tractors

If the double pins are not accessible, carry out operations 9 to 12, chapter 5D01.A.

57. Remove the circlip (1) and detach the gear (2) (if fitted) (Fig. 17).

### Tractors with creeper gears

58. Carry out operations 3 to 8, chapter 5D01.A.

59. Carry out operations 13 to 16, chapter 5D01.A.

60. Remove the circlip (1) and detach the gear (2) (if fitted) (Fig. 17).

### Tractors with or without creeper gears

61. Remove the handbrake mechanism assembly.  
Carry out operations 15 to 25, chapter 6I01.

62. Remove the screws (32), the supporting plate (35) and the shims [36].

63. Remove the bearing cup (33) and the bevel gear pinion fitted with bearing cones (30) and (31).

64. Remove the bearing cup (37).

65. Extract the bearing cones (30) and (31).




Fig. 17

## G. Reassembly of crownwheel and differential assembly

66. Check that the crownwheel and the bevel gear pinion have the same number.

67. Clean the contact faces of the new crownwheel (23) and of the carrier (29) and the screws and nuts referred to in the spare parts catalogue.

68. Smear the screws (1) (Fig. 18) with Loctite 270 on the first threads and place them in the crownwheel and carrier.

69. Tighten and lock the nuts (2) (Fig. 18) to a torque of 150 - 160 Nm.




Fig. 18

### Reassembly of differential assembly

70. Check the parts and replace any which are defective.

71. Reverse operations 46 to 48.

72. Smear the screws (15) with Loctite 270, then tighten them to a torque of 85 - 130 Nm.

**Note: The clearance J1 between the planetary pinions and the bull gears must be between +0.08 and +0.30.**








## Rear Axle - Differential

73. Push the bearing cup (27), the bearing cones (17) and (28) against the shoulder with the aid of a press and a suitable device (Figs. 19 - 20 - 21).

### H. Reassembly and refitting of the bevel drive pinion

#### Reassembly

74. Check the parts, replace any which are defective.  
75. Using a press and a suitable device, push the bearing cones (31) and (30) against the bevel drive pinion (Figs. 22-23).





6J01.12



## Rear Axle - Differential

### Refitting

76. Smear the periphery of the cup (37) with Loctite 603 and push it against the shoulder in the housing using a suitable tool.
77. Fit the pinion with bearing cones and cup (33).

**Note : Ensure the bearing cones and cups are clean and lubricated.**

### Method 1 for setting pre-load.

78. To determine correct shim thickness, add shims to a greater thickness than "a", i.e. protrusion of cup (33) from housing face (Fig. 24) in order to provide some end float.
79. Screw two guide studs in opposite positions into the housing. Fit the shims [36] of the thickness determined in operation 78 and the supporting plate (35).
80. Fit the screws (32), remove the guide studs and tighten to a torque of 90 - 120 Nm.
81. Now calculate the shims required to obtain P1 (Fig. 25) as follows.
82. Place the tip of a dial indicator against the drive pinion (Fig. 26).
83. Through the opening for the right hand hydraulic cover, pull on the pinion shaft turning it back and forth to ensure the bearing cones and cups are correctly seated.
84. Now set the dial indicator to zero.
85. Repeat operation 83 while pushing.
86. The correct thickness of shims required is the reading from the dial indicator, plus the pre-load of **0.05 to 0.12**, subtracted from shim thickness determined in operation 78.
87. Remove two screws (32), screw in two guide studs. Remove the two other screws and the supporting plate (35).
88. Fit the shims [36] selected in operation 86 and refit the supporting plate.
89. Fit the screws (32) smeared with Loctite 270. Remove the guide studs and tighten to a torque of 90 - 120 Nm.

### 2nd method (rear axle on a support only)

The principle involves removing or adding shims [36] to obtain torque of 0.80 to 2.00 Nm, measured with a rolling torque gauge or spring balance.

**Note: Each time the screws (32) are refitted, always tighten to a torque of 90 - 120 Nm.**

On the final refitting, smear the screws with Loctite 270 and apply the above - mentioned torque.




Fig. 24




Fig. 25




Fig. 26



## Rear Axle - Differential

### I. Refitting of differential assembly

90. Place the differential assembly in the housing (Fig. 27).
91. Screw in two guide studs in opposite positions and mount the right hand carrier (25).  
**Note: Position the oil passage of the carrier downwards.**
92. Fit and tighten two screws to a torque of 85 - 130 Nm. Remove the two guide studs. Fit and tighten the two other screws to the same torque.
93. Remove the cup (14) and the deflector [13] of the left hand carrier(9). Place the cup on the bearing cone (17).
94. Mount tool 3376847 M91 in the housing using two screws (2) tightened to a torque of 85 - 130 Nm (Fig. 28).
95. Tighten the central screw of the tool to a torque of 10 Nm (Fig. 28).  
**Note: Turn the crownwheel a few times to "seat" the bearing cones correctly in the cups. Recheck the tightening torque of the central screw of the tool.**
96. Fit and tighten calibrated spacers (A) (Fig. 28) in the two other holes in the housing.
97. Now determine shims P2 (Fig. 29) to obtain pre-load of : **zero to +0.25**
98. Place a straight edge against the two calibrated spacers.
99. Measure the gap J between the finger of the tool and the straight edge (B) with a feeler gauge (Fig. 30).




Fig. 27




Fig. 28




Fig. 29




Fig. 30



6J01.14

# Rear Axle - Differential

100. Calculate the distance C between the cup (14) and the contact face of the carrier (9) (Fig. 31).  
 **$C = (114 + J) - 70$**
101. On the carrier (9), determine the distance Y with a depth gauge and a straight edge (Fig. 32).
102. Select the correct thickness of the deflector [13] (see table) to obtain:  
 **$P2 = C - Y$**   
**Note: For carrying out shimming P2 there are eight deflectors of different thicknesses. If the determined value P2 is between two thicknesses deflector, select the thinner of the two.**
103. Remove the tool and the cup (14).
104. Place the deflector [13] selected in operation 102 and the cup (14) in the cover (9).  
**Note: Ensure that the deflector is mounted the right way round (Fig. 33).**
105. Screw in two guide studs in opposite positions.  
**Assemble :** the washer (11), the sliding coupler (7) and the spring (6) in the carrier (9). Fit the assembly with the feed orifice of the differential lock towards the top.
106. Fit and tighten two screws to a torque of 85 - 130 Nm. Remove the two guide studs. Fit and tighten the two other screws to the same torque.
107. Check the backlash between the crownwheel and bevel drive pinion:  
 **$J2 = +0.15$  to  $+0.40$**




Fig. 31





Fig. 32



Reference	Number of dots	mm
187 689 M1	0	0.73 - 0.78
892 173 M1	1	0.864 - 0.914
892 172 M1	2	0.991 - 1.041
892 171 M1	3	1.118 - 1.168
892 170 M1	4	1.245 - 1.295
191 124 M1	5	1.37 - 1.42
191 125 M1	6	1.49 - 1.54
521 401 M1	7	0.61 - 0.66




Fig. 33



## Rear Axle - Differential

108. Place the tip of the dial gauge on a tooth of the crownwheel (Fig. 34).

**Note:** Carry out this operation at four diametrically opposed points on the crownwheel. Clearance J2 is obtained as a function of the machining tolerances. If this clearance is outside the maximum tolerance, after shimming P2 has been carried out, it is possible to reduce the thickness of the deflector [13]. Place a shim of suitable thickness between the cup (27) and the carrier (29).

109. Check clearance J2 again.

### Refitting of the handbrake mechanism assembly

**Note:** The plate /5\ is rectangular. It must be positioned horizontally, lengthwise, on the pin(6) in the lever (13) to be correct (Fig. 35).

110. Carry out operations 39 to 47, chapter 6I01.

### Tractors with creeper gears

111. Refit the gear (2) (if mounted) and the circlip (1) (Fig. 36).

112. Refit the fork and the sleeve, connecting shaft and coupler assembly. Carry out operations 22 to 30, chapter 5D01.A.

Reconnect the creeper gears control cable.  
If necessary reverse operations 9 to 12, chapter 5 D01.A (4WD).

### Tractors without creeper gears

113. Refit the gear (2) (if mounted) and the circlip (1) (Fig. 36).

114. Refit the sleeve, connecting shaft and coupler assembly. Carry out operations 44 and 45, chapter 6F01. If necessary reverse operations 9 to 12, chapter 5 D01.A (4WD).

### Tractors with or without creeper gears

115. Refit the left hand cover. Carry out operations 7 to 11, chapter 8I02.

Mount the handbrake control support, the G.S. PTO support (if fitted), remove the guide studs, fit and tighten the screws to a torque of 72 - 96 Nm.

116. Position the control rod and adjust the handbrake mechanism.

Carry out operations 55 to 57, chapter 6I01.




Fig. 34




Fig. 35




Fig. 36



6J01.16

## 3000/3100 SERIES TRACTORS



### Rear Axle - Differential

117. Reconnect the G.S. PTO control (if fitted), the supply hose of the lift valve, the supply pipe of the rams and the lift and lowering valves (yellow connector). Clip the wire assembly to the valve supply hose.
118. Refit the right hand hydraulic cover.  
Carry out operations 15 to 27, chapter 8I01.
119. Refit the layshaft, the driving pinion and the top link support.
126. Raise the rear of the tractor with a trolley jack. Refit the wheels. Remove the stands under the rear axle. Tighten the wheel nuts to a torque of 400 - 450 Nm.
127. Top up the oil in the housing and remove the chocks. Refit the sheetmetal (if removed).
128. Start the engine. Carry out a road test. Check the operation of the controls and of the electrical circuits.
129. Check for leaks of the joint faces of the trumpet housings on the centre housing, of the covers and of the hydraulic connectors.

#### Tractors with 2-speed p.t.o.

Carry out operations 8 to 13, chapter 6D01.

#### Tractors with 4-speed p.t.o.

Carry out operations 79 to 82 and 85 to 92, chapter 6D01.

120. Refit the lift cover.  
Carry out operations 53 to 57 and reverse operation 7, chapter 6B01.  
Fix the harnesses with a clip.
121. Refit the fuel tank.  
Reconnect the fuel supply and return hoses and the harness of the tank gauge (connect as marked upon disassembly).
122. Refit the right hand and left hand trumpet housings.

#### 3000 tractors

Carry out operations 18 to 31, chapter 6C01.A.

#### 3100 tractors

Carry out operations 16 to 27, chapter 6C02.A.  
Refit the stabiliser support.

#### 3000 - 3100 tractors

123. Refill with fuel.
124. Refit the support with the auxiliary spool valves.  
Carry out operations 65 to 69, chapter 6B01.
125. Check the adjustment of the controls:  
**Ground speed PTO**: carry out operations 114 to 120, chapter 6F01.  
**Handbrake**: Carry out operations 71 to 75, chapter 6I01.  
**Shiftable PTO**: Carry out operations 47 and 52 to 58, chapter 6E02.  
**Economy 4-speed**: Carry out operations 127 and 132 to 137, chapter 6D01.  
**Creeper gears**: Carry out operations 24 and 29 to 34, chapter 5J01.

#### J. Service tool

Shimming tool 3376847 M91, available from the M.F. network.




Fig. 37



**Rear Axle - Brake pistons and seals**

**6 K01 Brake pistons and seals**

**CONTENTS**

- General	2
A. Disassembly	2
B. Reassembly	3
C. Bleeding of main braking circuit	4
D. Bleeding of trailer braking circuit	5





6K01.2

## Rear Axle - Brake pistons and seals

### General

The brake pistons are housed in two lateral cavities of the rear axle housing, concentric with the supporting face of each trumpet housing (see 5 A01, page 5). They comprise a shouldered part and are guided by 3 dowels force-fitted in the housing. Sealing is provided by 2 O-rings mounted in grooves of the rear axle housing. Each piston is controlled by a master cylinder supplied by a residual oil flow coming from the 17 bar valve. Each piston acts directly on a friction disc mounted on the planetary shaft at the entrance of the trumpet housing and a backplate centred by dowels and supported on the ring gear of the final drive unit. When the brake is released, there is minimal clearance between the piston and the disk. The brakes are self-adjusting and pedal travel remains constant. The discs are constantly lubricated by oil from the rear axle; the film of oil is maintained on the braking surfaces when they are not in use and cools the brakes when they are used.




Fig. 1




Fig. 2

### A. Disassembly

#### 3000 Tractors

1. Remove the trumpet housing. Carry out operations 1 to 15, chapter 6 C01.A.

#### 3100 Tractors

2. Remove the trumpet housing. Carry out operations 1 to 13, chapter 6 C02.A.

#### 3000 - 3100 Tractors

3. Remove the disc (1), the planetary shaft (2), the dowel (3) (Fig. 1).
4. Remove the backplate (1) (trumpet housing interior) (Fig. 2).
5. Withdraw the piston (1) from the housing with a jet of compressed air applied to the connector (2) (Fig. 3).

**Note:** To facilitate access to the connector (2), if necessary, disconnect the economy 4-speed p.t.o. control and rotate the connector.




Fig. 3



## Rear Axle - Brake pistons and seals

6. Remove the O-rings (1) and (2) on the centre housing and discard them.

### B. Reassembly

#### 3000 - 3100 Tractors

7. Clean and check the parts. Replace any which are defective.
8. Fit the piston (1) without seals in the housing (2) (Fig. 5).  
**Note:** Check that the piston slides freely in the bore of the housing and over the dowels (3) without binding (Fig. 5).
9. Fit new O-rings (1) and (2) (Fig. 6).  
**Note:** Lightly smear the seals with miscible grease («Amber technical» or equivalent) in order to keep them correctly at the bottom of the groove.




Fig. 4




Fig. 5




Fig. 6




Fig. 7



6K01.4

## Rear Axle - Brake pistons and seals

10. Position the piston over the dowels, then fit it in to place with the aid of a plastic mallet, striking alternate points around the circumference (Fig. 7).
11. Hold the piston with two large washers and two screws diametrically opposed (Fig. 8).

### Leak test (operations 12 to 15, Fig. 8).

If work is carried out on the brake piston and O-rings, it is necessary to check for leaks.

12. Fit a pressure gauge to the connector (2).
13. Supply the circuit with compressed air at approx. 5 bar, so as to ensure operation of the piston. Reduce the pressure to 0.3 bar to carry out the test.
14. Close the pressure reducing valve. For 1 min. no reduction in pressure should be indicated at the pressure gauge.
15. Disconnect the pressure gauge. Remove the screws and the holding washers. Reconnect the brake hose.

### 3000 Tractors

#### Refitting the trumpet housing

16. Refit the trumpet housing. Carry out operations 18 and 19, chapter 6 C01.A.
17. Refit the planetary shaft (2), the disc (1) and the dowel (3) (Fig. 1).  
**Note: Check that the disc slides freely on the planetary shaft.**
18. Carry out operations 22 to 34, chapter 6 C01.A.

### 3100 Tractors

#### Refitting the trumpet housing

19. Refit the trumpet housing. Carry out operations 16 and 17, chapter 6 C02.A.
20. Refit the planetary shaft (2), the disc (1) and the dowel (3) (Fig. 1).  
**Note: Check that the disc slides freely on the planetary shaft.**
21. Carry out operations 20 to 31, chapter 6 C02.A.

### 3000 - 3100 Tractors

22. Bleed the main braking circuit and the trailer braking circuit (if fitted), see C and D.
23. Test:
  - lifting
  - braking on the road
24. Check for leaks
  - between the trumpet housing and the rear axle housing
  - at the lift valve supply hose (left hand trumpet housing)




Fig. 8

## C. Bleeding of main braking circuit

25. To each vent screw (1) on the left and right hand of the rear axle housing attach a transparent hose (int. dia. 6 mm) (Fig. 9).
26. Immerse the ends of the two hoses in a container partially filled with transmission oil (Fig. 9).
27. Run the engine at approx. 1200 rpm. Using suitably protected pliers or clamp stop up the return hose (1) (Fig. 11).
28. Open the right vent screw. Check that there are no leaks between the pipe and the vent screw.
29. Unlock the brake pedals.
30. **Gently** depress the right pedal through its entire travel and release it in the same way. Repeat the operation several times until the oil flows without air bubbles.
31. Close the vent screw and remove the pliers.
32. Open the left vent screw. Check that there are no leaks between the pipe and the vent screw.
33. **Gently** depress the left pedal through its entire travel and release it in the same way. Repeat the operation several times until the oil flows without air bubbles.
34. Close the vent screw and remove the pliers.
35. Activate each pedal several times in order to position the brake pistons.
36. Check the hardness of action of each pedal.  
**Note: If a problem of functioning should appear, carry out bleeding a second time.**  
**If the problem persists, check for leaks:**
  - from the circuit
  - at the master cylinders
  - at the piston seals.







## Rear Axle - Brake pistons and seals

### D. Bleeding of trailer braking circuit

**Note:** It is imperative to bleed the main braking circuit before bleeding the trailer braking circuit.

37. To the vent screw of the pilot head of the trailer brake valve attach a transparent hose (int. dia. 4 mm) (Fig. 10).
38. Immerse the end of the hose in a container partially filled with transmission oil (Fig. 10).
39. Run the engine at approx. 1200 rpm. Using suitably protected pliers stop up the return hose (1) (Fig 11).
40. Open the vent screw. Check that there are no leaks between the pipe and the vent screw.
41. **Gently** depress the twin pedals. Repeat the operation several times until the oil flows without air bubbles.
42. Close the vent screw and remove the pliers.
43. Connect a pressure gauge to the trailer brake connector (Fig. 12).
44. Run the engine at approx. 2000 rpm.
45. **Gradually** depress the twin brake pedals.
46. The pressure obtained should be between 130 and 150 bar maximum.





**Rear Axle - Automatic hitch**

6M01.1

*6 M01 Automatic hitch*

CONTENTS

A. Adjustment of automatic hook control \_\_\_\_\_ 2

B. Adjustment of automatic hook \_\_\_\_\_ 3



6M01.2






## Rear Axle - Automatic hitch

### A. Adjustment of automatic hitch control

**Note: Operations 2 to 5 must be carried out when replacing the control cable.**

1. Set the lever "U" to the «locked» position (Fig. 1).
2. Turn the clevis (1) until it meets the end of the threaded part of the cable (7).
3. Attach the clevis (1) to the lever "U" with the clip (2). Tighten the nut (3).
4. Adjust the outer cable stop (6), with the nut (4) reaching the end of the threaded part.
5. Tighten the nut (5).
- Note: Check that the cable is not constrained.**
6. Screw the clevis (2) until it reaches the threaded part of the cable (4) (Fig. 2).
7. Fit the clevis (2) to the lever "V" with the clip (1).
- Note: Make sure that the lever "V" is in the locked position.**
8. Tighten the nut (3).
9. Fit the outer cable stop (7) in the support (8), then tighten the nut (6) in such a way that the cable (4) is not subject to any constraint or any play.
10. Tighten the nut (5).





## Rear Axle - Automatic hitch

### B. Adjustment of automatic hitch

11. Start the engine.
12. Press on the internal or external lift control button so that the lift system is in the continuous pumping position.
13. Raise the lower part of the hook with the aid of a trolley jack (Fig. 3).
14. Having ensured that the upper parts of the lift rods are fixed, adjust the length of the rods by turning the lower rod (4) so that it is able to engage the clevis (3) on the hook pin (1), leaving a play of between 0 and 1 mm.
15. Fit the split pins (2).
16. Activate the internal hitch control button inside the cab and check that there is play of  $10.5 \text{ mm} \pm 1.5$  between the latch (1) and the locking pin (2) (Fig. 4).
17. Remove the trolley jack.
18. Check the operation of the hook.
19. Fit the protection plate.




Fig. 3




Fig. 4

